

[Manuals.plus](#) /

› [Wisoqu](#) /

› Wisoqu HiFi ANC ENC Noise Cancelling Cordless Earbuds User Manual

## Wisoqu Wisoquxheui8zfo3

# Wisoqu HiFi ANC ENC Noise Cancelling Cordless Earbuds User Manual

MODEL: WISOQUXHEUI8ZFO3

## 1. Introduction

Thank you for choosing the Wisoqu HiFi ANC ENC Noise Cancelling Cordless Earbuds. These earbuds are designed to provide a superior audio experience with advanced features such as Active Noise Cancellation (ANC), Environmental Noise Cancellation (ENC), and a convenient LED touchscreen charging case. This manual will guide you through the setup, operation, and maintenance of your new earbuds.

# SMART HEADSET



*Support protocol: HFP/A2DP/HSP/ AVRCP*



**Bluetooth  
5.4**



**Noise  
Reduction**



**LED Touch  
Screen**

Image: Smart Headset features including Bluetooth 5.4, Noise Reduction, and LED Touch Screen.

## 2. Safety Information

- Do not disassemble or modify the product.
- Keep the earbuds and charging case away from water, moisture, and extreme temperatures.
- Avoid prolonged exposure to high volume levels to prevent hearing damage.
- Dispose of batteries and electronic components responsibly according to local regulations.
- Use only the provided or certified charging cables.

## 3. Package Contents

Please check the package for the following items:

- Wisoqu Cordless Earbuds (Left and Right)
- LED Touchscreen Charging Case
- USB Charging Cable
- Multiple Pairs of Silicone Ear Tips (various sizes)



Image: Contents of the Wisoqu Earbuds package.

#### 4. Product Overview

The Wisoqu earbuds feature an ergonomic in-ear design for comfort and a secure fit. The charging case includes an LED touchscreen for easy control and status display.



Image: Wisoqu earbuds in their LED touchscreen charging case.



Image: Close-up of the Wisoqu earbuds.

### Key Components:

- **Earbuds:** Equipped with Graphene Diaphragm units for HiFi sound, touch controls, and microphones for calls.
- **Charging Case:** Houses the earbuds, charges them, and features an LED full-color touchscreen for various functions.
- **Touch Controls:** Both earbuds feature touch-sensitive areas for media playback, call management, and noise control.

## 5. Setup

---

### 5.1 Charging the Earbuds and Case

1. Place the earbuds into the charging case. Ensure they are correctly seated.
2. Connect the USB charging cable to the charging port on the case and a power source.
3. The LED touchscreen on the case will display the charging status. A full charge for the case takes approximately 1.5 hours.
4. The earbuds will charge automatically when placed in the powered case.

# LONG LASTING BATTERY LIFE



*Headset: 2\*30mAh lithium-ion battery*

*Charging Case: 400mAh lithium-ion battery*

Large capacity new energy lithium battery, charging time 1.5h, talk time 1.5h, lower power consumption



Image: Battery specifications and charging time.

## 5.2 Bluetooth Pairing

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth.
4. Search for available Bluetooth devices and select "Wisoqu Earbuds" (or similar name) from the list.
5. Once connected, the LED touchscreen may indicate a successful connection, and you will hear an audio prompt.
6. The earbuds will automatically reconnect to the last paired device when taken out of the case, if Bluetooth is enabled on the device.

## 6. Operating Instructions

### 6.1 Power On/Off

- **Power On:** Open the charging case, and the earbuds will power on automatically.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will power off automatically.

### 6.2 Music Playback Control

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.

### 6.3 Call Management

- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold either earbud for 2 seconds.

## 6.4 Active Noise Cancellation (ANC) & Environmental Noise Cancellation (ENC)

These earbuds feature both ANC for reducing ambient noise and ENC for clear call quality. Specific touch gestures or options on the LED touchscreen allow you to toggle between modes or activate/deactivate noise cancellation features. Refer to the on-screen prompts on the charging case for detailed control.

## 6.5 Video Controller Function

The charging case's LED touchscreen supports control for various short video applications when connected to your phone. You can use the screen to play, pause, and skip tracks directly within compatible video apps.




Image: Video Controller function via the charging case touchscreen.

## 6.6 Find Your Earbuds Feature

If you misplace an earbud, the charging case or a connected app may offer a 'Find My Earbuds' function to help locate them by emitting a sound or showing their last known location.

Find your earbuds  
Never worry about dropping your earbuds again



Image: Illustration of the 'Find your earbuds' feature.

## 7. Maintenance

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the earbuds and charging case. Do not use harsh chemicals or abrasive materials.
- **Ear Tips:** Regularly remove and clean the silicone ear tips with water and mild soap. Ensure they are completely dry before reattaching.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place.

## 8. Troubleshooting

- **Earbuds not pairing:** Ensure both earbuds are in the case, charged, and the case lid is open. Turn off and on your device's Bluetooth, then try pairing again.
- **No sound from one earbud:** Place both earbuds back in the case, close the lid, wait a few seconds, then open it

again. Reconnect to your device.

- **Charging issues:** Check the charging cable and adapter. Ensure the earbuds are properly seated in the case. Clean the charging contacts if necessary.
- **Touch controls unresponsive:** Ensure your fingers are clean and dry. Try restarting the earbuds by placing them in the case and taking them out again.

## 9. Specifications

Feature	Specification
Model Name	Wisoquxheui8zfo3
Connectivity Technology	Bluetooth V5.4
Noise Control	Active Noise Cancellation (ANC), Environmental Noise Cancellation (ENC)
Form Factor	In Ear
Control Method	Touch, LED Touchscreen (Case)
Material	PC+ABS
Earbud Battery Capacity	2 * 30mAh Lithium-ion
Charging Case Battery Capacity	400mAh Lithium-ion
Charging Time (Case)	Approx. 1.5 hours
Item Weight	4.3 ounces

## 10. Warranty and Support

Wisoqu products are designed and manufactured to the highest quality standards. For warranty information, technical support, or customer service inquiries, please refer to the contact information provided with your purchase or visit the official Wisoqu website. Please retain your proof of purchase for warranty claims.