

[Manuals.plus](#) /

› [OUTON](#) /

› OUTON H-LDD006 Dimmable Floor Lamp with Shelf User Manual

OUTON H-LDD006

OUTON H-LDD006 Dimmable Floor Lamp with Shelf User Manual

Model: H-LDD006

1. INTRODUCTION

Thank you for choosing the OUTON H-LDD006 Dimmable Floor Lamp with Shelf. This modern floor lamp combines ambient lighting with practical storage, featuring multiple control methods, adjustable color temperatures, and a convenient timer function. This manual provides essential information for safe installation, operation, and maintenance of your new lamp.

2. SAFETY INSTRUCTIONS

- Ensure the power supply is disconnected before assembly, cleaning, or bulb replacement.
- This product is for indoor use only.
- Do not expose the lamp to water or high humidity.
- Use only the specified bulb type (LED, E26 base, 12W) to prevent damage or fire hazards.
- Place the lamp on a stable, level surface to prevent tipping. The weighted shelf design enhances stability.
- Keep the power cord away from heat sources and sharp edges.
- Do not attempt to modify or repair the lamp yourself. Contact qualified personnel for service.

3. PACKAGE CONTENTS

Please check that all components are present and in good condition:

- Floor Lamp Frame (Solid Wood Posts and MDF Shelves)
- Linen Lampshade
- LED Bulb (E26, 12W)
- Remote Control
- Power Cable
- Assembly Hardware (screws, etc.)
- User Manual

4. ASSEMBLY INSTRUCTIONS

Assembly of the OUTON H-LDD006 floor lamp is designed to be straightforward and typically takes about 10 minutes. Follow these steps:

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Assemble the solid wood posts and MDF shelves according to the included diagrams, ensuring the integrated nuts align correctly.
3. Secure all connections with the provided hardware.
4. Attach the linen lampshade to the top section of the lamp.
5. Screw the LED bulb into the E26 socket.
6. Connect the power cable to the lamp and then plug it into a suitable power outlet.



Figure 4.1: High-Quality Shelf Lamp Components

5. OPERATING INSTRUCTIONS

Your OUTON floor lamp offers three convenient control methods: Smart Touch, Remote Control, and App Control.

5.1 Smart Touch Control

The integrated touch panel on the lamp post allows for direct control:

- **Short Press:** Turn the lamp On/Off.
- **Slide:** Adjust brightness continuously from 1% to 100%.
- **Touch Color Temperature Icon:** Cycle through 4 color temperatures (3000K Warm White, 4000K Natural White,

5000K Daylight, 6500K Cool White).

- **Long Press:** Activate the 1-hour timer function or memory function.



Figure 5.1: Smart Touch Control Functions

5.2 Remote Control

The included remote control provides convenient operation from a distance of up to 15 meters:

- **Power Button:** Turn the lamp On/Off.
- **Brightness Buttons (+/-):** Increase or decrease brightness.
- **Color Temperature Buttons (K, +/-):** Adjust color temperature (Warm Tone, Cool Tone, Cycle Modes).
- **1H Button:** Activate the 1-hour timer.
- **Scene Modes:** Buttons for specific lighting modes like Work, Night, Study, Nursery.



Figure 5.2: Remote Control Operation

5.3 App Control (Hxlight)

For advanced control, download the Hxlight app on your mobile device. The app allows control within a 15-meter range (Note: Alexa or Google Assistant are not supported).

1. Download the "Hxlight" app from your device's app store.
2. Ensure Bluetooth is enabled on your mobile device.
3. Open the app and follow the on-screen instructions to add and connect your lamp.
4. Once connected, you can adjust brightness, color temperature, and set timers directly from the app interface.



Figure 5.3: Multiple Control Ways

5.4 Color Temperature Adjustment

The lamp offers 4 distinct color temperature settings:

- **3000K Warm White:** Ideal for relaxing and cozy environments.
- **4000K Natural White:** Suitable for general illumination and comfortable living spaces.
- **5000K Daylight:** Bright and clear, good for reading or tasks.
- **6500K Cool White:** Energetic and focused, suitable for workspaces.

4 Color Temperature Adjustable



Figure 5.4: 4 Color Temperature Adjustable

5.5 Memory Function

The lamp features a memory function that automatically saves the last used brightness and color temperature settings. When the lamp is turned on again, it will resume these previous settings.

5.6 1-Hour Timer Function

Activate the 1-hour timer via the remote control or by long-pressing the touch control. The lamp will automatically turn off after one hour, providing convenience for bedtime or energy saving.




Figure 5.5: Timer & Memory Function

6. MAINTENANCE

6.1 Cleaning

To clean the lamp, ensure it is unplugged from the power outlet. Use a soft, dry cloth to wipe down the wooden frame and shelves. For the linen lampshade, gently dust with a soft brush or vacuum with a low-power setting. Avoid using abrasive cleaners or solvents.

6.2 Bulb Replacement

The lamp uses an E26 base LED bulb with a power consumption of 12 Watts and a lifespan of over 50,000 hours. While the bulb is designed for longevity, if replacement is necessary:

1. Ensure the lamp is unplugged and the bulb has cooled down.
2. Carefully unscrew the old bulb from the E26 socket.
3. Screw in a new E26 LED bulb (max 60 Watts, 12W recommended for optimal performance).
4. Reconnect power and test the lamp.

7. TROUBLESHOOTING

If you encounter issues with your OUTON floor lamp, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Lamp does not turn on.	No power, loose bulb, faulty bulb.	Check power connection. Ensure bulb is screwed in tightly. Replace bulb if necessary.
Remote control not working.	Dead batteries, obstruction, out of range.	Replace remote batteries. Remove any obstructions between remote and lamp. Ensure you are within 15m range.
App control not connecting.	Bluetooth off, app not paired, out of range.	Ensure Bluetooth is enabled on your device. Re-pair the lamp in the Hxlight app. Ensure you are within 15m range.
Brightness or color temperature not adjusting.	Control method issue, lamp malfunction.	Try another control method (remote, touch, app). If problem persists, contact customer support.

8. SPECIFICATIONS

Detailed technical specifications for the OUTON H-LDD006 Floor Lamp:



Figure 8.1: Shelf Floor Lamp Details

Feature	Detail
Model Number	H-LDD006

Feature	Detail
Brand	OUTON
Dimensions (L x W x H)	26 x 26 x 160 cm (10.2 x 10.2 x 62.9 inches)
Weight	5 Kilograms (approx. 11 lbs)
Material	Solid Wood (frame), MDF (shelves), Linen (lampshade)
Bulb Type	LED (included)
Bulb Base	E26 Medium
Power Consumption	12 Watts (Max 60 Watts)
Luminous Flux	1080 Lumens
Color Temperatures (CCT)	3000K, 4000K, 5000K, 6500K (Adjustable)
Dimmability	1% - 100% Continuous Dimming
Control Methods	Smart Touch, Remote Control, Hxlight App
Special Features	Memory Function, 1-Hour Timer
Lifespan	50,000+ Hours

9. WARRANTY & SUPPORT

Specific warranty information for the OUTON H-LDD006 Floor Lamp is not provided in the product details. For warranty claims, technical support, or any questions regarding your product, please contact OUTON customer service through the retailer where you purchased the item or visit the official OUTON brand store online. Please retain your proof of purchase for any warranty-related inquiries. For further assistance, you may visit the OUTON brand store:[OUTON Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question