

[Manuals.plus](#) /

› [Abestorm](#) /

› Abestorm DecDust 1080IG Air Filtration System User Manual

Abestorm DecDust 1080IG

Abestorm DecDust 1080IG Air Filtration System User Manual

Model: DecDust 1080IG

1. INTRODUCTION

The Abestorm DecDust 1080IG is an advanced air filtration system designed to improve air quality in various environments such as workshops, garages, and during home renovations. It features a 270-degree air intake, a powerful vortex fan, and a built-in ionizer to efficiently capture dust and fine particles. This manual provides essential information for the safe and effective use of your air filtration system.

2. SAFETY INFORMATION

Please read all safety instructions carefully before operating the device.

- Ensure the power supply matches the unit's requirements.
- Do not operate the unit with a damaged power cord or plug.
- Keep hands and loose clothing away from moving parts.
- Do not use in wet or damp conditions.
- Unplug the unit before performing any maintenance or cleaning.
- This product is not suitable for use in California due to specific regulatory requirements.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- Abestorm DecDust 1080IG Air Filtration System
- MERV-11 Filters (3 included)
- Remote Control (requires 2 AA batteries, not included)
- Mounting Hardware (chains, hooks, screws, anchors)



Image: Contents of the Abestorm DecDust 1080IG package, showing the main unit, three MERV-11 filters, a remote control, and various mounting accessories like chains, hooks, and screws.

4. SETUP AND INSTALLATION

The DecDust 1080IG offers multiple installation options to suit your workspace:

- **Suspended by Chain:** Ideal for overhead placement to maximize air circulation. Use the provided chains and hooks to hang the unit securely from a ceiling or sturdy support structure.
- **Flatwise Placement:** Place the unit directly on a flat surface such as a workbench or table. Ensure stable positioning.
- **Mounted with Screws:** Secure the unit to a wall using the provided screws and anchors. Ensure the wall can support the unit's weight.
- **Vertical Placement:** Position the unit upright on the floor or a stable surface.



Image: Visual representation of the four different ways to install the air filtration system: hanging from chains, resting flat on a surface, mounted on a wall, and standing vertically.

After installation, plug the unit into a standard electrical outlet. The unit is designed for portability with sturdy handles on all four corners, making it easy to move between locations.

5. OPERATING INSTRUCTIONS

The DecDust 1080IG can be operated via its intuitive control panel or the included remote control.

5.1 Control Panel and Remote

The control panel features buttons for power, speed adjustment, and ionizer activation. The remote control allows for convenient operation from up to 26 feet away.



Image: The unit's control panel with an LED display and buttons for On/Off, Power, and Speed. An infrared remote control is also shown, indicating a range of up to 26 feet.

- **Power Button:** Press to turn the unit On or Off.
- **Speed Button:** Toggle between two fan speeds: Low (780 CFM) and High (1080 CFM).
- **Ionizer Button:** Activate or deactivate the built-in ionizer.
- **Timer:** Set the operating time from 1 to 9 hours using the remote control.

5.2 Ionization Technology

The built-in ionizer charges dust particles, improving their capture efficiency by the filters. This process helps to minimize filter clogging and extends filter lifespan. It also contributes to energy savings and reduced noise levels.



Image: A visual explanation of the built-in ionizer, depicting how it charges fine dust particles for enhanced capture and improved air quality.

5.3 Airflow and Filtration

The unit features a 270-degree air intake and a powerful vortex fan, providing a large airflow of up to 1080 CFM. It is equipped with three MERV-11 filters that effectively capture fine particles, wood dust, and other airborne contaminants.




Image: The air filtration system operating in a workshop, demonstrating its 270-degree air intake and the movement of air through the filters.

Your browser does not support the video tag.

Video: An official product video demonstrating the features and operation of the Abestorm DecDust 1080IG Shop Dust Collector with its built-in ionizer.

The unit also offers an outlet ducting option for directed emission control, helping to prevent secondary pollution. This is suitable for ducts under 10 inches. Please measure your outlet size before purchasing ducts.




Image: The air filtration system with an attached outlet duct, illustrating how filtered air can be directed to prevent secondary contamination in the workspace.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your air filtration system.

- **Filter Replacement:** The unit is designed for easy filter removal and replacement. Check filters regularly and replace them when they appear dirty or when airflow is noticeably reduced. The MERV-11 filters are crucial for effective particle capture.
- **Cleaning:** Wipe the exterior of the unit with a dry cloth. Do not use abrasive cleaners or allow water to enter the internal components.
- **Dust Bag:** If using dust bags (not explicitly mentioned as included but implied by "dust bags that can be quickly removed and replaced"), ensure they are emptied or replaced regularly.

7. TROUBLESHOOTING

If you encounter issues with your Abestorm DecDust 1080IG, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Unit does not turn on.	No power, loose connection, remote batteries dead.	Check power cord connection. Ensure outlet is functional. Replace remote control batteries.
Reduced airflow.	Clogged filters.	Inspect and replace MERV-11 filters.
Unusual noise during operation.	Obstruction in fan, loose components.	Turn off and unplug the unit. Carefully check for any obstructions. If noise persists, contact customer support.
Ionizer not working.	Ionizer feature deactivated, malfunction.	Ensure the ionizer is activated via the control panel or remote. If still not working, contact customer support.

8. SPECIFICATIONS

Feature	Detail
Model Number	DecDust 1080IG
Product Dimensions	19.4 x 9.6 x 19.4 inches
Item Weight	30.25 Pounds (Unit weight: 22 lbs)
Airflow (CFM)	Up to 1080 CFM
Filter Type	MERV-11
Particle Retention Size	0.3 Micron
Control Method	Remote Control, On-unit Panel
Power Source	AC
Wattage	62 watts
Special Features	270-degree air filtration system, Built-in ionizer
Floor Area Coverage	Up to 1100 Square Feet
Batteries for Remote	2 AA batteries (not included)
Certification	UL Certified





Image: The physical dimensions of the unit, showing its height, width, depth, and weight.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact Abestorm customer service. Refer to the contact details provided on the product packaging or the official Abestorm website.

Note: This product is not intended for use in California due to state-specific regulatory requirements. Orders from California cannot be shipped.