Kidsneed SM935A-2

Kidsneed Baby Monitor with 2 Cameras User Manual

Model: SM935A-2

INTRODUCTION

Thank you for choosing the Kidsneed Baby Monitor with 2 Cameras. This manual provides detailed instructions for setting up, operating, and maintaining your baby monitor system. Please read this manual thoroughly before use to ensure proper functionality and safety. This system is designed to help you monitor your baby with high-resolution video, two-way audio, and various smart features.



Image: The Kidsneed Baby Monitor system, featuring the parent unit (monitor) and two baby cameras.

WHAT'S IN THE BOX

Please check the package contents to ensure all items are present:

- 1 x Parent Unit (Monitor)
- 2 x Baby Camera Units
- 3 x Power Adapters (for Parent Unit and Camera Units)
- 1 x User Manual

SETUP

1. Charging the Parent Unit

Before first use, fully charge the parent unit for approximately 8 hours. Connect the small end of the power adapter to the parent unit's charging port and the other end to a power outlet.



Image: A hand plugging the power adapter into the parent unit, illustrating the charging process.

2. Positioning the Baby Camera Units

Place the baby camera units in a location that provides a clear view of your baby. Ensure the camera is at least 3 feet (1 meter) away from the baby's crib or bed to prevent entanglement hazards. Connect each camera unit to a power outlet using its dedicated power adapter.

3. Pairing Cameras (if necessary)

The cameras are typically pre-paired with the parent unit. If a camera loses connection or you are adding a new camera, refer to the 'Add Camera' option in the parent unit's menu. Follow the on-screen prompts to complete the pairing process.

OPERATING THE MONITOR

Parent Unit Overview




Image: An illustration highlighting key features of the Kidsneed Baby Monitor system, including remote pan/tilt/zoom, infrared night vision, two-way communication, room temperature display, lullabies, 960ft range, and 1200mAh battery.

1. Power On/Off

Press and hold the Power button on the parent unit to turn it on or off. The camera units will power on automatically when connected to power.

2. Pan, Tilt, and Zoom (PTZ)

Use the directional buttons on the parent unit to remotely adjust the camera's viewing angle. Press the 'Zoom' button to zoom in (2x) or out on the image.



Image: The parent unit displaying a baby, alongside a camera unit with arrows indicating its 355-degree pan and 120-degree tilt capabilities, demonstrating comprehensive room coverage.



Image: A visual comparison on the parent unit screen, showing a baby at 1x zoom and then at 2x zoom, illustrating the digital zoom function.

3. Night Vision

The camera automatically switches to infrared night vision mode in low-light conditions, providing a clear greyscale image of your baby.




Image: The parent unit screen showing a baby sleeping in a crib, depicted in clear greyscale, demonstrating the automatic night vision feature in a dark room.

4. Two-Way Talk

Press and hold the microphone button on the parent unit to speak to your baby through the camera's speaker. Release the button to hear your baby.

5. Lullabies

Access the menu to select and play from 4 pre-programmed lullabies to soothe your baby. You can also stop the lullabies from the menu.



Image: A baby camera unit with musical notes emanating from it, indicating the lullaby function, and a thermometer icon, representing the temperature sensor.

6. Temperature Monitoring

The camera unit has a built-in temperature sensor that displays the room temperature on the parent unit. Alerts can be set for temperature deviations.

7. VOX Mode (Voice Operated Exchange)

In VOX mode, the parent unit's screen will turn off to save battery, but it will automatically activate and display video when sound is detected from the baby's room. You can adjust the VOX sensitivity level in the settings.

8. Battery Life

The parent unit features a 1200mAh battery. Battery life varies depending on usage:

- Audio Only Mode: Up to 12 hoursLive Screen Mode: Up to 4 hours
- keep a Closed Eye from Day to Night **Kidsneed** Audio Only 12 hrs Live Screen 4 hrs

Image: The parent unit displaying battery life information, indicating 12 hours in audio-only mode and 4 hours with the live screen on.

9. Multi-Camera Support

The system supports up to four cameras. You can switch between cameras manually or set it to scan mode, which cycles through connected cameras automatically.



Image: A graphic illustrating the capability to connect and monitor up to four cameras simultaneously, showing different scenarios like monitoring a baby, an elderly person, or a pet.

MAINTENANCE

To ensure optimal performance and longevity of your Kidsneed Baby Monitor, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the parent unit and camera units. Do not use abrasive cleaners or solvents.
- **Storage:** If storing the unit for an extended period, ensure the parent unit's battery is fully charged, then power it off. Store in a cool, dry place.
- **Battery Care:** Avoid fully discharging the parent unit's battery frequently. Charge it regularly to maintain battery health.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No image/sound on parent unit	Parent unit or camera is off; Out of range; Camera not paired.	Ensure both units are powered on. Move units closer. Re-pair camera if necessary.
Poor image quality	Low light (night vision active); Lens dirty; Interference.	This is normal for night vision. Clean camera lens. Move away from other electronic devices.
Static or interference	Too far from camera; Obstructions; Other 2.4GHz devices.	Move parent unit closer to camera. Reduce obstructions. Turn off other 2.4GHz devices temporarily.
Parent unit battery drains quickly	Constant screen on; Old battery.	Use VOX mode. Ensure full charge before use. Battery may need replacement over time.

SPECIFICATIONS

• Model: SM935A-2

• Display Size: 3.5 inches LCD

• Video Resolution: 480p

• Connectivity: 2.4GHz FHSS (Wireless, No Wi-Fi/App required)

• Range: Up to 960 feet (line of sight)

• Camera Features: Pan (355°), Tilt (120°), 2x Zoom, Automatic Night Vision, Two-Way Talk, Temperature Sensor

• Parent Unit Battery: 1200mAh Lithium Ion (included)

• Power Source: Corded Electric

• Included Components: 1 Monitor Part, 2 Camera Parts

• Indoor/Outdoor Usage: Indoor

WARRANTY AND SUPPORT

Kidsneed products are designed for reliability and performance. For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Kidsneed website. Keep your purchase receipt as proof of purchase for warranty claims.

© 2025 Kidsneed. All rights reserved.