

[Manuals.plus](#) /

› [OffiGo](#) /

› OffiGo Electric Standing Desk 180 x 70 cm White User Manual

OffiGo 850066549704

OffiGo Electric Standing Desk 180 x 70 cm White User Manual

Model: 850066549704

INTRODUCTION

Welcome to your new OffiGo Electric Standing Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your desk. Designed for ergonomic comfort, this desk allows you to easily switch between sitting and standing positions, promoting a healthier work environment. Please read these instructions carefully before assembly and use to ensure optimal performance and safety.



Image: A woman standing at the OffiGo Electric Standing Desk, demonstrating its use in a standing position.

SETUP AND ASSEMBLY

The OffiGo Electric Standing Desk is designed for straightforward assembly. All necessary installation tools are included, and each accessory is clearly labeled to guide you through the process. The desktop consists of three panels, optimized for stability and a seamless work surface.

Assembly Steps:

1. Unpack all components and verify against the parts list provided in the packaging.
2. Assemble the desk frame according to the detailed diagrams. Ensure all screws are tightened securely.

3. Attach the three desktop panels. The 3-panel design enhances stability and provides a more complete surface compared to traditional multi-panel desks.
4. Install the control panel and connect all electrical cables as indicated.
5. Attach the included hooks and route cables through the integrated cable hole for a tidy workspace.



Crochets



Pieds Silencieux



Trou pour Câble

Image: Detailed view of desk features: side hooks for accessories, silent feet for stability, and a cable management hole for organization.

OPERATING INSTRUCTIONS

Your OffiGo Electric Standing Desk features smooth, quiet electric height adjustment and convenient memory presets.

Height Adjustment:

- The desk can be adjusted from a minimum height of 72 cm to a maximum height of 118 cm.
- Use the **Up (▲)** and **Down (▼)** buttons on the control panel to manually adjust the desk height. The current height will be displayed on the LED screen.
- The motor operates quietly, with a sound level between 45 and 55 decibels, ensuring minimal disturbance.

Memory Presets:

The desk includes two memory functions to save your preferred sitting and standing heights.

1. **To Save a Height:** Adjust the desk to your desired height using the Up/Down buttons. Press and hold one of the memory buttons (**1** or **2**) until you hear a beep or see the LED display flash, indicating the height has been saved.
2. **To Recall a Height:** Simply press the corresponding memory button (**1** or **2**). The desk will automatically move to the saved height.



TOUCHEZ SIMPLEMENT POUR RÉGLER LA HAUTEUR

2 Réglages de Mémoire

Image: The desk's control panel, showing buttons for height adjustment, an LED display for current height, and two programmable memory settings.



HAUTEUR RÉGLABLE

Hauteur applicable

Maximum 190cm

Minimum 150cm

72cm à 118cm

Personnalisez la hauteur souhaitée

Image: Visual representation of the desk's adjustable height, ranging from 72 cm (sitting) to 118 cm (standing).

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your OffiGo Electric Standing Desk.

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. For stubborn marks, use a mild, non-abrasive cleaner. Avoid harsh chemicals that may damage the finish.
- **Regular Checks:** Periodically check all screws and bolts to ensure they are tight. Loose connections can affect stability and motor function.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 80 kg. Overloading can strain the motor and frame.

- **Cable Management:** Ensure cables are neatly routed and not pinched or tangled, especially during height adjustments.

TROUBLESHOOTING

If you encounter any issues with your OffiGo Electric Standing Desk, please refer to the following common troubleshooting steps:

- **Desk Not Moving:**
 - Check if the power cord is securely plugged into both the desk and a working wall outlet.
 - Ensure there are no obstructions preventing the desk from moving up or down.
 - Try resetting the desk by unplugging it for 30 seconds, then plugging it back in.
- **Uneven Movement:**
 - Verify that the weight on the desk is evenly distributed.
 - Check for any loose connections in the frame or legs.
- **Motor Noise:**
 - A slight motor hum is normal during operation (45-55 dB). If the noise is excessive or unusual, ensure the desk is not overloaded and there are no loose parts.

If these steps do not resolve the issue, please contact OffiGo customer support for further assistance.

SPECIFICATIONS

Detailed specifications for your OffiGo Electric Standing Desk:

Feature	Detail
Brand	OffiGo
Model Number	850066549704
Color	White
Product Dimensions (L x W x H)	180 x 70 x 72 cm (minimum height)
Adjustable Height Range	72 cm to 118 cm
Material	FSC Certified Wood (desktop), High-strength Steel (frame)
Item Weight	22 Kilograms
Weight Capacity	80 kg
Special Features	Ergonomic, Height Adjustable, Electric, 2 Memory Presets, Cable Management, Accessory Hooks
Motor Noise Level	45-55 dB



DIMENSION DU PRODUIT

■ Pour s'asseoir et se tenir debout



offigo

Image: Product dimensions and adjustable height range for the Offigo Electric Standing Desk.



STABLE ET DURABLE

Capacité de charge 80 kg



Image: Illustration highlighting the desk's robust structure and its ability to support up to 80 kg.

WARRANTY AND SUPPORT

OffiGo is committed to providing high-quality products. For warranty information, technical support, or any questions not covered in this manual, please contact OffiGo customer service. Keep your purchase receipt as proof of purchase for any warranty claims. Please refer to the contact information provided with your product packaging or visit the official OffiGo website for support details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DG2TJY51>

More documents and user manuals: **<https://manuals.plus/>**