CafeGrace 9118B

CafeGrace 5-in-1 Automatic Milk Frother and Steamer (Model 9118B) User Manual

Brand: CafeGrace | **Model:** 9118B

1. Introduction

Thank you for choosing the CafeGrace 5-in-1 Automatic Milk Frother and Steamer. This versatile appliance is designed to enhance your beverage experience by creating various milk preparations, including airy froth, dense froth, hot milk, chocolate milk, and cold froth. Its intuitive design and efficient operation make it a valuable addition to any kitchen.

2. Important Safety Instructions

- Read all instructions before use.
- Do not immerse the main unit (base) in water or other liquids. Only the stainless steel pitcher is washable.
- Ensure the power cord is not damaged and is plugged into a grounded outlet.
- Keep the appliance away from children.
- Do not operate the appliance if it has been damaged in any way. Contact customer support.
- The appliance uses induction heating; avoid touching the heating plate during operation.
- Do not overfill the pitcher beyond the maximum fill lines to prevent overflow.
- Always use the provided lid during operation to prevent splashes and maintain temperature.
- Unplug the appliance when not in use and before cleaning.

3. Package Contents

Verify that all items are present in your package:

- CafeGrace 5-in-1 Automatic Milk Frother Main Unit (Base)
- Stainless Steel Milk Pitcher with Handle
- Transparent Lid
- Magnetic Whisk
- User Manual

4. Product Overview

Familiarize yourself with the components of your CafeGrace Milk Frother.



Figure 1: The CafeGrace 5-in-1 Automatic Milk Frother and Steamer, featuring a sleek black base and a stainless steel pitcher with a handle.

Key Features:

- **Main Unit (Base):** Houses the control panel and induction heating element. Features a high-definition LCD touch display.
- **Stainless Steel Pitcher:** Removable, 21 oz (600 ml) capacity, with clear MIN/MAX markings for different milk preparations. Dishwasher safe.
- **Magnetic Whisk:** Detachable whisk for efficient frothing and stirring.
- **Lid:** Transparent lid with a secure fit to monitor the frothing process.
- **5-in-1 Functionality:** Offers options for airy froth, dense froth, hot milk, chocolate milk, and cold froth.
- **Induction Heating:** Ensures rapid, even heating and prevents milk from burning.



Figure 2: Visual representation of the five functions: Airy Froth Milk, Dense Froth Milk, Hot Milk, Chocolate Milk, and Cold Froth Milk.



Figure 3: The extra-large LED screen display showing temperature and selected function icons.



Figure 4: Detailed view of the product's design, highlighting the 360° base, comfort handle, and backside cooling vents for optimal performance and safety.

5. Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Wash the stainless steel pitcher, lid, and whisk with warm soapy water, then rinse and dry thoroughly. The pitcher and whisk are dishwasher safe.
3. **Placement:** Place the main unit (base) on a stable, dry, and flat surface.
4. **Assemble:** Ensure the magnetic whisk is securely placed at the bottom of the pitcher. Place the pitcher onto the main unit.
5. **Power:** Plug the power cord into a standard electrical outlet. The display will illuminate.

6. Operating Instructions

The CafeGrace Milk Frother offers 5 distinct functions for various milk preparations. Follow these steps for optimal results:

1. **Add Milk:** Pour the desired amount of milk into the stainless steel pitcher. Observe the MIN/MAX markings inside the pitcher. For frothing, do not exceed the lower MAX line (300ml/10.6oz). For hot milk or chocolate milk, do not exceed the upper MAX line

(600ml/21.1oz).

2. **Secure Lid:** Place the transparent lid firmly on the pitcher.
3. **Select Function:** Press the power button on the front display to cycle through the 5 available functions. Each press will highlight a different icon on the LED screen:
    - **Airy Froth Milk:** For light, fluffy foam.
    - **Dense Froth Milk:** For rich, creamy foam.
    - **Hot Milk:** Heats milk without frothing.
    - **Chocolate Milk:** Heats and stirs milk with added chocolate.
    - **Cold Froth Milk:** Creates cold foam without heating.
4. **Start Operation:** Once the desired function is selected, the appliance will automatically begin operation. The LED display will show the live temperature of the milk and a circular progress indicator.
5. **Automatic Shut-off:** The frother will automatically stop once the selected program is complete or the optimal temperature is reached.
6. **Serve:** Carefully remove the pitcher from the base and pour your prepared milk.



Figure 5: Diagram illustrating the circulation heating process, which ensures rapid and even heating of milk to prevent burning.



Figure 6: Internal view of the pitcher showing MIN and MAX fill lines for different milk volumes and preparations.

7. Maintenance and Cleaning

Proper cleaning ensures the longevity and hygiene of your milk frother.

- **Before Cleaning:** Always unplug the appliance from the power outlet and allow it to cool completely.
- **Stainless Steel Pitcher:** The removable stainless steel pitcher is dishwasher safe. Alternatively, it can be hand-washed with warm soapy water and a non-abrasive sponge. Rinse thoroughly and dry.
- **Magnetic Whisk:** The magnetic whisk can be easily removed from the bottom of the pitcher for separate cleaning. Wash with warm soapy water, rinse, and dry.
- **Lid:** Wash the transparent lid with warm soapy water, rinse, and dry.
- **Main Unit (Base):** Wipe the exterior of the main unit with a soft, damp cloth. Do not use abrasive cleaners or immerse the base in water.



Figure 7: The removable stainless steel pitcher and whisk are designed for easy cleaning and are dishwasher safe.

8. Troubleshooting

If you encounter any issues, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in or power issue.	Ensure the power cord is securely plugged into a working outlet.
Milk not frothing or heating.	Incorrect milk level or whisk not properly placed.	Check that milk is between MIN and MAX lines. Ensure the magnetic whisk is correctly seated at the bottom of the pitcher.
Milk overflows during operation.	Pitcher overfilled.	Do not fill milk above the indicated MAX lines for the selected function.
Burning smell or milk sticking to bottom.	Rare, but could indicate residue or malfunction.	Clean the pitcher thoroughly after each use. If the problem persists, discontinue use and contact customer support.

Problem	Possible Cause	Solution
Display shows an error code.	Internal error.	Unplug the unit, wait 5 minutes, then plug it back in. If the error persists, contact customer support.

9. Specifications

Feature	Detail
Brand	CafeGrace
Model Name	Automatic Milk Frother
Item Model Number	9118B
Color	Black
Material	Stainless Steel
Capacity	21 oz (600 ml)
Wattage	550 watts
Number of Settings	5
Special Features	Automatic milk frother with 5 functions, Compact Design, Easy to Clean, Split stainless steel cup body, Temperature Display
Product Care Instructions	Dishwasher Safe (Pitcher and Whisk)
Item Weight	3.78 pounds (1.72 Kilograms)
UPC	744585160840

10. Warranty and Support

For detailed warranty information and customer support, please refer to the warranty card included in your product packaging or contact CafeGrace customer service directly. Keep your purchase receipt for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How can I order a replacement magnetic whisk for the CafeGrace 9118B 5-in-1 Automatic Milk Frother?

To order a replacement magnetic whisk for your CafeGrace 9118B, you should contact the manufacturer's customer support directly. The user manual provides the following guidance for parts and support:Check your packaging: Refer to the...

Read full answer