Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

De'Longhi ECAM32070SB

De'Longhi Magnifica Plus Fully Automatic Espresso Machine

Model: ECAM32070SB | Brand: De'Longhi

Product Overview

The De'Longhi Magnifica Plus is a fully automatic espresso machine designed for ease of use and versatility. It allows users to craft a wide variety of coffee and milk-based beverages with minimal effort. Key features include a touchscreen display, integrated grinder, and an automatic milk frothing system.

- **18 One-Touch & Customizable Recipes:** Offers a diverse selection of beverages including Espresso, Latte Macchiato, Cappuccino, Americano, and Iced Coffees.
- **Built-in Conical Burr Grinder:** Features 13 adjustable settings for optimal grind consistency.
- **LatteCrema Hot System:** Automatically froths milk and milk alternatives with 3 customizable frothing settings (light, creamy, dense).
- **3.5” TFT Full-Touch & Color Display:** Provides intuitive navigation and customization options.
- **4 User Profiles:** Allows personalization and saving of drink recipes for multiple users.
- **Auto-Clean Function:** Simplifies maintenance with automatic cleaning cycles and detachable, dishwasher-safe parts.

Setup

Before first use, ensure all packaging materials are removed. Rinse the water tank, milk carafe, and brew unit with fresh water. Perform an initial rinse cycle as instructed by the machine's display to prime the system.

Initial Preparation

1. **Unpack:** Remove the machine and all accessories from the packaging.
2. **Position:** Place the machine on a stable, flat surface away from heat sources.
3. **Water Tank:** Fill the removable water tank with fresh, cold water. The included Total Hardness Test can be used to determine water hardness for optimal machine settings.
4. **Bean Hopper:** Open the bean hopper lid and fill with fresh coffee beans.
5. **Power On:** Plug the machine into a grounded power outlet and press the power button. Follow on-screen instructions for initial setup.

Operating Instructions

Brewing Coffee

The Magnifica Plus features a user-friendly touchscreen display for selecting and customizing beverages.



The 3.5-inch full-touch color display provides an intuitive interface for selecting and customizing your desired coffee beverages.

1. **Select Beverage:** On the touchscreen, swipe through the available 18 recipes and tap your desired drink (e.g., Espresso, Coffee, Latte).
2. **Customize (Optional):** For customizable recipes, adjust parameters such as size, intensity, and milk froth level using the on-screen sliders. You can save these preferences to one of the 4 user profiles.
3. **Brew:** Place your cup under the coffee spouts and press the 'Brew' button on the display. The machine will automatically grind the beans and dispense the beverage.

Automatic Milk Frothing (LatteCrema Hot System)

The integrated LatteCrema Hot System allows for automatic frothing of milk for cappuccinos, lattes, and other milk-based drinks.



The LatteCrema Hot System ensures perfect milk texturing with automatic frothing, compatible with various milk types and featuring an auto-clean function.

1. **Attach Milk Carafe:** Fill the milk carafe with fresh milk (dairy or alternative) and attach it to the machine's milk spout.
2. **Select Milk-Based Drink:** Choose a milk-based recipe from the display (e.g., Latte, Cappuccino).
3. **Adjust Froth (Optional):** Use the dial on the milk carafe to select your desired froth level (light, creamy, or dense).
4. **Brew:** Place your cup under the milk spout and press 'Brew'. The machine will froth and dispense the milk, followed by the espresso.

Built-in Grinder

The conical burr grinder ensures fresh coffee grounds for every cup, with adjustable settings for different bean types and desired strength.



The integrated conical burr grinder offers 13 grind settings, ensuring optimal freshness and flavor from whole beans.

To adjust the grind setting, turn the dial inside the bean hopper. It is recommended to adjust the grind setting only when the grinder is operating.

Official Product Video

Watch an official introduction to the new De'Longhi Magnifica Plus, highlighting its key features and ease of use.

Maintenance

Regular cleaning and maintenance are crucial for the longevity and optimal performance of your espresso machine.

Daily Cleaning

1. **Drip Tray & Grounds Container:** Empty and rinse the drip tray and coffee grounds container daily. These parts are detachable and dishwasher-safe.
2. **Milk Carafe Auto-Clean:** After preparing milk, turn the dial on the milk carafe to the 'Clean' position. The machine will automatically flush hot water through the milk spout to clean it. The carafe itself is detachable and

dishwasher-safe for deeper cleaning.



The easy carafe auto-rinse function helps maintain hygiene after each milk preparation.

Periodic Maintenance

- **Brew Unit:** The brew unit is removable for manual rinsing. Refer to the full manual for detailed instructions on brew unit removal and cleaning.
- **Descaling:** The machine will prompt you when descaling is required. Use De'Longhi descaling solution and follow the on-screen instructions.

Troubleshooting

This section provides general guidance for common issues. For detailed troubleshooting steps and error codes, please refer to the comprehensive user manual provided with your machine.

- **No Coffee Dispensed:** Check water tank level, ensure coffee beans are present in the hopper, and verify the brew unit is correctly inserted.
- **Milk Not Frothing:** Ensure the milk carafe is clean and properly assembled. Use fresh, cold milk. Check the

milk frothing dial setting.

- **Machine Not Turning On:** Verify the power cord is securely plugged into both the machine and the power outlet.
- **Error Messages:** The display will show specific error codes. Consult your user manual for the meaning of each code and the recommended solution.

Specifications

Feature	Detail
Brand	De'Longhi
Model Name	Magnifica Plus
Item Model Number	ECAM32070SB
Color	Silver
Product Dimensions	17.5"D x 9.5"W x 14"H
Item Weight	21.2 pounds
Voltage	120 Volts
Coffee Maker Type	Espresso Machine
Filter Type	Reusable
Human Interface Input	Touchscreen
Country of Origin	Romania

Warranty and Support

For warranty information, product registration, and customer support, please refer to the documentation included with your De'Longhi Magnifica Plus espresso machine or visit the official De'Longhi website. Extended protection plans may also be available for purchase.

© 2025 De'Longhi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DG4BCHK8

More documents and user manuals: **https://manuals.plus/**