Shahoo SH-OCRC23-PL

Shahoo Gaming Chair SH-OCRC23-PL User Manual

Model: SH-OCRC23-PL

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your Shahoo Gaming Chair with Footrest and Massage Lumbar Support. Please read this manual thoroughly before use to ensure proper function and longevity of your product.





Image 1: Shahoo Gaming Chair, Purple.

Safety Information

- Do not exceed the maximum weight recommendation of **300 pounds**.
- Avoid using liquids near the chair to prevent damage.
- Ensure all screws and bolts are securely tightened before and during use.
- Keep hands and fingers clear of moving parts during adjustment.

Package Contents

Verify that all components are present before beginning assembly:

- Shahoo Gaming Chair components
- Assembly Tool Kit
- Installation and Usage Manual

Setup and Assembly

Assembly is required for this product. Please follow the included installation manual for step-by-step instructions. It is recommended to assemble the chair on a soft, clean surface to prevent damage.



Image 2: Chair dimensions and 300 lbs weight capacity.

Key Assembly Steps:

1. Unpack all components and verify against the parts list in the separate assembly manual.
2. Attach the chair base and wheels.
3. Secure the seat to the gas lift.
4. Install the backrest to the seat.
5. Attach the armrests.
6. Install the retractable footrest.
7. Attach the head pillow and lumbar support cushion.

The assembly process typically takes approximately 30-40 minutes for one person.

Operating Instructions

Your Shahoo Gaming Chair offers multiple adjustable features for personalized comfort.

Adjustable Features:

- **Height Adjustment:** Use the lever located under the seat on the right side to adjust the chair height between 48.5 inches and 52 inches. Pull the lever up to raise or lower the seat while applying or releasing weight.
- **Recline Function:** The backrest can be adjusted between 90° (upright for gaming/working) and 160° (reclined for resting). Use the recline lever on the right side of the chair to unlock, adjust, and lock the desired angle.
- **360° Swivel:** The chair features a full 360° swivel for easy movement and access to your surroundings.
- **Retractable Footrest:** Pull out the footrest from under the seat for leg support when reclining. Push it back in when not in use.
- **Massage Lumbar Support:** The lumbar support cushion includes a massage function. Connect the USB cable from the cushion to a power source (e.g., computer USB port, power bank) to activate the massage feature.
- **Detachable Head Pillow and Lumbar Support:** Both the head pillow and lumbar support cushion are detachable, allowing you to customize your seating experience.
- **Linkage Armrests:** The armrests are designed to move with the recline of the chair, providing continuous support.



Image 3: Visual representation of adjustable back angle, 360° rotation, and height adjustment.



Image 4: Close-up of the lumbar massage cushion.

Maintenance

To maintain the condition and extend the lifespan of your Shahoo Gaming Chair:

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the leather finish.
- **Inspection:** Periodically check all bolts and screws to ensure they are tight. Re-tighten as necessary.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the material to fade or crack.
- **Weight Limit:** Adhere strictly to the 300-pound maximum weight recommendation.

Troubleshooting

If you encounter any issues with your gaming chair, refer to the following common solutions:

- **Chair is Wobbly:** Ensure all assembly bolts are securely tightened. Check that the base is properly attached to the gas lift.
- **Height Adjustment Not Working:** Verify that the gas lift lever is fully engaged. If the issue persists, the gas lift cylinder may need replacement.
- **Recline Function Not Engaging:** Check that the recline lever is fully released and not obstructed. Ensure the backrest is properly seated in its mechanism.
- **Footrest Not Extending/Retracting Smoothly:** Inspect the footrest rails for any obstructions or damage. Apply a silicone-based lubricant if necessary.
- **Massage Function Not Working:** Confirm the USB cable is securely connected to both the lumbar cushion and a functional power source. Try a different USB port or power source.

For issues not covered here, please contact Shahoo customer support.

Specifications

Feature	Specification
Brand	Shahoo
Model Number	SH-OCRC23-PL
Color	Purple
Product Dimensions (D x W x H)	18.5" x 20.9" x 52.4"
Overall Size (W x L x H)	19.5 inches x 19.5 inches x 52 inches
Maximum Weight Recommendation	300 Pounds
Material	PU Leather, Foam
Back Style	High Back
Special Features	Adjustable Height, Recline, Swivel, Footrest, Massage Lumbar Support
Assembly Required	Yes
Item Weight	41 pounds

Warranty and Support

For information regarding product warranty, please refer to the documentation provided at the time of purchase or contact Shahoo customer support directly. If you require assistance with assembly, operation, or troubleshooting, please reach out to the manufacturer's support channels.
Visit the Shahoo Store on Amazon for more products and support information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question