Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Casaottima SPCB01171401001USCP

Casaottima 32-Inch Small Computer Desk with 4 Fabric Drawers Instruction Manual

Model: SPCB01171401001USCP

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your Casaottima 32-Inch Small Computer Desk. Please read all instructions carefully before assembly and use to ensure proper function and safety. Keep this manual for future reference.



An overview of the Casaottima 32-inch computer desk, showcasing its compact design, white tabletop, metal frame, four fabric drawers, and side storage bag.

Safety Information

- Always assemble the desk according to the provided instructions.
- Do not place heavy items on the desk that exceed its weight capacity to avoid tipping.
- Ensure the desk is properly anchored to the floor if necessary to prevent it from moving or tipping over, especially in households with children or pets.
- Keep small parts away from children during assembly.
- Periodically check all connections and fasteners to ensure they remain tight.

Package Contents

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Desk tabletop (MDF board)
- Metal frame components (legs, support bars)
- 4 Fabric drawers
- Side hook
- Cloth storage bag
- Adjustable footpads
- Assembly hardware (screws, bolts, Allen wrench)


Setup and Assembly

Assembly is required. Please follow these steps carefully. It is recommended to assemble the desk on a soft, clean surface to prevent scratches.

Step 1: Assemble the Desk Frame

1. Attach the metal legs to the tabletop using the provided screws and Allen wrench. Ensure all connections are secure but do not overtighten initially.
2. Connect the support bars between the legs to enhance stability.
3. Once the frame is fully assembled, tighten all screws firmly.

Step 2: Assemble the Fabric Drawers



Visual instructions demonstrating the simple three-step process for assembling the fabric drawers before inserting them into the desk frame.

1. Unfold each fabric drawer.
2. Insert the bottom panel into the drawer to create a stable base.
3. Attach the handle to the front of each drawer.

Step 3: Install Drawers, Hook, and Bag

1. Slide the assembled fabric drawers into their designated slots on the desk frame.
2. Attach the side hook to either the left or right side of the desk, according to your preference.
3. Hang the cloth storage bag on the desired side of the desk. The bag and hook are reversible.



The modular design allows the fabric drawer unit and side bag to be installed on either the left or right side of the desk to suit different room layouts and user preferences.

Step 4: Adjust Footpads

1. Adjust the non-slip footpads at the bottom of each leg to ensure the desk is stable and level on uneven ground. This also protects your floor from scratches.

Operating Instructions

Using the Fabric Drawers

The four fabric drawers are designed for organized storage. Simply pull the handles to open and push to close. They are suitable for storing various items such as:


- Books and files
- Office supplies
- Small electronic devices
- Personal items



The four fabric drawers offer organized storage for books, files, laptops, and other office supplies, keeping the desktop clear.

Utilizing the Side Hook and Cloth Bag

The side hook provides a convenient spot for hanging headphones, bags, or other accessories, keeping them within easy reach and off the desktop. The cloth storage bag offers additional space for documents, magazines, or other small items, helping to maintain an orderly workspace.



The desk features a convenient side hook for headphones or bags, a removable fabric storage bag for additional items, and adjustable footpads for stability on uneven surfaces.

Maintenance

Cleaning

- For the tabletop and metal frame, wipe with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- The fabric drawers can be spot cleaned with a mild detergent and water. Allow them to air dry completely before reinserting.

General Care

- Avoid exposing the desk to direct sunlight or extreme temperature changes to prevent warping or discoloration.
- Do not place hot items directly on the tabletop; use coasters or protective pads.
- Regularly check and tighten all screws and bolts to maintain stability.

Troubleshooting

Desk is Unstable/Wobbly

- Ensure all assembly screws and bolts are securely tightened.
- Adjust the non-slip footpads on each leg to compensate for uneven flooring. Turn them clockwise or counter-clockwise until the desk is stable.

Drawers Do Not Slide Smoothly

- Check that the fabric drawers are correctly assembled with the bottom panel fully inserted.
- Ensure the drawers are not overloaded, which can cause them to sag or stick.
- Verify that no foreign objects are obstructing the drawer slots.

Specifications



A detailed diagram illustrating the length, width, and height of the desk, including the dimensions of the fabric drawers and side storage bag.

Feature	Detail
Brand	Casaottima
Model Number	SPCB01171401001USCP
Product Dimensions (D x W x H)	15.8" x 31.5" x 29.7"
Color	White
Style	Modern
Top Material Type	Engineered Wood (MDF)
Base Material	Alloy Steel
Number of Drawers	4 (Fabric)
Special Features	Desk with storage, Reversible Design, Side Hook, Cloth Storage Bag, Adjustable Footpads

Assembly Required	Yes

Warranty Information

For specific warranty details regarding your Casaottima 32-Inch Small Computer Desk, please refer to the documentation included with your purchase or contact Casaottima customer support directly. Warranty terms typically cover manufacturing defects and material flaws for a specified period from the date of purchase.

Support

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Casaottima customer service. You can typically find contact information on the product packaging, the manufacturer's official website, or through your point of purchase.

© 2025 Casaottima. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DG533HLV

More documents and user manuals: **https://manuals.plus/**