Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HOMCOM B81-005

HOMCOM 200CM/6.6FT Sliding Door Kit Instruction Manual

Brand: HOMCOM | **Model:** B81-005

1. Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your HOMCOM 200CM/6.6FT Carbon Steel Sliding Door Kit. Please read all instructions carefully before beginning installation to ensure safe and correct assembly and use. This kit is designed for single wooden doors, offering a space-saving and stylish solution for various rooms.

2. Safety Information

- Always wear appropriate safety gear, including gloves and eye protection, during installation.
- Ensure the mounting surface (wall) is structurally sound and capable of supporting the weight of the door and the hardware (up to 100 kg).
- Use appropriate fasteners for your wall type (wood studs, concrete, etc.). The provided fasteners may not be suitable for all wall types.
- Keep children and pets away from the installation area.
- Do not use this kit with hollow walls or walls with internal cavities unless proper reinforcement is installed.
- This product includes only the hardware kit; the door panel is NOT included.

3. Package Contents

Verify that all components listed below are present and undamaged before starting installation.




Image: All components included in the HOMCOM sliding door kit.

- 2 x Sliding Tracks (200 cm total length when assembled)
- 2 x Hangers (Rollers)
- 2 x Door Stoppers
- 2 x Anti-Jump Blocks
- 1 x Floor Guide
- Mounting Hardware (screws, anchors, washers, spacers, hex wrench)

4. Specifications



Image: Detailed diagram illustrating product dimensions and compatibility.

Feature	Detail
Model Number	B81-005
Material	Carbon Steel
Track Length	200 cm (6.6 ft)
Track Dimensions	200L x 4W x 0.6H cm
Maximum Supported Weight	100 kg
Maximum Door Width	100 cm (39.4 inches)
Compatible Door Thickness	30-35 mm or 35-40 mm
Minimum Clearance Above Door	14 cm
Door Type Compatibility	Single wooden doors only

Item Weight	7.2 kg
Color	Brown (Hardware is black)

5. Installation Instructions

This section outlines the general steps for installing the sliding door kit. Refer to the detailed diagrams provided with your product for precise measurements and component placement.

5.1 Prepare the Door and Wall

1. **Measure and Mark:** Determine the desired height for your door. The track should be installed at a height that allows for the door and rollers to clear the floor by approximately 1-1.5 cm. Ensure a minimum of 14 cm clearance above the top edge of the door for track installation.
2. **Locate Studs/Reinforcement:** Use a stud finder to locate wall studs or ensure adequate reinforcement for mounting the track. Mark the drilling points for the track.
3. **Drill Holes:** Drill pilot holes at the marked locations on the wall. Insert wall anchors if necessary, depending on your wall material.

5.2 Install the Track



Image: The 200 cm sliding track components.

1. **Assemble Track:** If your track comes in multiple pieces, connect them securely according to the manufacturer's instructions.
2. **Mount Track:** Attach the track to the wall using the provided screws and spacers. Ensure the track is perfectly level.

5.3 Attach Hangers to Door



Image: Close-up of a roller hanger mounted on a wooden door.



Image: The two roller hangers included in the kit.

1. **Mark Hanger Positions:** Measure and mark the positions for the hangers on the top edge of your door panel. Ensure they are evenly spaced and aligned.
2. **Drill Holes:** Drill pilot holes into the door panel at the marked positions.

3. **Attach Hangers:** Securely fasten the hangers to the door using the provided bolts.

5.4 Install Anti-Jump Blocks and Door Stoppers

1. **Anti-Jump Blocks:** Install the anti-jump blocks on the top edge of the door, above the hangers. These prevent the door from lifting off the track.
2. **Door Stoppers:** Slide the door stoppers onto the track. These will limit the door's travel and prevent it from sliding off the ends. Adjust their positions later for desired open/closed limits.

5.5 Hang the Door and Install Floor Guide



Image: The floor guide components.

1. **Hang Door:** Carefully lift the door and hook the rollers onto the track.
2. **Install Floor Guide:** Position the floor guide on the floor directly beneath the door, ensuring it aligns with the groove at the bottom of your door (if applicable) or the door's edge. Mark and drill holes, then secure the floor guide. This prevents the door from swinging outwards.

5.6 Final Adjustments

1. **Adjust Door Stoppers:** Slide the door stoppers to the desired open and closed positions and tighten them securely.
2. **Test Operation:** Gently slide the door back and forth to ensure smooth and quiet operation. Make any necessary adjustments to the floor guide or stoppers.

6. Operation

To operate your HOMCOM sliding door, simply grasp the door handle (if installed) or the edge of the door panel and slide it along the track. The rollers are designed for quiet and fluid movement. Ensure the path of the door is clear of obstructions.



Image: The HOMCOM sliding door kit installed with a wooden door.

7. Maintenance

- **Regular Cleaning:** Wipe the track and rollers periodically with a soft, damp cloth to remove dust and debris. Avoid abrasive cleaners.
- **Lubrication:** If the door's movement becomes less smooth, apply a small amount of silicone-based lubricant to the roller bearings and the top of the track. Do not use oil-based lubricants as they can attract dust.
- **Check Fasteners:** Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary.
- **Inspect Components:** Examine the rollers, hangers, and track for any signs of wear or damage. Replace any worn or damaged parts immediately.

8. Troubleshooting

- **Door is difficult to slide:**
  - Check the track for debris or obstructions. Clean thoroughly.

- Apply lubricant to the rollers and track.
- Ensure the track is level. An unlevel track can cause resistance.
- Verify the floor guide is not causing excessive friction.

- **Door makes noise when sliding:**
  - Lubricate the rollers and track.
  - Check for loose fasteners on the hangers or track.
  - Ensure the anti-jump blocks are not rubbing excessively.
- **Door swings out from the wall:**
  - Ensure the floor guide is properly installed and aligned with the door.
  - Check if the door has a groove for the floor guide; if not, ensure the guide is positioned to prevent outward swing.
- **Door comes off the track:**
  - Verify that the anti-jump blocks are correctly installed and tightened.
  - Check if the track is securely mounted and not sagging.

© 2026 HOMCOM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DG56HYZ6

More documents and user manuals: **https://manuals.plus/**