

[manuals.plus](#) /

› [Ayybboo](#) /

› [Ayybboo Football Digital Alarm Clock for Kids - Model 536 Instruction Manual](#)

Ayybboo 536

Ayybboo Football Digital Alarm Clock for Kids

MODEL 536 - USER MANUAL

INTRODUCTION

Thank you for choosing the Ayybboo Football Digital Alarm Clock for Kids, Model 536. This device is designed to help children develop time management skills with its engaging football design and various features. Please read this manual carefully to ensure proper setup and operation.



Image: Front view of the Ayybboo Football Digital Alarm Clock, Model 536, displaying the time and colorful light ring.

SAFETY INFORMATION

- Ensure the device is placed on a stable, flat surface to prevent accidental falls.
- Keep the alarm clock away from water, excessive moisture, and direct heat sources.
- Do not attempt to disassemble, modify, or repair the device yourself. Contact customer support if issues arise.
- Use only the provided USB charging cable and a compatible USB power adapter (5V/1A recommended) for power.
- This product is intended for children under adult supervision.

PACKAGE CONTENTS

- Ayybboo Football Digital Alarm Clock (Model 536)

- USB Charging Cable
- User Manual



PRODUCT OVERVIEW AND CONTROLS

Familiarize yourself with the buttons and ports on your alarm clock:



U01-Volume of the Tone=U09



Vogel



Weihnachten



Piep



Weich



Begeisterung



Glücklicht

Image: Side view of the alarm clock showing the Adjustment Key, RGB Key, Music/Countdown Key, '+' Key, and '-' Key.

Doppelter Wecker

Unterscheidung zwischen Wochentagen und Wochenenden



Schlummern für weitere 5 Minuten

Wenn der Wecker ertönt, drücken Sie die Taste auf der Oberseite des Weckers, um in den Schlummermodus zu wechseln.



Image: Top view highlighting the Snooze/Light button and a rear view showing the USB charging port.

Button Functions:

- **Adjustment Key:** Used to enter setting modes (time, alarm) and confirm selections.
- **RGB Key:** Cycles through the various night light colors.
- **Music/Countdown Key:** Selects alarm ringtones or activates the countdown timer.
- **‘+’ Key:** Increases values during settings or navigates options.
- **‘-’ Key:** Decreases values during settings or navigates options.
- **Snooze/Light Button (Top):** Activates the snooze function when an alarm sounds, or turns the night light on/off.

SETUP

Powering the Device

The Ayybboo Football Digital Alarm Clock is powered via a USB cable. Connect the provided USB cable to the charging port on the back of the clock and plug the other end into a compatible USB power adapter (not included) or a USB port. The clock will automatically turn on.

Initial Time Setting

1. Press and hold the **Adjustment Key** until the hour display starts blinking.
2. Use the '+' and '-' keys to adjust the hour. Press the **Adjustment Key** to confirm and move to minutes.
3. Use the '+' and '-' keys to adjust the minute. Press the **Adjustment Key** to confirm and move to 12/24 hour format selection.
4. Use the '+' and '-' keys to select between 12-hour (with AM/PM indicator) or 24-hour format. Press the **Adjustment Key** to confirm and exit time setting.

OPERATING INSTRUCTIONS

Setting Alarms (Dual Alarms)

The clock supports two independent alarms (Alarm 1 and Alarm 2). You can set each alarm for daily, weekdays (Monday-Friday), or Monday-Saturday.

1. Short press the **Alarm 1** or **Alarm 2** button (indicated by icons on the display) to select the alarm you wish to set.
2. Press and hold the **Adjustment Key** to enter alarm setting mode for the selected alarm. The hour display will blink.
3. Adjust the hour using the '+' and '-' keys, then press the **Adjustment Key** to confirm.
4. Adjust the minute using the '+' and '-' keys, then press the **Adjustment Key** to confirm.
5. Select the alarm frequency (daily, Mon-Fri, Mon-Sat) using the '+' and '-' keys. Press the **Adjustment Key** to confirm and exit alarm setting.
6. To activate or deactivate an alarm, short press the corresponding **Alarm 1** or **Alarm 2** button. An alarm icon will appear on the display when active and disappear when inactive.

Snooze Function

When an alarm sounds, press the **Snooze/Light Button** on top of the clock to activate the 5-minute snooze function. The alarm will temporarily stop and sound again after 5 minutes.

Zeitgesteuertes 120-Minuten-Nachtlicht



① Externe Stromversorgung anschließen



② Drücken und halten Sie die obere Taste, bis das Display L0:15 anzeigt



③ Drücken Sie „+“ und „-“, um die Timerlänge bis zu 120 Minuten einzustellen



Hinweis: Die zeitgesteuerte Nachtlichtfunktion erfordert den Anschluss an eine externe Stromquelle

Image: A child sleeping peacefully with the alarm clock on a bedside table, illustrating the snooze function.

Night Light Function

The clock features 7 monochromatic light colors and a dazzling color light. The night light can also be set with a timer.

- **To turn on/off:** Short press the **Snooze/Light Button** on top of the clock.
- **To change color:** While the night light is on, press the **RGB Key** on the side to cycle through the 7 available colors.
- **To set timer (requires external power):** While the night light is on and the clock is connected to external power, press and hold the **Snooze/Light Button** until "L0:15" (15 minutes) appears on the display. Use the '+' and '-' keys to adjust the timer duration from 0 to 120 minutes. The light will automatically turn off after the set time.

Siebenfarbiges Licht schaltbar



Die Schriftfarbe und die Lichtfarbe können nach Ihren Wünschen angepasst werden



Image: Illustration of setting the night light timer, showing the clock connected to external power and the display indicating the timer duration.

Ringtones and Volume

Choose from 6 gradual ringtones and 9 volume levels to ensure a gentle wake-up experience.

- **To select ringtone:** Press the **Music/Countdown Key** to cycle through the 6 available ringtones.
- **To adjust volume:** Use the '+' and '-' keys to set the volume level from U01 (lowest) to U09 (highest).

Power Failure Memory Function

The clock is equipped with a power failure memory function. In case of a power outage, the time and alarm settings will be retained, ensuring that the clock continues to function correctly once power is restored.



Image: Depiction of the power failure memory function, showing the clock retaining its time settings after being disconnected and reconnected to power.

MAINTENANCE

- Clean the clock's surface with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents.
- Keep the USB charging port free from dust and debris to ensure proper connection.
- If storing the device for an extended period, ensure it is fully charged and kept in a cool, dry place.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock not turning on	No power or low battery.	Connect the clock to a USB power source. Ensure the USB cable is securely connected.
Alarm not sounding	Alarm not activated or volume too low.	Ensure the alarm icon is displayed on the screen. Increase the alarm volume level using the '+' key.
Night light not working	Light is off, or not connected to external power for timer function.	Short press the Snooze/Light button to turn it on. Ensure external power is connected if using the timer function.
Time display incorrect	Time not set correctly.	Re-enter time setting mode (press and hold Adjustment Key) and adjust the time.
Low battery indicator blinking	Battery level is at 5% or below.	Connect the clock to a USB power source for charging immediately.

Fonction de Mémoire des Pannes de Courant

Cuando la luz está encendida, la hora sigue en hora



Image: The alarm clock display showing a red, blinking low battery indicator, signifying low battery capacity.

SPECIFICATIONS

- **Brand:** Ayybboo
- **Model Number:** 536
- **Color:** Black
- **Dimensions:** 9 x 3.81 x 11.5 cm (approximately 3.54 x 1.5 x 4.53 inches)
- **Weight:** 400 g (approximately 0.88 lbs)
- **Material:** Acrylonitrile Butadiene Styrene (ABS)
- **Display Type:** Digital LED
- **Power Source:** USB Cable (Electric)
- **Special Features:** Dual Alarms, 5-Minute Snooze, Colorful Night Lights (7 colors), Night Light Timer (0-120 min), 6 Ringtones, 9 Volume Levels, 12/24 Hour System, Countdown Function, Power Failure Memory, Low Battery Indicator.





Image: Detailed dimensions of the Ayybboo Football Digital Alarm Clock, including its height, width, and depth.

WARRANTY AND SUPPORT

For warranty information, technical support, or any inquiries regarding your Ayybboo Football Digital Alarm Clock, please refer to the contact details provided with your purchase documentation or visit the official Ayybboo website. Please retain your purchase receipt as proof of purchase for warranty claims.

 <p>Instruction Manual</p> <p>1. Seconds hand 2. Minute hand 3. Hour hand 4. Crown</p> <p>Settings: Please take account of the information above if your watch is fitted with a screwed crown. Turn the crown to position II (notched position) and turn it in either direction until the desired time is displayed. When done the crown must be turned back into position I (seconds hand is unable to adjust).</p>	<p>Ayybboo Kids Watch Instruction Manual</p> <p>Instruction manual for the Ayybboo Kids Watch, covering time setting, maintenance, water resistance, and warranty information. Learn how to care for and operate your child's watch.</p>
 <p>Manuale di Istruzioni</p> <p>1. Orologio digitale da polso Ayybboo per bambini 2. Orologio digitale da polso Ayybboo per bambini 3. Orologio digitale da polso Ayybboo per bambini 4. Orologio digitale da polso Ayybboo per bambini</p> <p>Funzioni: 1. Orologio digitale da polso 2. Orologio digitale da polso 3. Orologio digitale da polso 4. Orologio digitale da polso</p>	<p>Manuale di Istruzioni Orologio Ayybboo per Bambini</p> <p>Guida completa per l'uso e la manutenzione dell'orologio digitale Ayybboo per bambini, con istruzioni dettagliate su impostazioni, funzioni e cura.</p>
 <p>KALERUM</p> <p>Design & Quality IKEA Design & Quality IKEA</p>	<p>KALERUM Handle Assembly Instructions - IKEA</p> <p>Step-by-step guide for assembling the IKEA KALERUM handle, including drilling measurements and tool recommendations. Features clear instructions and diagrams described in text.</p>
 <p>Instruction Manual</p> <p>1. Seconds hand 2. Minute hand 3. Hour hand 4. Crown</p> <p>Settings: Please take account of the information above if your watch is fitted with a screwed crown. Turn the crown to position II (notched position) and turn it in either direction until the desired time is displayed. When done the crown must be turned back into position I (seconds hand is unable to adjust).</p>	<p>Ayybboo Kids Watch Instruction Manual</p> <p>Instruction manual for the Ayybboo Kids Watch, covering time setting, maintenance, water resistance, and warranty information. Learn how to care for and operate your child's watch.</p>
 <p>MITTLED</p> <p>IKEA Design & Quality IKEA</p>	<p>IKEA MITTLED LED Spotlight - Assembly and Safety Instructions</p> <p>Comprehensive assembly guide and safety instructions for the IKEA MITTLED LED spotlight. Learn how to install, use, and maintain your MITTLED light safely. This document covers important safety warnings, step-by-step installation, and product usage guidelines.</p>
 <p>HUDSON VALLEY LINE-2-LINE GROUP</p> <p>Corbett Vernazza 536-24</p>	<p>Corbett Vernazza 536-24 Installation Instructions</p> <p>Comprehensive installation guide for the Corbett Vernazza 536-24 lighting fixture by Corbett Lighting. Includes safety warnings in English, French, and Spanish, a detailed diagram description, step-by-step assembly instructions, and a replacement parts list.</p>