



Manuals.plus /

› HOYECHI /

› HOYECHI 3-Piece 2D Lighted Christmas Deer Family Set Instruction Manual

HOYECHI HYC8032-G

HOYECHI 3-Piece 2D Lighted Christmas Deer Family Set Instruction Manual

Model: HYC8032-G

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your HOYECHI 3-Piece 2D Lighted Christmas Deer Family Set. This set is designed to add a festive and warm glow to your outdoor holiday decorations. Please read these instructions carefully before use to ensure safe and proper installation.



The complete HOYECHI 3-Piece 2D Lighted Christmas Deer Family Set, featuring a buck, doe, and fawn, illuminated with warm LED lights and adorned with red bows.

2. IMPORTANT SAFETY INFORMATION

- **Outdoor Use Only:** This product is designed for outdoor use.
- **Unplug During Inclement Weather:** Always unplug the decoration during strong winds, heavy rain, or snow to prevent damage and ensure safety.
- **Glitter Warning:** This product contains glitter. Assemble outdoors or in an area that is easy to clean to avoid unnecessary mess.
- **Secure Placement:** Use the provided ground stakes and zip ties to firmly secure the deer figures to the ground, especially in windy conditions.
- **Power Source:** Ensure the power source is safe and suitable for outdoor use. Do not overload electrical outlets.
- **Inspection:** Regularly inspect the product for any damage to the lights, wiring, or frame. Discontinue use if any damage is found.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly:

- 1 x Buck Figure (with pre-installed 60 LED lights)
- 1 x Doe Figure (with pre-installed 50 LED lights)
- 1 x Fawn Figure (with pre-installed 35 LED lights)

- 3 x Red Bows (for each deer)
- Ground Stakes (for securing figures)
- Zip Ties (for securing connections)
- Power Adapter



Diagram showing the individual dimensions of the buck, doe, and fawn, along with the number of LEDs on each figure.

4. ASSEMBLY INSTRUCTIONS

The HOYECHI 3-Piece 2D Lighted Christmas Deer Family Set is designed for straightforward assembly. It is recommended to assemble the figures outdoors to manage any glitter shedding.

4.1 Step-by-Step Assembly

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, flat surface. Note the warning regarding glitter and consider assembling outdoors.
2. **Connect Body Sections:** Each deer figure consists of several flat sections. Align the corresponding parts (e.g., body to legs, neck to body) and secure them using the provided zip ties or integrated hooks/slots. For example, the tail and legs slide into designated holes on the main body.
3. **Install Antlers (Buck):** For the buck figure, carefully attach the antlers to the head section.

4. **Attach Bows:** Secure the red bows around the neck area of each deer figure.
5. **Position and Secure:** Once assembled, place the deer figures in your desired outdoor location. Use the ground stakes by inserting them through the designated loops at the base of the deer's feet and into the ground. This will provide stability against wind.
6. **Connect Power:** Connect the power adapter to the deer figures and then plug it into a suitable outdoor power outlet.



Image demonstrating the included ground nails and plug for secure installation, emphasizing the strong and sturdy design.

4.2 Assembly Video Guide

Official installation video demonstrating the assembly process for the HOYECHI 2D Set of Three Gold Deer, showing how to connect parts and secure them.

5. OPERATING INSTRUCTIONS

Once assembled and securely placed, operating your HOYECHI deer family set is simple:

- **Power On:** Plug the power adapter into a standard outdoor electrical outlet. The LED lights will illuminate, creating a warm white glow.
- **Power Off:** Unplug the power adapter from the electrical outlet to turn off the lights.
- **Timer (if applicable):** If using an external timer (not included), connect the power adapter to the timer and

program it according to the timer's instructions.



The deer family set beautifully illuminated at night in a snowy yard, creating a warm and inviting holiday display.

5.1 Product Showcase Video

Official product video showcasing the HOYECHI 2D Reindeer Family Christmas decorations in an outdoor setting, highlighting their festive appearance.

6. MAINTENANCE

- **Cleaning:** To clean the deer figures, gently wipe them with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials that could damage the glitter or wiring.
- **Storage:** When not in use, disassemble the deer figures and store them in their original packaging or a suitable container in a cool, dry place. This helps protect the glitter and lights for future seasons.
- **Light Replacement:** The LED lights are designed for long-lasting use. If a light fails, check for loose connections. If individual bulbs are replaceable (check product specifications), replace them with bulbs of the same type and wattage.

7. TROUBLESHOOTING

- **Lights Not Working:**

- Ensure the power adapter is securely plugged into a working electrical outlet.
- Check for any loose connections in the wiring between the deer figures.
- Inspect the fuse in the plug (if applicable) and replace if blown.

- **Figures Unstable:**

- Ensure all ground stakes are fully inserted into the ground.
- Verify that all zip ties and connections holding the frame together are tight.

- **Excessive Glitter Shedding:** This is normal during initial setup. Once assembled and placed, shedding should minimize. Avoid excessive handling.

8. SPECIFICATIONS

Brand	HOYECHI
Model Number	HYC8032-G
Item Weight	7.78 pounds (3.54 Kilograms)
Product Dimensions	22 x 8 x 48 inches (Buck: 28"L x 8.5"W x 48"H; Doe: 28"L x 8.5"W x 43"H; Fawn: 21.5"L x 5"W x 28"H)
Frame Material	Metal
Covering Material	Fabric, Glitter
Light Type	LED
Number of LED Lights	145 (Total)
Light Color	Warm White
Voltage	110 Volts

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact HOYECHI customer service directly. Keep your purchase receipt for any warranty claims.