

[Manuals.plus](#) /

› [domi outdoor living](#) /

› Domi Outdoor Living 10' x 12' Universal Winter Gazebo Cover Instruction Manual

domi outdoor living LGMF8160-C-EN-US

Domi Outdoor Living 10' x 12' Universal Winter Gazebo Cover Instruction Manual

Model: LGMF8160-C-EN-US

INTRODUCTION

Thank you for choosing the Domi Outdoor Living Universal Winter Gazebo Cover. This manual provides essential information for the proper installation, use, and maintenance of your 10' x 12' gazebo cover. Designed for hardtop gazebos, this all-season cover offers protection against various weather conditions, transforming your outdoor space into a functional storage area during colder months. Please read these instructions carefully before installation and retain them for future reference.



Image: The Domi 10' x 12' Universal Winter Gazebo Cover providing full enclosure for a hardtop gazebo during winter.

IMPORTANT SAFETY INFORMATION

Always secure the gazebo cover to a stable foundation using the pre-drilled holes to prevent it from being blown away in strong winds. Be cautious while opening and closing the zippered door and mesh curtains to avoid injury.

- Ensure the gazebo structure is stable and properly anchored before installing the cover.
- Do not use the cover in extreme weather conditions beyond its design capabilities.
- Regularly inspect the cover for any damage or wear, especially before and after severe weather.
- Keep children and pets away from the gazebo during installation and removal of the cover.
- Avoid using sharp objects near the cover to prevent tears or punctures.

PRODUCT FEATURES

The Domi Universal Winter Gazebo Cover is designed with several features to enhance its functionality and durability:

- **Premium PE Material:** Crafted from high-quality polyethylene for superior water resistance and durability.
- **Universal Fit:** Specifically designed for 10' x 12' hardtop gazebos, ensuring a snug fit for maximum protection.
- **Wind-Resistant Design:** Features extended 8.7-inch length sides and pre-drilled holes for secure anchoring against strong winds.
- **Practical Access:** Includes a zippered door for easy entry and exit.
- **Ventilation:** Equipped with mesh curtains for airflow and dust control, maintaining comfort inside.
- **UV-Resistant:** Provides protection against harmful UV rays.
- **Storage Conversion:** Transforms your gazebo into a protected storage space for outdoor furniture, bikes, and seasonal items.



Image: Detail of the window design, showing Velcro fasteners and mesh netting for ventilation.



Image: Detail of the double zipper door for easy access and the roller system for opening.




Image: Illustration of the pre-drilled holes and extended side length for secure ground anchoring.



Image: The gazebo cover converting the gazebo into a protected storage area for various outdoor equipment.

SETUP AND INSTALLATION

Proper installation is crucial for the cover's performance and longevity. It is recommended that at least three people assist with the installation process.

1. **Verify Gazebo Size:** Confirm that your hardtop gazebo measures 10' x 12' to ensure a correct and snug fit. This cover is not suitable for soft-top gazebos, pergolas, or full-wood gazebos.
2. **Unpack and Inspect:** Carefully unpack the cover and inspect it for any manufacturing defects or damage.
3. **Orient the Cover:** Identify the front (zippered door) and back of the cover. Unzip the door completely before attempting to place the cover over the gazebo structure.
4. **Drape Over Structure:** With assistance, carefully lift and drape the cover over the hardtop gazebo frame. Ensure it is centered and evenly distributed.
5. **Secure Top Corners:** Utilize the tabs at the top of all four corners to help secure the cover. Tying ropes to these grommets and pulling them over the top can aid in hoisting the cover.
6. **Fasten Sides and Bottom:**
 - Secure the cover to the gazebo posts using the inside ties located at each corner.
 - Utilize the pre-drilled holes along the extended 8.7-inch bottom sides to anchor the cover to the ground. Stakes, bricks, or cinder blocks can be used to weigh down the flaps for added stability, especially in windy conditions.
7. **Adjust Windows and Doors:** Ensure all zippers operate smoothly and mesh curtains are properly positioned for desired ventilation or privacy.

10x12FT

GAZEBO COVER

Hardtop Gazebo Not Included



Image: Dimensional diagram of the 10' x 12' gazebo cover, illustrating key measurements for proper fit.

OPERATION AND USAGE

Once installed, your gazebo cover provides a versatile enclosed space:

- **Access:** Use the zippered door for convenient entry and exit. Ensure zippers are fully closed when not in use to maintain enclosure integrity.
- **Ventilation:** The mesh windows allow for airflow while keeping insects out. Roll up and secure the outer fabric flaps to expose the mesh, or keep them down for full enclosure.
- **Storage:** The enclosed space is ideal for protecting outdoor furniture, bicycles, lawnmowers, and other seasonal items from cold, moisture, and dust.
- **Weather Protection:** The waterproof PE material prevents rain and snow accumulation, keeping the interior dry.

Prevent Snow Accumulation



Prevent Water Accumulation




Image: Visual representation of the cover's ability to prevent both snow and water accumulation.

MAINTENANCE

Regular maintenance will extend the life of your gazebo cover:

- **Cleaning:** Clean the cover periodically with mild soap and water. Avoid harsh chemicals or abrasive brushes that could damage the PE material. Rinse thoroughly and allow to air dry completely before storage.
- **Snow Removal:** In areas with heavy snowfall, regularly clear snow from the top of the cover to prevent excessive weight accumulation, which could stress the material and frame.
- **Inspection:** Periodically check the cover for any tears, punctures, or signs of wear. Promptly repair small damages to prevent them from worsening. Inspect zippers and ties for functionality.
- **Storage:** When not in use, clean and thoroughly dry the cover. Fold it neatly and store it in a cool, dry place away from direct sunlight and pests.

TROUBLESHOOTING

If you encounter issues with your gazebo cover, consider the following:

- **Cover does not fit:** Double-check your gazebo's dimensions. This cover is designed for 10' x 12' hardtop gazebos. Ensure it is oriented correctly.
- **Water pooling on top:** Ensure the cover is taut and properly secured to allow water to run off. Clear any debris that might obstruct drainage.
- **Cover flapping in wind:** Verify all anchoring points are securely fastened, including the pre-drilled holes at the bottom and ties to the gazebo frame. Add additional weights if necessary.
- **Zippers sticking:** Clean the zipper teeth and apply a silicone-based lubricant if needed. Avoid forcing stuck zippers.

For further assistance, please contact Domi Outdoor Living customer support.

SPECIFICATIONS

Feature	Detail
Brand	Domi Outdoor Living
Model Number	LGMF8160-C-EN-US
Product Dimensions (L x W x H)	3.66L x 3.05W x 2.95H meters (10' x 12' x 9.68')
Item Weight	9.71 kg (21.4 lbs)
Material	Polyethylene (PE)
Color	White
Water Resistance Level	Waterproof
UV Protection	Yes
Country of Origin	China

WARRANTY INFORMATION

For specific warranty details regarding your Domi Outdoor Living Universal Winter Gazebo Cover, please refer to the warranty card included with your purchase or contact Domi Outdoor Living customer service directly. Warranty terms typically cover manufacturing defects and material flaws under normal use.

CUSTOMER SUPPORT

If you have any questions, require assistance with installation, or need to report an issue, please contact Domi Outdoor Living customer support. Contact information can typically be found on the product packaging or the official Domi Outdoor Living website.
Manufacturer: domi outdoor living

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question