



[Manuals.plus](#) /

› [JREN](#) /

› JREN Kids Tablet Instruction Manual

JREN JR-J10

JREN Kids Tablet Instruction Manual

Model: JR-J10

INTRODUCTION

Thank you for choosing the JREN Kids Tablet. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device. Please read it thoroughly to ensure optimal performance and a safe user experience for your child.



Image: The JREN Kids Tablet, featuring a vibrant pink protective case and a 10.1-inch display showing animated characters, highlighting its entertainment capabilities.

WHAT'S IN THE BOX

Upon opening the package, please verify that all the following items are included:

- JREN Kids Tablet (Model: JR-J10)
- Charging Cord
- Charger

SETUP GUIDE

1. Initial Charge

Before first use, fully charge the tablet. Connect the provided charging cord to the tablet's charging port and the charger

to a power outlet. The battery indicator on the screen will show charging progress. A full charge can provide up to 12 hours of continuous use.

2. Power On/Off

To power on, press and hold the power button located on the side of the tablet until the screen lights up. To power off, press and hold the power button, then select "Power off" from the options that appear on the screen.

3. Wi-Fi Connection

1. Go to **Settings**.
2. Tap on **Network & internet**.
3. Select **Wi-Fi** and turn it on.
4. Choose your desired Wi-Fi network from the list and enter the password if prompted.

4. Google Account Setup

Follow the on-screen prompts to set up a Google account. This is essential for accessing the Google Play Store and Google Kids Space.

OPERATING INSTRUCTIONS

Display and Navigation

10 Inch Large Screen

Octa-Core CPU | 4GB RAM+4GB Virtual | 64GB ROM



Image: The JREN Kids Tablet displaying its 10.1-inch screen, highlighting its Octa-Core CPU, 4GB RAM + 4GB Virtual RAM, and 64GB ROM for smooth performance.

The tablet features a 10.1-inch HD touchscreen (1280 x 800 pixels). Navigate by tapping, swiping, and pinching. An eye-care mode is available in settings to reduce eye strain.

Google Kids Space

Pre-installed Kids App



Google Kids Space



Youtube KIDS




Image: A blue JREN Kids Tablet screen showing the Google Kids Space interface, with logos for Google Kids Space and YouTube Kids, indicating pre-installed child-friendly applications.

The tablet comes with Google Kids Space, offering a curated library of age-appropriate content including educational games, videos, and stories. Access it from the home screen or app drawer.

Parental Controls ([Google Family Link](#))

Parental Control



Time Limit



Content Filter



Child Lock



Activity Reporter



Image: Icons representing parental control features: Time Limit, Content Filter, Child Lock, and Activity Reporter, with children and an adult in the background using the tablet.

Utilize Google Family Link to manage your child's screen time, app downloads, and content filtering. This can be controlled from your own device. For detailed instructions, visit the official Google Family Link support page.

- Set daily screen time limits.
- Approve or block app downloads from the Play Store.
- Filter content based on age appropriateness.
- View activity reports to understand usage patterns.

Camera Functionality

HD Dual Camera

Front 2MP | Rear 5MP



Image: A child interacting with the JREN Kids Tablet, which displays a family video call on its screen, emphasizing the tablet's 2MP front and 5MP rear HD dual cameras.

The tablet is equipped with a 2MP front camera and a 5MP back camera. Open the Camera app to take photos or record videos. These cameras are suitable for video calls and capturing everyday moments.

Storage Expansion

The tablet has 64GB of internal storage, which can be expanded up to 1TB using a microSD card (not included). Insert the microSD card into the designated slot on the tablet.

MAINTENANCE AND CARE

Cleaning the Tablet

Use a soft, lint-free cloth to clean the screen and body of the tablet. For stubborn smudges, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials.

Long Battery Life



Video



Game



Web



Standby



Image: Two children in a car using the JREN Kids Tablet, with icons indicating long battery life for video (6H), game (5H), web (8H), and standby (14 Days).

The 6000mAh battery provides extended usage. To prolong battery life, avoid extreme temperatures, do not overcharge, and disconnect the charger once fully charged. If the tablet will not be used for an extended period, charge it to about 50% before storing.

Kid-Proof Case

Kids-proof Case



Image: A happy child running with the JREN Kids Tablet, which is protected by its durable, pink EVA kid-proof case with a built-in stand and ergonomic handle, designed to withstand drops and bumps.

The tablet comes with a durable EVA kid-proof case designed to protect against drops, scratches, and bumps. The built-in stand allows for hands-free viewing, and the ergonomic handle makes it easy for children to carry.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Tablet won't turn on.	Low battery; software crash.	Charge the tablet for at least 30 minutes. If still unresponsive, press and hold the power button for 10-15 seconds to force a restart.
Wi-Fi connection issues.	Incorrect password; router issue; out of range.	Double-check Wi-Fi password. Restart your router. Ensure tablet is within Wi-Fi range.
Apps are slow or crashing.	Too many apps running; low storage; outdated app.	Close background apps. Clear app cache. Free up storage space. Update apps from Google Play Store.

Problem	Possible Cause	Solution
Screen is unresponsive.	Temporary software glitch.	Force restart the tablet by holding the power button for 10-15 seconds.

SPECIFICATIONS

Feature	Detail
Model	JR-J10
Operating System	Android 14
Processor	Octa-Core, 2 GHz (Allwinner)
RAM	8GB (4GB physical + 4GB virtual)
Internal Storage	64GB
Expandable Storage	Up to 1TB via microSD card (not included)
Screen Size	10.1 Inches
Screen Resolution	1280 x 800 Pixels HD
Front Camera	2MP
Rear Camera	5MP
Battery Capacity	6000mAh
Average Battery Life	Up to 12 hours
Wireless Connectivity	Wi-Fi (802.11ac), Bluetooth
Dimensions (LxWxH)	10.5 x 10.5 x 0.6 inches
Item Weight	1.56 pounds
Color	Pink

WARRANTY AND SUPPORT

The JREN Kids Tablet comes with a 2-year worry-free guarantee as mentioned in the product features. For warranty claims, technical support, or any inquiries, please contact JREN customer service through the retailer's platform or the contact information provided with your purchase documentation.

Please retain your proof of purchase for warranty validation.

