## Soundcore Space One Pro

# Soundcore Space One Pro Headphones Instruction Manual

Model: Space One Pro

## Product Overview

The Soundcore Space One Pro headphones are designed to provide an immersive audio experience with advanced noise-cancelling capabilities and high-fidelity sound. This manual provides essential information for setting up, operating, and maintaining your headphones.



Image: Soundcore Space One Pro headphones shown with their protective carrying case.

## Setup and Initial Use

### Charging

Before first use, fully charge your Soundcore Space One Pro headphones. Connect the included USB-C cable to the charging port on the headphones and to a power source. The LED indicator will show charging status.

### Power On/Off

To power on, press and hold the power button until the LED indicator lights up. To power off, press and hold the power button until the LED indicator turns off.

### Bluetooth Pairing

1. Ensure the headphones are powered off.
2. Press and hold the power button for 5 seconds until the LED indicator flashes blue, indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for "Soundcore Space One Pro" in the list of available devices.

4. Select the headphones to connect. Once connected, the LED indicator will turn solid blue.

### Wired Connection

The headphones can also be used with a wired connection. Connect one end of a 3.5mm audio cable (not included) to the audio input port on the headphones and the other end to your audio device. Noise cancellation features can still be used when connected via cable.

## Operating Instructions

### Active Noise Cancellation (ANC) and Transparency Mode

The Soundcore Space One Pro features an exclusive 4-stage noise cancelling system that adapts to your environment, blocking a wider range of on-the-go noise. It also includes a Transparency Mode to allow you to hear your surroundings.





Image: An internal diagram illustrating the components of the 4-stage noise cancelling system within the headphone earcups.

Use the dedicated ANC button on the headphones or the Soundcore app to switch between ANC, Normal, and Transparency modes.

### Easy Chat Feature

The Easy Chat feature automatically lowers music volume and activates Transparency Mode when you speak, allowing for quick conversations without removing your headphones. This feature can be enabled and configured through the Soundcore app.

## Audio Quality and Customization

Experience rich, lossless audio with the Space One Pro's advanced drivers featuring triple composite diaphragms. Support for LDAC mode enables Hi-Res audio playback.




Image: A person wearing the Soundcore Space One Pro headphones, with text highlighting "Rich, Undistorted Sound" and "Hi-Res Audio Wireless LDAC" logos.

Utilize the Soundcore app to customize your listening experience with various sound effects, including a custom equalizer (EQ) and HearID Sound personalization, which tailors the sound profile to your unique hearing.

## Battery Life and Charging

The headphones offer extended playback times:

- Up to 40 hours with Active Noise Cancellation (ANC) on.
- Up to 60 hours with ANC off.

Ultra-fast charging provides 8 hours of playback from just a 5-minute charge.




Image: Graphic showing the Soundcore Space One Pro headphones with text indicating "60H" for total battery life, "40H ANC ON", "60H ANC OFF", and "5 Mins = 8 Hrs Ultra-Fast Charging".

## Foldable Design and Portability

The Soundcore Space One Pro features a FlexiCurve Structure that allows the headphones to fold down to half their original size, making them highly portable and easy to store in bags or luggage.




Image: A hand holding the Soundcore Space One Pro headphones in their super foldable design, demonstrating their compact size.

## Maintenance and Care

### Cleaning

To clean your headphones, use a soft, dry cloth. Do not use abrasive cleaners or solvents. For ear cushions, gently wipe with a damp cloth and allow to air dry completely before use.

## Storage

When not in use, store your headphones in the provided protective case to prevent damage from dust, splashes, and impacts. The case offers four-layer full protection, including water-resistance (excluding zipper and strap), anti-scratch, dust-resistance, impact-resistance, and a protective soft fleece lining.

# FOUR-LAYER FULL PROTECTION




Image: A cross-section diagram of the headphone case, illustrating its four layers of protection: water-resistant, anti-scratch and dust-resistant, impact-resistant, and protective soft fleece-lined.




Image: A hand placing the headphone case, highlighting its ergonomic recessed handle, into a bag.

## Troubleshooting

- **No Power:** Ensure the headphones are charged. Connect to a power source and try again.
- **Cannot Pair:** Make sure the headphones are in pairing mode (flashing blue LED). Turn off and on your device's Bluetooth. If issues persist, try forgetting the device on your Bluetooth list and re-pairing.

- **No Sound:** Check volume levels on both headphones and your connected device. Ensure the correct audio output is selected on your device. If using a wired connection, ensure the cable is fully inserted.
- **Noise Cancellation Not Working Effectively:** Ensure earcups are properly sealed around your ears. Adjust the ANC settings via the Soundcore app.
- **Poor Call Quality:** Ensure the microphone is not obstructed. Check for strong Bluetooth connection.

For more detailed troubleshooting or advanced settings, refer to the Soundcore app or the official Soundcore support website.

## Specifications

| Feature | Detail |
|---|---|
| Brand | Soundcore |
| Model Name | Space One Pro |
| Connectivity Technology | Wireless (Bluetooth) |
| Form Factor | Over Ear |
| Noise Control | Adaptive Noise Cancellation |
| Battery Life | 60 Hours (ANC off), 40 Hours (ANC on) |
| Included Components | Ear Cushions, Headphones Case |
| Material | Fabric (for case) |
| Case Dimensions | 8.1 Inches (width) x 8.5 Inches (height) x 2.8 Inches (depth) |




Image: The protective headphone case shown with its approximate dimensions: 8.1 inches width, 8.5 inches height, and 2.8 inches depth.

## Warranty and Support

### Warranty Information

For detailed warranty information, please refer to the warranty card included with your product or visit the official Soundcore website. Warranty terms and conditions may vary by region.

## Customer Support

If you encounter any issues or have questions regarding your Soundcore Space One Pro headphones, please contact Soundcore customer support through their official website or the contact information provided in your product packaging. You can also visit the Soundcore Store on Amazon for more product information and resources.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**