

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Godrej](#) /

› [Godrej 7 Kg Eco-Wash Fully-Automatic Front Load Washing Machine WFEON ARG 7012 5.0 FEBT SLSR User Manual](#)

Godrej WFEON ARG 7012 5.0 FEBT SLSR

Godrej 7 Kg Eco-Wash Fully-Automatic Front Load Washing Machine User Manual

Model: WFEON ARG 7012 5.0 FEBT SLSR

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your new Godrej 7 Kg Eco-Wash Fully-Automatic Front Load Washing Machine. Please read these instructions carefully before installation and use, and retain them for future reference. This appliance is designed for household use only.

FULLY-AUTOMATIC FRONT LOAD WASHING MACHINE WITH INBUILT HEATER

Best Wash Quality,
Energy and
Water
efficient



Image: The Godrej Front Load Washing Machine, emphasizing its efficiency and wash quality, shown with a user and child.

2. SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or

injury. This section outlines general safety guidelines. For detailed safety instructions, refer to the full user manual included with your product.

- **Electrical Safety:** Ensure the washing machine is connected to a properly grounded outlet. Do not use extension cords or adapters.
- **Water Supply:** Connect the machine to a cold water supply using new hose sets. Do not reuse old hose sets.
- **Child Safety:** Keep children and pets away from the appliance during operation. Activate the Child Lock feature to prevent unintended use.
- **Flammable Materials:** Do not wash items that have been cleaned, washed, soaked, or spotted with combustible or explosive substances.
- **Installation:** Ensure the machine is installed on a firm, level surface. Proper leveling is crucial for stable operation.



Image: The washing machine with its door open, illustrating key safety and performance features like Child Lock and the durable Stainless Steel Drum.

3. INSTALLATION

Proper installation is vital for the performance and longevity of your washing machine. It is recommended to have the appliance installed by a qualified technician.

3.1 Unpacking

Carefully remove all packaging materials. Inspect the machine for any damage. Remove all transit bolts from the rear of the machine before use. These bolts secure the drum during transport and must be removed to prevent damage during operation.

3.2 Location

Place the washing machine on a solid, level floor. Ensure there is adequate space around the machine for ventilation and maintenance. Avoid direct sunlight or extreme temperatures.

3.3 Leveling

Adjust the leveling feet at the bottom of the machine until it is perfectly stable and level. Use a spirit level to verify. An unbalanced machine can cause excessive vibration and noise.

3.4 Water Connection

Connect the intake hose to a cold water tap and to the water inlet valve on the back of the washing machine. Ensure all connections are tight to prevent leaks. The drain hose should be securely placed into a standpipe or laundry tub, ensuring it is not kinked.

3.5 Electrical Connection

Plug the power cord into a grounded electrical outlet. Ensure the voltage and frequency match the specifications listed on the appliance's rating label.

4. OPERATING INSTRUCTIONS

Your Godrej washing machine offers a range of programs and features for optimal laundry care. Familiarize yourself with the control panel and wash program options.

4.1 Control Panel Overview





Image: The washing machine's control panel, featuring the program selector, digital display, and buttons for various wash options. The control panel features a central program dial, an advanced digital display, and push buttons for various functions such as Delay, Spin, Temp, and Function. The LED display provides information on the selected program, remaining time, and error codes.

4.2 Loading Laundry

Open the door and load clothes loosely into the drum. Do not overload the machine. For best results, sort laundry by fabric type, color, and soil level.



Image: A user loading clothes into the washing machine drum.

4.3 Adding Detergent and Softener

Add the appropriate amount of detergent to the main wash compartment and fabric softener to its designated compartment in the dispenser drawer. Refer to detergent packaging for dosage recommendations.

4.4 Selecting a Wash Program

Turn the program dial to select one of the 15 available wash programs. The selected program will be displayed on the LED screen. Programs include:

- **Cotton:** For durable cotton items.
- **Rapid 15:** A quick wash cycle for lightly soiled items.
- **90°C Hot Wash:** Available in select programs for hygienic cleaning and bacteria elimination.
- **Eco-Wash:** Optimized for energy and water efficiency.
- **Baby Care:** Gentle wash for baby clothes.
- **Intensive Wash:** For heavily soiled items.
- **Synthetic:** For synthetic fabrics.
- **Woollens:** Gentle cycle for wool items.
- **Denim:** Specific program for denim garments.
- **Mix Fabric:** For mixed loads.
- **Rinse + Spin:** For rinsing and spinning only.
- **Spin Only:** For draining and spinning only.
- **Colors:** Designed to protect colored garments.
- **Bulky:** For larger items like blankets.
- **Sports Wear:** For athletic apparel.




Image: Examples of clothing types that can be washed, illustrating the versatility of wash programs.

4.5 Special Functions

- **Delay Start:** Postpone the start of a wash cycle by up to 24 hours.
- **Pre-Wash:** An additional wash cycle before the main wash for heavily soiled items.
- **Extra Rinse:** Adds an extra rinse cycle to ensure thorough detergent removal.
- **Child Lock:** Locks the control panel to prevent accidental changes during operation.
- **Mute Wash:** Reduces operational sounds for quieter washing.
- **Pause to Add Items:** Allows you to pause the cycle and add forgotten items (if water level and temperature permit).





Image: The washing machine highlighting features such as the ability to pause and add items, delay start, and foam protection.

4.6 Starting and Stopping a Cycle

Press the Start/Pause button to begin the selected wash cycle. To pause the cycle, press the Start/Pause button again. To cancel a cycle, press and hold the Start/Pause button for a few seconds.

5. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your washing machine.

5.1 Drum Clean

The Stainless Steel Acu Wash Drum is designed for hygienic cleaning. The Drum Clean LED will automatically start blinking after 25 cycles, serving as a reminder to run a drum cleaning cycle. This cycle heats water up to 90°C to sanitize the drum.



Image: An illustration of the drum cleaning process, showing water flow within the drum.

5.2 Dispenser Drawer Cleaning

Periodically remove and clean the detergent dispenser drawer to prevent residue buildup. Rinse it under running water and dry before reinserting.

5.3 Door Seal Cleaning

Wipe the door seal after each wash to remove any lint or moisture, preventing mold and odors.

5.4 Exterior Cleaning

Clean the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners or solvents.

6. TROUBLESHOOTING

This section addresses common issues you might encounter. For more complex problems, contact customer service.

- **Machine Not Starting:** Check if the power cord is securely plugged in and the door is fully closed. Ensure the water supply is turned on.
- **Excessive Vibration/Noise:** Verify that the machine is level and that all transit bolts have been removed. Ensure the load is balanced (Unbalanced Load Detection system will help).
- **Water Leaks:** Check hose connections for tightness. Ensure the drain hose is properly installed.
- **Foam Protection:** If excessive foam is detected, the machine may automatically adjust the cycle to reduce it. Use appropriate detergent dosage.
- **Error Codes:** The Error Detection System will display codes on the LED screen. Refer to the full manual for a list of codes and their solutions.



Image: The washing machine illustrating features like Unbalanced Load Detection and the Advanced Drum Clean function.

7. SPECIFICATIONS

| Feature | Specification |
|----------------|------------------------------|
| Brand | Godrej |
| Model | WFEON ARG 7012 5.0 FEBT SLSR |
| Capacity | 7 Kilograms |
| Type | Fully-Automatic Front Load |
| Inbuilt Heater | Yes (90°C Hot Wash) |

| Feature | Specification |
|----------------------------|---|
| Maximum Rotational Speed | 1400 RPM |
| Wash Programs | 15 |
| Drum Type | Stainless Steel Acu Wash Drum |
| Control Console | Push Button with Advanced Digital Display |
| Special Features | Auto Restart, Child Lock, Delay Start, Eco-Wash, Unbalanced Load Detection, Foam Protection, Intensive Wash, Mute Wash, Rapid 15, Extra Rinse, Pre-Wash, Overflow Protection System, Error Detection System |
| Color | Silver Stream |
| Material | Stainless Steel |
| Voltage | 230 Volts |
| Item Weight | 60 kg |
| Product Dimensions (LxWxH) | 56.5 x 59.4 x 84 Centimeters |
| Included Components | 1 Washing Machine, Drain Hose, Intake Hose, Safety Cover, User Manual |



Image: The Godrej Front Load Washing Machine, showcasing its design and key features like the In-Built Heater.

8. WARRANTY AND SUPPORT

Your Godrej washing machine comes with a comprehensive warranty:



- **Wash Motor:** 10 Year Warranty
- **Entire Washing Machine:** 2 Year Warranty


For warranty claims, technical assistance, or any product-related inquiries, please contact Godrej customer support.

Keep your purchase receipt and product serial number handy when contacting support.

You can find more information and support on the official Godrej website or through authorized service centers.

Related Documents - WFEON ARG 7012 5.0 FEBT SLSR

| | |
|--|--|
|   How to get the best of your Godrej Washing Machine | <p><u>Godrej Washing Machine User Manual: Installation, Operation, and Maintenance Guide</u></p> <p>Comprehensive user manual for Godrej Fully Automatic Front Load Washing Machines (WFEON CRS 6510, 7010, 7512, 8012 models). Includes detailed instructions on installation, operation, program selection, maintenance, troubleshooting, and warranty information.</p> |
|   How to get the best out of your Godrej Washing Machine | <p><u>Godrej Fully Automatic Front Load Washing Machine User Manual WFEON Series</u></p> <p>Comprehensive user manual for Godrej Fully Automatic Front Load Washing Machines (WFEON RGL 9014 5.0, 8514 5.0, 8014 5.0, ZUS 9014 5.0). Includes safety, installation, operation, maintenance, troubleshooting, and warranty information.</p> |
|   | <p><u>Godrej Fully Automatic Front Load Washing Machine Warranty Terms and Conditions</u></p> <p>Detailed warranty terms and conditions for the Godrej Fully Automatic Front Load Washing Machine, including coverage, exclusions, and customer responsibilities.</p> |
|   HOW TO GET THE BEST OUT OF YOUR GODREJ EON WASHING MACHINE | <p><u>Godrej EON Washing Machine User Manual - WSAXIS DX 70 5.0 SN2 T</u></p> <p>Comprehensive user manual for the Godrej EON WSAXIS DX 70 5.0 SN2 T Fully Automatic Top Load Washing Machine. Includes installation, operation, maintenance, safety guidelines, and troubleshooting.</p> |
|   How to get the best out of your Godrej Eon Washing Machine | <p><u>Godrej Eon Washing Machine User Manual: Operation, Installation & Troubleshooting</u></p> <p>Comprehensive user manual for the Godrej Eon Washing Machine. Learn about safe operation, installation, maintenance, troubleshooting, and specifications for models WTEON RHN 10 5.0 FEEH, WTEON RHN 12 5.0 FEEH, WTEON RHN 10 FT GLGR, and WTEON RHN 12 FT GLGR. Includes program details and error codes.</p> |



[Godrej Eon Washing Machine User Manual: Operation, Features, and Troubleshooting](#)

Comprehensive user manual for the Godrej Eon Fully Automatic Top Load Washing Machine.

Covers setup, operation, programs, maintenance, troubleshooting, error codes, specifications, and warranty information.

Documents - Godrej – WFEON ARG 7012 5.0 FEBT SLSR

[pdf]

Verma Divya SBICard 35 MM CL EDGE CB D 87 R BFN4 LIGR Air Cooler 3 SBI CardWashing Machine
SA 7 0KG Axis WSAXIS DX 70 5 SN2 T WNRD Washing GPGR Axismodel godrej aug24sbicard sbi card
en assets media images personal offers categories shopping aug24 model |||

Product Category Air Cooler Air Cooler Air Cooler Air Cooler Air Cooler Air Cooler Air
Cooler Air Co ... 18ATC3 PYB WVBG AC 1T SIC 12ITC3 WYR Split 3S AC 1T SIC
12PTC3 WWP Split 3S AC 1T SIC 12DTC3-GYA AL **WFEON ARG 7012 5.0 FEBT**
SLSP WFEON CRS 6510 5.0 FKEDM GLWLL AC 1.5T SIC 12TTC3 WYR

lang:es score:15 filesize: 517.11 K page_count: 24 document_date: 2024-08-09

[pdf]

Verma Divya SBICard Product Category SBI CardWashing Machine SA 7 0KG Axis WSAXIS DX 70 5 SN2 T WNRD Washing GPGR AxisModel List Godrej sbicard sbi card en assets media images personal offers categories shopping Godrei 13may25 Model III

Product Category Type Refrigerator DC Refrigerator DC Refrigerator DC Refrigerator
DC Refr ... RPM Silver Stream WFEON ARG 7014 FEBDT SLSR Washing Machine
FAFL 7 kg 1200 RPM Silver Stream **WFEON ARG 7012 5.0 FEBT SLSR** Washing
Machine FAFL 8 kg 1400 RPM Silver Stream WFEON CEL 8014 IE...

lang:es score:15 filesize: 603.17 K page_count: 34 document date: 2025-05-09