

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [MiLi](#) /

› [MiLi MiCard Wireless Rechargeable Wallet Tracker User Manual](#)

MiLi MiCard

MiLi MiCard Wireless Rechargeable Wallet Tracker User Manual

Brand: MiLi | Model: MiCard

INTRODUCTION

The MiLi MiCard is a credit-card-sized Bluetooth tracking device designed to help you locate your valuables. It features wireless recharging, a long-lasting battery, and seamless integration with the Apple Find My network. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your MiCard.



Image: The MiLi MiCard, a thin, black credit-card sized tracker.

SAFETY INFORMATION

- Do not attempt to disassemble, repair, or modify the device.
- Avoid exposing the device to extreme temperatures or direct sunlight for prolonged periods.
- Keep the device away from strong magnetic fields.
- Dispose of the device and its battery responsibly according to local regulations.
- While the device is IP65 waterproof, avoid submerging it in water or exposing it to high-pressure water jets.

PACKAGE CONTENTS

- 1 x MiLi MiCard Wireless Rechargeable Wallet Tracker
- User Manual (this document)

Note: A wireless charging pad is not included and must be prepared separately.

1. Initial Charging

Before first use, fully charge your MiLi MiCard. The device supports wireless charging. Place the MiCard on any compatible wireless charging pad. A full charge typically takes about 1 hour and can provide power for 4-6 months of use. The overall battery life is up to 5 years.



Image: The MiLi MiCard on a wireless charging pad, illustrating its wireless charging capability and long battery life.

2. Pairing with Apple Find My (iOS Only)

The MiLi MiCard is MFi Certified and designed exclusively for iOS devices. Follow these steps to pair it with your Apple Find My app:

1. Ensure your MiCard is charged and powered on.
2. Open the **Find My** app on your iPhone, iPad, or Mac.
3. Navigate to the **Items** tab.

4. Tap the + icon and select **Add Other Item**.
5. Follow the on-screen instructions to connect your MiCard. The app will guide you through the pairing process.
6. Once connected, you can name your MiCard and assign an emoji to it for easy identification.



Image: The MiLi MiCard integrates with the Apple Find My app, allowing users to locate their items and play a sound.

OPERATING INSTRUCTIONS

1. Locating Your Item

- Play Sound:** If your MiCard is within Bluetooth range, open the Find My app, go to the Items tab, select your MiCard, and tap "Play Sound" to make it emit an audible alert (70-85dB).
- Precision Finding:** For supported iPhone models, use Precision Finding to get exact directions to your MiCard when it's nearby.
- Left-Behind Alerts:** Enable notifications in the Find My app to receive an alert on your iOS device if you leave your MiCard behind and it goes out of Bluetooth range. This helps prevent accidental loss.

Left-Behind Remind




Image: The MiLi MiCard's left-behind alert feature, notifying the user when their item is no longer detected nearby.

2. Lost Mode (NFC Function)

If your MiCard is lost and found by someone, they can tap their NFC-enabled smartphone (both iOS and Android) to the MiCard. This will display a message with your contact information (if you have set it up in Lost Mode within the Find My app), allowing them to return your item.

Lost Mode- NFC Function

Get the lost person's contact information



Image: The MiLi MiCard's NFC function in Lost Mode, enabling a finder to access contact information by tapping their phone to the card.

3. Optimal Placement

The MiCard's ultra-thin design (as thin as two credit cards) allows for versatile placement. Consider placing it in:

- Wallet credit card slots
- Phone cases
- Handbags or purses
- Luggage tag holders
- Passport books

MiCard, Keep an Eye on Your Valuables



Image: Examples of how the MiLi MiCard can be discreetly placed in various personal items due to its slim design.

MAINTENANCE

1. Charging

Recharge your MiCard wirelessly when the battery level is low. The Find My app will show the battery status of your MiCard. Regular charging ensures continuous tracking functionality. While the battery is designed for a 5-year lifespan, individual charge cycles last 4-6 months depending on usage.

2. Cleaning

Wipe the MiCard with a soft, dry, lint-free cloth. Avoid using abrasive cleaners, solvents, or aerosol sprays that may damage the device's surface or internal components.

3. Water Resistance

The MiCard has an IP65 waterproof rating, meaning it is resistant to dust and low-pressure water jets from any direction. It is not designed for submersion. Ensure the device is dry before charging.

TROUBLESHOOTING

- Device not connecting to Find My:** Ensure Bluetooth is enabled on your iOS device. Make sure the MiCard is charged. Try restarting your iOS device and the MiCard (if applicable, by pressing the power button if it has one, or allowing it to fully discharge and recharge).
- Sound not playing:** Check the volume settings on your iOS device. Ensure the MiCard is within Bluetooth range.
- Battery draining quickly:** Ensure the MiCard is fully charged. If the issue persists, contact MiLi customer support.
- Physical damage:** The MiCard is made with high-strength materials but is not indestructible. Avoid bending or dropping the card, especially on hard surfaces, as this may cause damage.
- Not working with Android:** The MiLi MiCard is MFi Certified and works exclusively with Apple's Find My network on iOS devices. Android devices are not supported for tracking, only for reading NFC contact information in Lost Mode.

For further assistance, please refer to the official MiLi support channels.

SPECIFICATIONS

Feature	Detail
Model	MiCard
Dimensions	5 x 3.46 x 0.55 inches (approximate)
Item Weight	2.08 ounces
Battery Type	1 Lithium Polymer battery (included)
Battery Life (per charge)	4-6 months
Overall Battery Lifespan	Up to 5 years
Charging	Wireless Rechargeable
Connectivity	Bluetooth, NFC
Compatibility	Apple Find My (iOS Only)
Water Resistance	IP65 Rated
Material	Plastic

WARRANTY AND SUPPORT

For warranty information and technical support, please visit the official MiLi website or contact their customer service directly. Keep your purchase receipt as proof of purchase.