

MP17

Generic 68-Inch Animated Butler with Light-Up Eyes (Model MP17) Instruction Manual

Model: MP17

1. PRODUCT OVERVIEW

The Generic 68-Inch Animated Butler with Light-Up Eyes is a life-size Halloween prop designed to add a spooky and interactive element to your haunted house or party display. This animated figure features a butler with a raven on his shoulder, both designed for lifelike animation and sound.

Key Features:

- **Lifelike Animation:** Features a life-size butler and an animated raven, both designed to add a spooky touch to any setting.
- **Interactive Experience:** Equipped with a motion sensor that triggers glowing candelabra flames, red-eyed raven, and spooky dialogue between the butler and raven.
- **Authentic Detail:** Exquisitely dressed in a velvet jacket and a ruffled shirt, the butler exhibits a realistically aged appearance with detailed facial expressions and hands.
- **Entertaining Dialogue:** Engages guests with a recitation of Edgar Allan Poe's "The Raven," complemented by the raven's eerie interruptions.
- **Versatile Decoration:** Ideal for Halloween parties, haunted houses, or any event requiring a creepy ambiance to captivate and entertain guests.



Figure 1: The 68-Inch Animated Butler prop in a haunted house setting.

2. SAFETY INFORMATION

Please read and follow all safety instructions carefully to prevent injury or damage to the product.

- For outdoor use only.
- Unplug during inclement weather.
- Do not allow children to play on or near the display.
- Keep away from flammable materials.
- Always supervise children when operating.
- Do not expose to rain or snow.
- Batteries should be replaced by an adult.
- Always follow assembly instructions carefully.

3. PACKAGE CONTENTS

Ensure all components are present before beginning assembly:

- Metal Stand Base
- Numbered/Lettered Support Poles (various lengths)
- Butler Shoes (2)
- Pants garment
- Waist Ring
- Butler Top Piece (with head, torso, arms, and attached ruffled shirt/velvet jacket)
- Candelabra

- Animated Raven
- Assembly Instructions

4. SETUP AND ASSEMBLY

Follow these steps to assemble your Animated Butler. No tools are required.

Assembly Video:

Your browser does not support the video tag.

Video 1: Detailed assembly instructions for the 68-Inch Animated Butler.

1. **Assemble the Base:** Connect the initial support poles to the metal stand base. The poles are lettered and numbered for easy matching. Push the lock button on the stand and click the pole into place.
2. **Attach Shoes:** After the first two poles are in place, add one shoe to each side by sliding the pole into the shoe.
3. **Continue Pole Assembly:** Continue adding the remaining poles, ensuring you match the letters/numbers.
4. **Add Pants:** Once the pole assembly is complete, slide the pants garment onto the poles. For a more realistic effect, you may add stuffing to the pants.
5. **Install Waist Ring:** Secure the waist ring around the poles, locking it into place. Pull the pants up over the ring to create the butler's waist.
6. **Attach Top Piece:** Place the butler's top piece (torso, head, arms) onto the assembled poles, ensuring it locks securely. Pull the coat down and around the bottom, then fluff it out for a realistic appearance.
7. **Connect Candelabra:** The butler's arms are poseable. Move the right arm away from the body. Connect the candelabra's electronic wire to the coupler on the right arm. This connection allows the candelabra to light up. Hide the wires and pull the sleeve of the butler's arm down over the hand. The candelabra is held in place with a piece of Velcro. Stuffing the arms will also add a more realistic look.
8. **Attach Raven:** Place the animated raven onto the butler's left shoulder. Ensure the coat fabric does not obstruct the connection point. Connect the raven's electronic wire to the corresponding coupler on the butler's shoulder.



Figure 2: Close-up of the butler's detailed face.

5. OPERATING INSTRUCTIONS

The Animated Butler can be activated in two ways:

- **Motion Sensor Activation:** The prop is equipped with a motion sensor. When motion is detected, the candelabra flames will light up amber, the raven's eyes will light up red, and the butler and raven will engage in dialogue.
- **Manual Button Activation:** A manual activation button is located on the butler's left hand. Press this button to trigger the animation and dialogue.

The prop requires 3 AA batteries (not included) for operation. Ensure fresh batteries are installed correctly in the designated battery compartment.

6. MAINTENANCE

- **Cleaning:** Gently wipe the surface of the prop with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, disassemble the prop and store it in its original packaging or a protective container in a cool, dry place away from direct sunlight.
- **Battery Replacement:** Replace batteries when the animation or lights become dim or stop functioning. Always replace all batteries at the same time with new ones of the same type. Do not mix old and new batteries or different types of batteries.

7. TROUBLESHOOTING

- **Prop Not Activating:**
 - Ensure batteries are correctly installed and are fresh.
 - Check all electronic connections (candelabra, raven) to ensure they are securely plugged in.

- Verify the manual activation button is functioning.
- Ensure the motion sensor is not obstructed and is in an area where it can detect movement.
- **Lights or Sound Not Working:**
 - Check battery levels and replace if necessary.
 - Inspect all wiring for any visible damage or loose connections.

8. SPECIFICATIONS

Feature	Detail
Model Number	MP17
Product Dimensions (L x W x H)	0.1 x 0.1 x 68 inches
Item Weight	15 pounds
Frame Material	Metal
Material	Fabric, Plastic, Metal
Power Source	Battery Powered (3 AA batteries, not included)
Voltage	4.5 Volts
Light Color	Yellow (Candelabra)
Number of Light Sources	1 (Candelabra)
Theme	Halloween

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact the manufacturer directly. Retain your proof of purchase for any warranty claims.