Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Nokia /
- > Nokia 225 4G (2024) User Manual

Nokia 225 4G

Nokia 225 4G (2024) User Manual

Model: 225 4G (TA-1689)

1. Introduction

The Nokia 225 4G (2024) is a compact and durable mobile phone designed for essential communication and entertainment. It features 4G connectivity, a long-lasting battery, and a rear camera. This manual will guide you through its functions and features, ensuring you get the most out of your device.

2. PACKAGE CONTENTS

Verify that all items are present in your product package:

- Nokia 225 4G (2024) Handset
- Power Adapter
- USB Cable

3. DEVICE LAYOUT



Image: Front and back view of the Nokia 225 4G (2024) phone. The front shows the screen, earpiece, and physical keypad with numbers and function keys. The back shows the rear camera, flash, and Nokia branding.

The Nokia 225 4G (2024) features a 2.4-inch LCD display, a physical keypad for navigation and input, and a rear camera with a flash. The device has a durable polycarbonate shell. Key elements include:

- Display: 2.4-inch color screen.
- **Keypad:** Alphanumeric keys, navigation keys, call/end keys, and a central select button.
- Rear Camera: Located on the back with an accompanying flash.
- Earpiece/Speaker: Located at the top of the front panel.
- Charging Port: USB port for charging and data transfer.

• 3.5 mm Audio Jack: For connecting headphones.

4. SETUP

4.1. Battery Installation

- 1. Gently remove the back cover of the phone by prying it from the designated notch.
- 2. Insert the Lithium Ion battery into its compartment, ensuring the metal contacts align correctly with the phone's terminals.
- 3. Replace the back cover, pressing firmly until it clicks into place.

4.2. SIM Card Installation

The Nokia 225 4G (2024) supports Dual SIM functionality.

- 1. Remove the back cover and battery as described above.
- 2. Locate the SIM card slot(s). Insert your SIM card(s) into the designated slot(s) with the gold contacts facing down and the cut corner aligned.
- 3. Replace the battery and back cover.

4.3. Charging the Battery

- 1. Connect the USB cable to the phone's charging port.
- 2. Connect the other end of the USB cable to the power adapter.
- 3. Plug the power adapter into a wall outlet. The phone will display a charging indicator.
- 4. A full charge takes approximately 3 hours.

5. OPERATING INSTRUCTIONS

5.1. Power On/Off

- To power on, press and hold the Power/End Call button until the Nokia logo appears.
- To power off, press and hold the Power/End Call button, then select 'Power off' from the options.

5.2. Navigation

- Use the directional keys (up, down, left, right) to move through menu options.
- Press the central Select button to confirm a selection or open an application.
- Use the Back key (usually the right soft key) to return to the previous screen.

5.3. Making Calls

- 1. From the home screen, enter the phone number using the keypad.
- 2. Press the **Call button** (green key) to initiate the call.
- 3. To end a call, press the **End Call button** (red key).

5.4. Sending Messages

- 1. Go to Menu > Messages.
- 2. Select Create message or New message.
- 3. Enter the recipient's number or select from contacts.
- 4. Type your message using the keypad.
- 5. Select Send.

5.5. Camera Functionality

- Access the camera from the main menu.
- Frame your shot using the display.
- Press the **Select button** to capture a photo.

5.6. Music and Entertainment

- MP3 Player: Use the built-in MP3 player to listen to music stored on your device (requires expandable memory card, sold separately).
- FM Radio: Tune into FM radio stations. Headphones may be required as an antenna.
- Bluetooth: Connect Bluetooth speakers or earbuds for wireless audio.
- Games: Enjoy pre-installed games such as Snake.

5.7. Cloud Apps

The Cloud Apps portal provides access to various online content, including videos, news, and weather updates. Please note that this device does not support additional app downloads or Wi-Fi connectivity.

6. SPECIFICATIONS

Model Name	225 4G
Item Model Number	TA-1689
Operating System	S30+
CPU Model	A6-5200
CPU Speed	1 GHz
Screen Size	2.4 Inches
Resolution	240 x 320
Refresh Rate	60 Hz
RAM Memory Installed Size	64 MB
Memory Storage Capacity	64 MB (Expandable)
Battery Power Rating	1450 Milliamp Hours
Phone Talk Time	5 Hours
Charging Time	3 Hours
Product Dimensions	4.78 x 2.05 x 0.46 inches
Item Weight	3.14 ounces
Wireless Communication Technologies	Bluetooth, Cellular
Connectivity Technologies	Bluetooth, USB
Special Features	Basic Phone, Dual SIM, Expandable Memory
Audio Jack	3.5 mm
Form Factor	Bar

7. MAINTENANCE

- Cleaning: Use a soft, dry cloth to clean the phone's screen and body. Avoid using harsh chemicals or abrasive materials.
- Battery Care: To maximize battery lifespan, avoid exposing the phone to extreme temperatures. It is recommended to fully charge the device before its first use.
- Storage: When not in regular use, store your Nokia 225 4G (2024) in a cool, dry environment away from direct sunlight and moisture.

8. TROUBLESHOOTING

- **Phone not turning on:** Ensure the battery is correctly inserted and sufficiently charged. Try connecting the charger to see if the charging indicator appears.
- **No network signal:** Verify that your SIM card(s) are properly inserted. Confirm that your network service provider is a GSM carrier, as this product is exclusively compatible with GSM networks. It is not compatible with AT&T, Verizon, or their subsidiaries, and does not support Band 71 with T-Mobile.
- Battery draining quickly: Reduce screen brightness, close any unused applications running in the background, and limit the use of features like Bluetooth when not needed.
- **Unable to access internet/Cloud Apps:** Ensure you have an active data plan with your GSM carrier. Note that this device does not support Wi-Fi connectivity.

9. WARRANTY AND SUPPORT

For detailed warranty information, technical assistance, and customer support, please refer to the warranty card included with your purchase or visit the official Nokia support website. Keep your proof of purchase for any warranty claims.

Related Documents - 225 4G

NOKIA	
Nokia 225 4G (2024) User Guide	Nokia 225 4G (2024) User Guide: Setup, Features, and Safety Information Comprehensive user guide for the Nokia 225 4G (2024) phone, covering setup, calls, messages, personalization, camera, clock, calendar, calculator, data management, and important safety and product information.
1919 (2021-45-21 on 50)	
NOKIA	
Nokia 225 4G (2024) Gebruik ershandleiding	Nokia 225 4G (2024) Gebruikershandleiding De officiële gebruikershandleiding voor de Nokia 225 4G (2024) telefoon, met instructies voor installatie, gebruik, functies, veiligheid en onderhoud.

r	
NOKIA	
	Nokia 225 4G (2024) User Guide
Nokia 225 4G (2024) User Guide	User guide for the Nokia 225 4G (2024) mobile phone, covering setup, calls, messages, personalization, camera, clock, calendar, calculator, data erasure, safety information, and product
	care.
1996 SNS-11-10 ex-68	
NOKIA	
	Nokia 225 4G (2024) User Guide
Nokia 225 4G (2024) User Guide	Comprehensive user guide for the Nokia 225 4G (2024) feature phone, covering setup, calls,
	messages, personalization, camera, clock, calendar, calculator, safety information, and device care.
1930 में 2015 की देश कर प्रंत	
NOKIA	
	Nokia 225 4G (2024) User Guide
Nokia 225 4G (2024) User Guide	User guide for the Nokia 225 4G (2024) phone, covering setup, calls, messages, personalization,
	camera, clock, calendar, calculator, and safety information.
team 2012 6-6-30 ton-Gri	
NOKIA	
Nokia 225 4G (2024) Používateľská príručka	N. I.: 005 40 (0004) II. 0 11
	Nokia 225 4G (2024) User Guide Official user guide for the Nokia 225 4G (2024) feature phone, covering setup, features, calls,
typinen (2015-60-82 al-54	messages, customization, camera, tools, and safety information.