

- Manuals.plus /
- › WIN STELLAR /
- › WIN STELLAR Interior Door Instruction Manual

WIN STELLAR 28" x 80" Left Hand 5-Panel Solid Core & Black Hinges

WIN STELLAR Interior Door Instruction Manual

Model: 28" x 80" Left Hand 5-Panel Solid Core & Black Hinges
Brand: WIN STELLAR

INTRODUCTION

This manual provides detailed instructions for the assembly, installation, operation, and maintenance of your WIN STELLAR 28 x 80 5-Panel Paintable Interior Door Slab with Ready-to-Assemble Black Hinge Jamb Kit. Please read all instructions carefully before beginning installation to ensure proper function and longevity of your door.



Image: A WIN STELLAR 5-panel interior door, painted white, installed in a modern kitchen, demonstrating its aesthetic integration.

PRODUCT SPECIFICATIONS

Specification	Detail
Product Dimensions	1.4 x 28 x 80 inches
Door Panel Width	28 inches
Door Panel Height	80 inches
Door Panel Thickness	1 3/8 inches

Specification	Detail
Fits Rough Openings	30" x 82"-82.5"
Material	Pine Wood Jamb, CARB P2 Certified Solid MDF
Included Components	Prehung Jamb Kit (Assembly Required), Solid Core Prebuilt Door Slab
Item Package Quantity	2 (Door Panel, Jamb Kit)



Image: A size guide table illustrating various door dimensions and their corresponding rough opening requirements.

COMPONENTS AND PACKAGING

Your WIN STELLAR interior door system arrives in two separate packages: one containing the door slab and the other containing the ready-to-assemble prehung jamb kit. Please verify all components are present and undamaged upon receipt.

Package Contents:

- Solid Core MDF Door Panel (without pre-drilled borehole for hardware)
- Ready-to-Assemble Jamb Kit (Header, Hinge Jamb, Strike Jamb)
- 3 Black Hinges (pre-screwed onto the hinge jamb)
- Hinge Screws



Image: An exploded view showing the individual components of the door kit: the door slab, the three jamb pieces, and the accompanying screws.

READY-TO-ASSEMBLE DOOR KIT

Header

Hinge Jamb

Door

Strike Jamb

INCLUDED HARDWARE

Hinges



Hinge Screws



Image: A diagram illustrating the ready-to-assemble door kit with labels for the header, hinge jamb, door, strike jamb, and included hardware (hinges and screws).

SETUP AND INSTALLATION


The WIN STELLAR door system is designed for straightforward assembly. The jamb kit requires assembly, and the door panel does not come with pre-drilled boreholes for door hardware, allowing for custom placement. A nailer and saw will be required for installation.

Installation Steps:

1. **Prepare the Rough Opening:** Ensure your rough opening dimensions are appropriate for the door size (30" x 82"-

82.5" for this model). The door slab and prehung jamb can be trimmed 0.5 inches from both the top and bottom edges if minor adjustments are needed.

- 2. **Assemble the Jamb Kit:** Connect the header to the hinge jamb and strike jamb. The hinges are already screwed onto one side of the hinge jamb, simplifying this step.
- 3. **Attach Door to Jamb:** The other side of the hinges is designed for easy screw attachment to the door panel. Align the door panel with the pre-attached hinges on the jamb and secure it using the provided screws. Note that the door panel does not have a pre-drilled borehole for the door handle/lock, allowing you to choose your desired hardware placement.
- 4. **Install Assembled Unit:** Carefully place the assembled door and jamb unit into the rough opening. Use shims to ensure the unit is plumb, level, and square within the opening.
- 5. **Secure the Jamb:** Once aligned, secure the jamb to the rough framing using appropriate fasteners (e.g., nails from a nailer).
- 6. **Finish Trim and Hardware:** Install any necessary trim around the door frame. Drill the borehole for your chosen door handle and lock, then install the hardware according to its manufacturer's instructions.



Size Guide

Door Size	Fit Opening width (A : Without Jamb)	Fit Opening Height (B : Without Jamb)
24" x 80"	26"	82.5"
28" x 80"	30"	82.5"
30" x 80"	32"	82.5"
32" x 80"	34"	82.5"
36" x 80"	38"	82.5"
24" x 96"	26"	98.5"
28" x 96"	30"	98.5"
30" x 96"	32"	98.5"

Image: A visual guide demonstrating the assembly of the door kit, highlighting the connection points for the header, hinge jamb, and door.

PRODUCT FEATURES

The WIN STELLAR interior door is engineered with quality materials and thoughtful design for enhanced performance and aesthetic appeal.

Solid Core MDF Construction:

The heavy-duty door slab is constructed from solid core MDF (Medium-Density Fiberboard), providing superior durability, sound dampening, and privacy compared to hollow core doors. This material is safe and sturdy, contributing to a quieter indoor environment.



Image: A comparison illustrating how solid core door construction offers significantly more sound dampening than hollow core designs, contributing to a quieter space.

Paintable Primed Finish:

The door features a prefinished surface with a three-layer painting technique, including a water-resistant coating, a primed layer for perfection, and an extra finish for enhanced smoothness and durability. This primed surface is ready for custom painting, allowing you to match your interior decor.

70% More Sound-Dampering Than Hollow Core



Ours



Solid Core



Others

Hollow Core



Image: A diagram detailing the three-layer painting technique applied to the door's prefinished surface, including a water-resistant coating, primer, and a final smooth finish.

PRE-ASSEMBLED PANELS

Removing the hassle of
lengthy **alignment** and **setup processes**



Image: Examples of interior doors custom-painted with various designs, showcasing the versatility of the paintable surface to express personal style.

Durable and Environmentally Friendly:

The door's MDF surface is designed to be sturdy, scratch-resistant, and water-resistant. It is also CARB P2 Certified, indicating compliance with strict toxic emission standards, making it a safe and environmentally friendly choice for your home.

Custom-Painted Doors:

Express Your Style



Image: A graphic illustrating the durable MDF surface, emphasizing its ready-to-use pre-finished state, hardness compared to natural wood, scratch resistance, water resistance, and CARB2 compliance for safety and environmental friendliness.

OPERATING INSTRUCTIONS

Once installed, your WIN STELLAR interior door operates like any standard hinged door. Ensure that the door swings freely and closes securely within the jamb. The solid core construction provides a substantial feel and contributes to sound reduction when closed.

- To open, turn the door handle and pull or push the door in the direction of its swing.
- To close, gently push the door until it latches securely into the strike plate on the jamb.
- Avoid slamming the door to prevent damage to the door, frame, or hardware.

CARE AND MAINTENANCE

Proper care and maintenance will help preserve the appearance and functionality of your WIN STELLAR interior door.

Cleaning:

- For general cleaning, wipe the door surface with a soft, damp cloth.
- For stubborn marks, use a mild, non-abrasive household cleaner. Avoid harsh chemicals or abrasive scrubbers, which can damage the finish.
- Dry the surface immediately after cleaning to prevent water spots.

Painting:

The door comes with a primed finish, ready for painting. Use high-quality interior paint suitable for MDF surfaces. Follow the paint manufacturer's instructions for application, drying times, and recoating.

Hardware:

Periodically check the tightness of all screws on the hinges and door hardware. Tighten as necessary to ensure smooth operation and prevent sagging.

TROUBLESHOOTING

If you encounter issues with your door, consider the following common solutions:

- **Door Does Not Close Properly:**

- Check if the door frame is plumb and square. Adjust shims if needed.
- Ensure hinges are securely fastened to both the door and the jamb.
- Verify the strike plate alignment with the door latch. Adjust the strike plate if necessary.

- **Door Squeaks:**

- Apply a small amount of lubricant (e.g., silicone spray or petroleum jelly) to the hinge pins.

- **Paint Adhesion Issues:**

- Ensure the door surface was clean and dry before painting.
- Use a high-quality primer if the existing primed surface was compromised or if you are using a paint type that requires additional priming.

WARRANTY AND SUPPORT

For information regarding product warranty, returns, or technical support, please refer to the WIN STELLAR official website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

WIN STELLAR Customer Service: Please visit the [WIN STELLAR Store on Amazon](#) for contact information and further assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page
<https://manuals.plus/asin/B0DG8CW3Y3>
More documents and user manuals: <https://manuals.plus/>