

THINK 30 097AAC

THINK 30 6-Piece Extendable Dining Table Set

Model: 097AAC

[Safety](#) [Overview](#) [Setup](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty](#) [Support](#)

1. SAFETY INFORMATION

Please read and understand all safety instructions before assembling or using this product. Failure to follow these instructions may result in injury or damage to the product.

- **Weight Limits:** Do not exceed the weight limit of **350 pounds (158 kg)** for the dining table. Each dining chair and the bench can support up to **250 pounds (113 kg)**.
- **Assembly:** Always follow the assembly instructions carefully to prevent injury. Ensure all fasteners are securely tightened before use.
- **Sharp Edges:** Be cautious of sharp edges during handling and assembly.
- **Heat Sources:** Keep the product away from direct heat sources to prevent damage to the wood and upholstery.
- **Stability:** Do not stand on the table, chairs, or bench. Ensure the product is placed on a level surface.

2. PRODUCT OVERVIEW

The THINK 30 6-Piece Extendable Dining Table Set provides a versatile and elegant dining solution for your home. This set includes one extendable dining table, four upholstered side chairs, and one upholstered bench.

Key Features:

- **Extendable Table:** The dining table features an 18-inch removable leaf, allowing it to extend from 60 inches to 78 inches in length.
- **Durable Construction:** The table is constructed with acacia wood legs, and the chairs and bench feature rubberwood frames, ensuring stability and longevity.
- **Comfortable Seating:** Chairs and bench are upholstered with linen fabric and filled with soft foam for a comfortable dining experience.
- **Versatile Bench:** The bench can also serve as a console table or storage area in other parts of your home.



Image: The complete 6-piece dining set, including the extendable table, four chairs, and a bench, arranged in a dining room.

Component Details:

Dining Table

WOODEN DINING TABLE



Smooth Corners



Birch Veneer
Showing Natural Grain



Sturdy Acacia Wood
Frame

Image: Detailed view of the dining table highlighting smooth corners, natural birch veneer grain, and the sturdy acacia wood frame.

- Material: Acacia wood legs, Birch veneer top
- Features: Smooth corners, natural grain finish

Dining Chairs

ELEGANT DINING CHAIRS



High Back Design



Comfortable
Breathable Fabric



Sturdy Rubberwood
Frame



High Quality
Soft Sponge



Non-Slip
Protection

Image: Detailed view of a dining chair, emphasizing its high back design, breathable linen fabric, sturdy rubberwood frame, soft foam cushioning, and non-slip leg protection.

- Material: Rubberwood frame, Linen fabric, Soft foam cushion
- Features: High back design, non-slip protection on legs

Dining Bench

ELEGANT DINING CHAIRS



Image: The upholstered dining bench, illustrating its versatility for use in dining areas, bedrooms, entryways, or under stairs.

- Material: Rubberwood frame, Linen fabric, Soft foam cushion
- Features: Multi-functional design for various home uses

3. SETUP AND ASSEMBLY

The THINK 30 Dining Table Set requires assembly. Detailed installation instructions are included in the product packaging. Please follow these instructions step-by-step for a smooth and correct assembly process.

Before You Begin:

- **Unpack:** Carefully unpack all components and hardware. Lay them out on a clean, soft surface (e.g., a blanket or carpet) to prevent scratches.
- **Identify Parts:** Refer to the parts list in the included manual to identify all components.
- **Tools:** Ensure you have any necessary tools as specified in the assembly guide.
- **Assistance:** Assembly may be easier with two people, especially for the dining table.

Assembly Tips:

- Do not fully tighten all screws until the entire unit is assembled and stable.
- Ensure all parts are correctly oriented before fastening.
- If you encounter any difficulties, refer to the detailed instructions provided or contact customer support.

4. OPERATING INSTRUCTIONS

Extending the Dining Table:

The dining table is designed with a removable 18-inch leaf to adjust its length from 60 inches to 78 inches, accommodating more guests.

1. **To Extend:** Gently pull the two halves of the table apart. Insert the 18-inch leaf into the center opening. Push the table halves back together until the leaf is securely in place.
2. **To Retract:** Gently pull the two halves of the table apart. Carefully lift and remove the 18-inch leaf. Push the table halves back together until they meet.

EXTENDED DINING TABLE



Removable Dining Leaf



60"

← Extended →



78"

Image: Visual representation of the dining table in its compact 60-inch configuration and its extended 78-inch configuration with the leaf inserted.

Seating Capacity:

The 60-inch table comfortably seats 4-6 guests. When extended to 78 inches with the leaf, the table can comfortably seat 6-8 guests.

5. MAINTENANCE AND CARE

Proper care will help maintain the appearance and longevity of your dining set.

- **Cleaning Wood Surfaces:** Wipe wood surfaces with a dry, soft cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, which can damage the finish.
- **Cleaning Upholstery:** For upholstered chairs and bench, spot clean with a mild fabric cleaner as needed. Test the cleaner on an inconspicuous area first. Do not saturate the fabric.
- **Spills:** Blot spills immediately with a clean, dry cloth.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading and wood discoloration.
- **Tighten Fasteners:** Periodically check and tighten all screws and bolts to ensure the stability of the furniture.

6. TROUBLESHOOTING

If you encounter any issues with your dining set, please refer to the following common solutions:

- **Wobbling Table/Chairs:** Ensure all assembly screws and bolts are securely tightened. Check that the furniture is placed on a level surface. Adjust any leveling feet if present.
- **Difficulty Extending/Retracting Table Leaf:** Ensure the table halves are properly aligned and free of obstructions. The leaf should slide smoothly into place. Do not force it.
- **Scratches/Dents:** For minor scratches on wood, furniture repair markers or polishes can be used. For significant damage, professional repair may be required.
- **Stains on Upholstery:** Refer to the cleaning instructions in the Maintenance section. For stubborn stains, consult a professional upholstery cleaner.

If these steps do not resolve your issue, please contact THINK 30 customer support for further assistance.

7. SPECIFICATIONS



Image: Comprehensive diagram illustrating the dimensions of the dining table, chairs, and bench, including height, width, and depth measurements.

Feature	Detail
Model Number	097AAC
Product Dimensions (Table)	60-78 inches (L) x 36 inches (W) x 30.3 inches (H)
Table Leaf Size	18 inches
Table Material	Acacia wood legs, Birch veneer top
Table Weight Capacity	350 pounds (158 kg)
Chair Dimensions	Approx. 19 inches (W) x 17.7 inches (D) x 39 inches (H)
Chair Material	Rubberwood frame, Linen fabric, Soft foam cushion
Chair Weight Capacity (Each)	250 pounds (113 kg)
Bench Dimensions	Approx. 38 inches (L) x 16 inches (W) x 19 inches (H)
Bench Material	Rubberwood frame, Linen fabric, Soft foam cushion
Bench Weight Capacity	250 pounds (113 kg)
Total Item Weight	140.9 pounds (63.9 kg)
Assembly Required	Yes
Product Care Instructions	Wipe with Dry Cloth

8. WARRANTY INFORMATION

Specific warranty details for the THINK 30 6-Piece Extendable Dining Table Set are typically provided with your purchase documentation. Please refer to the warranty card or contact the manufacturer directly for information regarding warranty coverage, terms, and conditions.

9. CUSTOMER SUPPORT

For any questions, missing parts, or assistance with assembly or product use, please contact THINK 30 customer support. Have your model number (097AAC) and purchase information ready when contacting support. Contact information can usually be found on the product packaging, the included instruction manual, or the official THINK 30 website.