

[Manuals.plus](#) /

› [FurnitureR](#) /

› FurnitureR Mid-Back Velvet Upholstered Home Office Desk Chair Instruction Manual (Model DBLCACH)

## FurnitureR DBLCACH

# FurnitureR Mid-Back Velvet Upholstered Home Office Desk Chair

Model: DBLCACH

### IMPORTANT SAFETY INFORMATION

Ensure the chair is used on a stable, level surface. Adjust the height to suit your specific needs for optimal comfort and posture.

Always check all connections and fasteners are secure before use. Do not stand on the chair. Avoid using abrasive cleaners on the velvet upholstery.

## PACKAGE CONTENTS

Before assembly, please verify that all components are present and undamaged. Refer to the parts list below.



**Figure 1:** All components included in the package. Ensure all parts are accounted for before proceeding with assembly.

- Chair Seat and Backrest Assembly (1)
- Gas Lift Cylinder (1)
- Star Base (1)
- Casters (5)
- Hardware Pack (Screws, Allen Wrench)

## ASSEMBLY INSTRUCTIONS

---

The chair requires assembly. Follow these steps carefully. It is recommended to assemble on a soft, clean surface to prevent damage.

1. **Attach Casters to Base:** Insert each of the five casters into the holes at the end of each leg of the star base. Push firmly until they click into place.



**Figure 2:** Securely insert casters into the base.

2. **Insert Gas Lift:** Place the gas lift cylinder into the center hole of the assembled star base.



**Figure 3:** Position the gas lift cylinder correctly.

3. **Attach Mechanism to Seat:** Align the seat mechanism with the pre-drilled holes on the underside of the chair seat. Secure it using the provided screws and Allen wrench. Ensure the lever is facing the front of the seat.



**Figure 4:** Fasten the mechanism to the seat bottom.

4. **Connect Seat to Gas Lift:** Carefully place the assembled seat onto the gas lift cylinder, ensuring it is centered and fully seated.



**Figure 5:** Lower the seat onto the gas lift post.

5. **Final Check:** Once assembled, sit on the chair to ensure the gas lift engages properly and all connections are stable.



**Figure 6:** Overview of the assembly process.

## **OPERATING INSTRUCTIONS**

---

### **Adjusting Chair Height**

To adjust the chair's height, locate the lever on the right side beneath the seat.

- To raise the seat: Lift the lever while taking your weight off the seat. The seat will rise automatically.
- To lower the seat: Lift the lever while remaining seated. The seat will lower under your weight.



**Figure 7:** The chair features adjustable height and 360-degree swivel for optimal positioning.

### **360-Degree Swivel and Rolling Wheels**

The chair is designed with a 360-degree swivel function, allowing for easy rotation without moving the base. The dual casters provide smooth rolling on various floor types, enabling effortless movement around your workspace.



Dual caster wheels smoothly roll over all floor types



Figure 8: Dual casters ensure smooth and quiet movement across different floor surfaces.

### Adjustable Tilt Function

The chair offers a 125° adjustable tilt function. To adjust the recline angle:

- Locate the tilt tension knob and lever beneath the seat.
- To lock the chair in an upright position, push the lever inwards.
- To allow tilting, pull the lever outwards.
- To adjust the tension of the tilt, turn the knob: turn clockwise to tighten (less recline effort) or counter-clockwise to loosen (more recline effort).



Figure 9: Adjusting the chair's tilt and tension for personalized comfort.

## CARE AND MAINTENANCE

- **Upholstery Cleaning:** For velvet upholstery, gently blot spills immediately with a clean, dry cloth. For general cleaning, use a soft brush or vacuum with an upholstery attachment to remove dust and debris. For stubborn stains, consult a professional upholstery cleaner or use a velvet-safe cleaning product, testing on an inconspicuous area first.
- **Frame and Base:** Wipe metal parts with a soft, damp cloth. Avoid harsh chemicals.
- **Casters:** Periodically check casters for hair or debris that may hinder smooth rolling. Clean as needed.
- **Fasteners:** Regularly check all screws and bolts to ensure they are tight. Re-tighten if necessary to maintain stability.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Chair does not adjust height	Gas lift not engaged or faulty.	Ensure the height adjustment lever is fully pulled. If the issue persists, the gas lift may need replacement.
Chair wobbles	Loose screws or uneven floor.	Check and tighten all assembly screws. Ensure the chair is on a flat, level surface.
Casters do not roll smoothly	Debris caught in casters or damaged casters.	Remove any hair or debris from the caster wheels. If damaged, casters may need replacement.
Chair makes noise	Loose connections or friction between parts.	Tighten all screws. Apply a small amount of silicone lubricant to moving parts if necessary, avoiding upholstery.

## SPECIFICATIONS

Feature	Detail
Brand	FurnitureR

<b>Feature</b>	<b>Detail</b>
Model Name	Desk Chair
Item Model Number	DBLCACH
Color	Dark Blue
Material	Velvet (Upholstery), Foam (Fill)
Product Dimensions (D x W x H)	22"D x 22.4"W x 33.5"H
Item Weight	18.1 pounds
Back Style	Tufted Back
Special Features	Ergonomic, Rolling, Adjustable Height, 360-degree Swivel, 125-degree Adjustable Tilt
Recommended Uses	Studying, Working, Doing Makeup, Relaxing, Home Office, Bedroom, Vanity Room
UPC	755752485246

# DIMENSIONS



Figure 10: Key dimensions of the chair for reference.

## WARRANTY AND SUPPORT

For warranty information or product support, please contact FurnitureR customer service directly. Keep your purchase receipt for any warranty claims.

Visit the official FurnitureR store for more information: [FurnitureR Store](#)