

[Manuals.plus](#) /

› [TOZO](#) /

› TOZO Hybrid Active Noise Cancelling Wireless Earbuds User Manual

TOZO NC9

TOZO Hybrid Active Noise Cancelling Wireless Earbuds

MODEL: NC9

User Manual

Introduction

This manual provides comprehensive instructions for the TOZO NC9 Hybrid Active Noise Cancelling Wireless Earbuds. These earbuds are designed to deliver a superior audio experience with advanced noise cancellation, clear call quality, and extended playtime. Please read this manual thoroughly to ensure proper use and maintenance of your device.



Image: The TOZO NC9 Red Earbuds are shown inside their open charging case, which features a digital LED display indicating battery levels. One earbud is slightly elevated, showcasing its design.

What's in the Box

The TOZO NC9 package includes the following components:

- TOZO 2024 Hybrid Active Noise Cancelling Wireless Earbuds
- Charging Case
- Eartips (multiple sizes for optimal fit)
- USB-C (A to C) cable (20cm)
- User Manual

Setup Guide

1. Initial Charging

Before first use, fully charge the earbuds and the charging case. Connect the provided USB-C cable to the charging port on the case and a power source. The LED display on the case will indicate the charging status.

SMART DIGITAL DISPLAY

Keep precise track of your battery status. Charge at the right time and say goodbye to low-battery anxiety.



Image: A close-up of the TOZO NC9 charging case's smart digital display, showing "100%" battery level, indicating a full charge.

2. Pairing with Your Device

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for "TOZO NC9" in the list of available Bluetooth devices and select it to connect.
4. Once connected, a voice prompt will confirm successful pairing.

The earbuds utilize Bluetooth 5.3 technology for stable and efficient connection.

3. Optimal Fit

Select the eartip size that provides the most comfortable and secure fit for your ears. A proper seal is crucial for effective noise cancellation and sound quality.

Operating Instructions

Touch Controls

Action	Left Earbud	Right Earbud
Play/Pause	Single Tap	Single Tap
Next Track	Double Tap	Double Tap
Previous Track	Triple Tap	Triple Tap
Answer/End Call	Single Tap	Single Tap
Reject Call	Press and Hold (2s)	Press and Hold (2s)
Activate Voice Assistant	Press and Hold (2s)	Press and Hold (2s)
Switch ANC/Transparency Mode	Press and Hold (2s)	Press and Hold (2s)

Noise Control Modes

The TOZO NC9 offers Hybrid Active Noise Cancelling (ANC) and Transparent Mode:

- **Hybrid Active Noise Cancelling:** Reduces external noise by up to 45dB, ideal for immersive listening in noisy environments.




Image: A man is shown wearing the TOZO NC9 earbuds on an airplane, illustrating the effectiveness of the 45dB advanced noise cancellation feature.

- **Transparent Mode:** Allows you to hear your surroundings clearly without removing the earbuds, enhancing awareness and safety.

TOZO App Features

Enhance your experience by downloading the TOZO app. The app provides access to:

- 32 Preset EQ Modes for customized sound profiles.
- An "EQ Zone" to share and discover personalized EQ settings from other users.
- Additional features for controlling noise cancellation and other settings.

TOZO APP

The TOZO app has 32 preset EQs and access to over 2,000 personalized EQs shared by global audiophiles.

32

Preset EQ Modes

100+

White Noise Tracks

2000+

User-Shared EQs



Image: Screenshots of the TOZO app interface, highlighting the 32 preset EQ modes, over 100 white noise tracks, and more than 2000 user-shared EQs available for customization.

Maintenance and Care

Cleaning

Regularly clean your earbuds and charging case with a soft, dry, lint-free cloth. Remove eartips and clean them with mild soap and water, then dry thoroughly before reattaching.

Water Resistance (IPX8)

The TOZO NC9 earbuds are IPX8 waterproof, meaning they can withstand submersion in water up to 1 meter for 30 minutes. This makes them suitable for workouts and light rain. However, the charging case is not waterproof. Do not expose the charging case to water.

Storage

Store the earbuds in their charging case when not in use to protect them and ensure they remain charged.

Troubleshooting

- **Earbuds not pairing:** Ensure both earbuds are in the charging case, then open the lid. Check your device's Bluetooth settings and try re-pairing.
- **No sound from one earbud:** Place both earbuds back in the case, close the lid, wait a few seconds, then open it again. This often re-syncs them.
- **Poor sound quality:** Ensure eartips provide a good seal. Clean any debris from the earbud nozzles. Check audio source quality.
- **Charging issues:** Verify the USB-C cable is securely connected to both the case and the power source. Clean the charging contacts on the earbuds and inside the case.
- **Low latency issues (gaming/video):** Ensure your device supports Bluetooth 5.3 and that there are no significant obstacles between your device and the earbuds.

Specifications

Feature	Detail
Model Name	NC9
Noise Control	Hybrid Active Noise Cancellation (up to 45dB)
Microphones	6 Mics with ENC Clear Call Technology
Bluetooth Version	5.3
Wireless Range	Up to 15 meters (49 feet)
Water Resistance	IPX8 (Earbuds only)
Total Playtime (with case)	Up to 59 hours (ANC off) / 42 hours (ANC on)
Earbud Playtime (single charge)	14 hours (ANC off) / 10 hours (ANC on)
Charging Time	1.5 hours (earbuds and case)
Audio Driver Size	10mm (OrigX Acoustic 2.0)
Control Type	Touch Control / APP
Charging Case Battery Capacity	500 mAh

Warranty and Support

TOZO products come with a standard manufacturer's warranty. For detailed warranty information, product support, or technical assistance, please visit the official TOZO website or contact their customer service. You can often find contact details and FAQs on the product packaging or the TOZO brand store online.

For the latest information and support, please visit:www.tozostore.com