Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DREO DR-HTF009S

DREO DR-HTF009S Tower Fan User Manual

Model: DR-HTF009S | Brand: DREO

Important Safety Instructions

Please read all instructions and warnings carefully before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always place the fan on a stable, flat, and level surface to avoid tipping.
- Do not operate the fan with a damaged cord or plug. If the cord or plug is damaged, contact DREO customer support for assistance.
- Keep the fan away from water or moist environments. Do not immerse the fan in water or other liquids.
- Ensure that fingers or other objects do not enter the fan grilles during operation.
- Unplug the fan from the power outlet when not in use, before cleaning, or before moving it.
- Do not block air openings or operate near curtains or other materials that may block airflow.
- This appliance is for household use only. Do not use outdoors.
- Supervise children when the fan is in use.

Package Contents

Verify that all items listed below are present and in good condition.

- 1 x DREO Tower Fan Unit
- 2 x Base Halves
- 1 x Remote Control (Battery included)
- 1 x User Manual
- 1 x Quick Start Guide



This image displays all the components included in the DREO Tower Fan package: the main tower fan unit, two base halves, a remote control, a quick start guide, and the user manual.

Setup

Follow these steps to assemble your DREO Tower Fan.

1. **Base Assembly:** Keep the two base halves in a crossed position. Insert the pegs on one half into the slots on the other half. Press down firmly to join the base halves together.
2. **Attach Base to Fan Body:** Run the power cord through the central hole of the assembled base. Align the four pegs on the fan body with the corresponding slots on the base. Rotate the base clockwise until it locks securely into place.
3. **Cord Management:** Thread the power cord through all rear cord keepers on the base to ensure it is neatly secured and does not interfere with the fan's stability.
4. **Remote Control Preparation:** Remove the battery protective film from the remote control before first use.

Your browser does not support the video tag.

Video demonstrating the assembly process of the DREO 42-inch Tower Fan, including attaching the base and managing the power cord.

Operating Instructions

Your DREO Tower Fan offers multiple ways to control its functions.

Control Panel


The intuitive touch control panel is located on the top of the fan unit.



A detailed view of the DREO Tower Fan's intuitive touch control panel located on the top of the unit.

Remote Control

Use the included remote control for convenient operation from a distance.



The DREO Tower Fan shown alongside its compact remote control for convenient operation.

App Control & Voice Control

Download the DREO app to control your fan via smartphone or integrate with voice assistants like Alexa and Google Assistant.




A smartphone screen displaying the DREO app interface, demonstrating remote control capabilities for the tower fan.

Modes and Speed Settings

The fan features 9 speed settings and 4 operating modes:


- **Normal Mode:** Provides a constant airflow at your selected speed.
- **Natural Mode:** Simulates natural breeze by cycling through various speeds.
- **Sleep Mode:** Operates at a low, quiet speed with the display dimmed for undisturbed sleep.
- **Auto Mode:** Adjusts fan speed automatically based on the ambient room temperature.



The fan's display indicating the selection of various operating modes, including Normal, Natural, Sleep, and Auto.

Oscillation

The fan offers 90° oscillation to distribute air widely. Oscillation angles can be adjusted via the DREO app.



The tower fan oscillating 90 degrees, showing its ability to distribute air across a broad area.

Timer

Set the fan to automatically turn off after 1 to 12 hours using the timer function.

Your browser does not support the video tag.

Video highlighting the quiet operation and smart functionalities, such as 9 speeds and multiple modes, of the DREO DC Tower Fan, ideal for bedrooms and home offices.

Maintenance

Regular cleaning ensures optimal performance and longevity of your fan.

Cleaning the Rear Grille and Impeller

1. Unplug the fan from the power outlet.
2. Remove the screw at the bottom of the rear grille.

3. Pull down the grille and carefully take it out.
4. Unscrew the lock at the bottom of the impeller.
5. Lift the impeller and take it out from the bottom.
6. Wash the grille and impeller with water and mild soap. Ensure they are completely dry before reassembly.
7. Reassemble the fan by aligning the shaft with the hole on the top of the fan cavity and pushing upwards. Align the slot on the bottom of the impeller with the motor shaft (ensure the lock thread faces outwards). Screw the impeller lock until tight.
8. Place the grille back from the bottom, lift it into place, and screw the grille until tight.



The removable rear grille and impeller of the DREO Tower Fan shown being cleaned under running water, highlighting easy maintenance.

General Cleaning

- Use a soft, dry cloth to wipe the exterior surfaces of the fan.
- Do not use abrasive cleaners or solvents as they may damage the surface.

Troubleshooting


If you encounter any issues, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Fan does not turn on	No power supply; Power cord not properly plugged in; Remote control battery depleted.	Check power outlet; Ensure power cord is securely plugged in; Replace remote control battery.
Weak airflow	Air inlet/outlet blocked; Fan grilles or impeller are dirty.	Ensure no obstructions; Clean the rear grille and impeller as per maintenance instructions.
Fan is noisy	Fan not on a level surface; Internal components are dirty.	Place fan on a stable, level surface; Clean the impeller and grilles.
Remote control not working	Battery depleted; Obstruction between remote and fan.	Replace remote control battery; Ensure clear line of sight to the fan's receiver.
App control issues	Wi-Fi connectivity issues; Incorrect app settings.	Check Wi-Fi connection; Refer to the DREO app's help section or online support.

Specifications

Technical details of your DREO Tower Fan.

Feature	Detail
Model Name	DR-HTF009S
Dimensions (D x W x H)	13"D x 13"W x 42"H
Weight	9.8 Pounds
Power Source	DC
Voltage	120.0V
Wattage	30 watts
Number of Speeds	9
Modes	Normal, Natural, Sleep, Auto
Oscillation	90 degrees
Noise Level	20 Decibels (minimum)
Air Flow Capacity	1397 Cubic Feet Per Minute
Speed	28 Feet Per Second (maximum)
Timer	12 hours
Control Method	App, Remote, Touch, Voice
Material	Plastic, Stainless Steel
Certifications	ETL, FCC, UL



A diagram illustrating the precise dimensions of the DREO Tower Fan, including its height, width, and depth.

Warranty and Support

DREO provides a warranty for this product. For detailed warranty information, please refer to the warranty card included in your package or visit the official DREO website. If you have any questions or require technical assistance, please contact DREO customer support.

- **Online Support:** Visit www.dreo.com/support
- **Email:** support@dreo.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DG8PNJDD

More documents and user manuals: **https://manuals.plus/**