**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**Yakry S15**

# Yakry Automatic Pet Feeder with Camera (Model S15) - User Manual

Comprehensive guide for setup, operation, and maintenance of your smart pet feeder.

## Product Overview

The Yakry Automatic Pet Feeder with Camera (Model S15) is designed to provide convenient and reliable feeding for your pets. Featuring an 8L capacity, HD 1080P camera with night vision, two-way audio, and smart app control, this feeder ensures your pets are fed on schedule and allows you to monitor them remotely. It supports both 2.4GHz and 5GHz Wi-Fi networks for seamless connectivity and includes dual power options for uninterrupted operation.




Image: The Yakry Automatic Pet Feeder (Model S15) in white, featuring an 8L food container, a clear food level window, and a camera. A small dog and a cat are shown next to the feeder, with a smartphone displaying a live feed of a dog, illustrating the camera and app control features.

## What's in the Box

Verify that all components are present before proceeding with setup:

- 1 x Pet feeder with camera
- 1 x Food Bowl
- 1 x Power Adapter
- 1 x Desiccant Bag
- 1 x User Guide (this manual)

## Specifications

| Feature | Detail |
|---|---|
| Model Number | S15 |
| Product Dimensions | 8.1 x 7.8 x 14.8 inches |
| Item Weight | 5.39 pounds |
| Capacity | 8L (approx. 33 cups) |
| Material | BPA-Free ABS Plastic |
| Camera | 1080P HD with 150° wide-angle view and infrared night vision |
| Audio | Two-Way Audio Communication (microphone and speaker) |
| Connectivity | Wi-Fi (2.4GHz and 5GHz support) |
| Power Source | AC Power Adapter (included), 3 x D alkaline batteries (backup, not included) |
| Recommended Kibble Size | 2-12mm (0.08-0.5 inches) |

## Setup Guide

### 1. Unpacking and Assembly

1. Carefully remove all components from the packaging.
2. Place the main feeder unit on a flat, stable surface.
3. Attach the food bowl to the designated slot at the base of the feeder. Ensure it clicks securely into place.
4. Open the lid of the food storage compartment. Insert the desiccant bag into its holder inside the lid to maintain food freshness.




Image: The pet feeder disassembled into its main unit, food bowl, and food storage lid, demonstrating its modular design for easy assembly and cleaning.

## 2. Power Connection

1. Connect the power adapter to the feeder's power input port.
2. Plug the power adapter into a standard wall outlet.
3. For backup power, open the battery compartment at the bottom of the feeder and insert three (3) D alkaline batteries (not included). This ensures uninterrupted feeding during power outages.




Image: Illustration of the feeder's dual power supply system, showing the USB power adapter plugged into a wall outlet and the battery compartment for D-cell batteries, highlighting continuous operation.

## 3. Filling the Food Tank

1. Ensure the feeder is clean and dry before adding food.
2. Pour dry pet food into the storage tank. The feeder has an 8L capacity, suitable for approximately 33 cups of dry food.
3. Close the lid securely to maintain food freshness and prevent spills. The lid features a strong locking mechanism.




Image: The pet feeder with a dog eating from its bowl, emphasizing its 8L capacity which can sustain a dog for 12 days or a cat for 32 days. A desiccant is also shown, indicating food freshness features.

## 4. App Installation and Wi-Fi Connection

1. Download the "Smart Life" app from your smartphone's app store (iOS or Android).
2. Register or log in to your Smart Life account.
3. Add the device: In the app, tap "+" to add a new device. Select "Small Home Appliance" then "Pet Feeder (Wi-Fi)".
4. Follow the on-screen instructions to connect the feeder to your Wi-Fi network. The feeder supports both 2.4GHz and 5GHz networks. Ensure your phone is connected to the same Wi-Fi network during setup.
5. Once connected, you can rename the device for easy identification.




Image: A smartphone displaying the "Smart Video Feeder" app interface, illustrating features like scheduling, manual feeding, recording, sharing, and various functions such as playback, gallery, night mode, and motion detection. This highlights the remote customization and control capabilities.

## Operating Instructions

### 1. Scheduling Feeds

- Open the "Smart Life" app and select your pet feeder.
- Navigate to the "Schedule" section.
- Tap "Add" to create a new feeding schedule.
- Set the desired feeding time, days of the week, and the number of portions per meal. The feeder allows up to 20 meals per day with adjustable portions.
- Save the schedule. The feeder will automatically dispense food at the programmed times.

## 2. Manual Feeding

- From the app's main feeder interface, tap the "Feed" button.
- Select the number of portions you wish to dispense immediately.
- Confirm to dispense food.

## 3. Using the Camera and Two-Way Audio

- **Live View:** In the app, access the live video feed to monitor your pet in real-time. The 1080p HD camera provides a 150° wide-angle view, and infrared night vision allows monitoring in low light conditions.
- **Two-Way Audio:** Tap the microphone icon in the app to speak to your pet. Tap the speaker icon to hear your pet.
- **Motion Detection:** Enable motion detection in the app settings to receive notifications when your pet approaches the feeder.
- **Video Recording:** The app allows for video recording of your pet's activities.




Image: A split image demonstrating the two-way audio feature. The top shows a person using a smartphone to speak, with a speech

bubble "Hey there, sweetie! Dinner's ready!". The bottom shows two cats near the feeder, with a speech bubble "Meow!", indicating the pet's response, fostering interaction.




Image: A person viewing a live camera feed of their cat on a smartphone, illustrating the ability to "Keep An Eye On Your Pets" with features like HD camera, motion detection, IR night vision, and a 120-degree wide angle view.

## Maintenance and Cleaning

Regular cleaning ensures the longevity and hygienic operation of your pet feeder.

1. **Disassembly:** Unplug the feeder from power. Remove the food bowl and the food storage tank. The feeder features a detachable design for thorough cleaning.
2. **Cleaning Components:** Wash the food bowl and food storage tank with mild soap and water. Rinse thoroughly and dry completely before reassembly. These parts are made from BPA-free materials.
3. **Main Unit:** Wipe the main unit with a damp cloth. Do not submerge the main unit in water.
4. **Desiccant Bag:** Replace the desiccant bag periodically (e.g., monthly) to ensure optimal food freshness.

5. **Food Dispenser Mechanism:** The feeder uses newly upgraded rubber blades to prevent clogs. If necessary, gently clean any food residue from the dispensing mechanism. Ensure kibble size is within the recommended 2-12mm range to prevent jamming.




Image: A person cleaning the detachable food container and bowl of the pet feeder under running water, emphasizing the "Detachable design for thorough clean" and highlighting that components are removable and washable.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Feeder not dispensing food. | Food tank empty; Food jammed; Power issue; Incorrect schedule. | Refill food tank. Check kibble size (2-12mm) and clear any jams. Ensure power adapter is connected and backup batteries are installed. Verify feeding schedule in the app. |

| | | |
|---|---|---|
| Cannot connect to Wi-Fi. | Incorrect Wi-Fi password; Feeder too far from router; Network interference; App issues. | Double-check Wi-Fi password. Move feeder closer to router. Ensure your router supports 2.4GHz/5GHz and try reconnecting. Restart feeder and app. |
| Camera not working or poor image quality. | Poor Wi-Fi signal; Lens obstruction; Low light. | Improve Wi-Fi signal strength. Clean camera lens. Ensure adequate lighting or rely on night vision. |
| Two-way audio not functioning. | Microphone/speaker muted in app; Volume too low; Network issues. | Check app settings for audio mute/volume. Ensure stable Wi-Fi connection. |
| Food not fresh. | Desiccant bag needs replacement; Lid not sealed properly. | Replace desiccant bag. Ensure the lid is securely closed and locked. |

## Warranty and Support

The Yakry Automatic Pet Feeder (Model S15) comes with a two-year warranty, ensuring peace of mind regarding product quality and performance.
For any after-sales service issues, technical support, or warranty claims, please contact Yakry customer support. You can typically reach the seller through the platform where you purchased the product.
**How to contact sellers on Amazon:**

1. Go to the product page on Amazon.
2. Look for "Sold by Yakry-US" (or the specific seller name) near the buy box.
3. Click on the seller's name.
4. On the seller's page, click "Ask a question" to send a message.

**24/7 Online Support is available.**

© 2024 Yakry. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0DG8SZKQZ**

More documents and user manuals: **https://manuals.plus/**