Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BOSHIRO 0090

BOSHIRO Farmhouse 10 Drawers Dresser User Manual

Model: 0090

Product Overview

The BOSHIRO Farmhouse 10 Drawers Dresser is a robust and stylish storage solution designed for bedrooms, living rooms, or hallways. This dresser features a light gray finish with traditional elements such as carved pilasters, bracket feet, and framed drawer fronts, complemented by antique brass metal drawer pulls. It provides extensive storage with a combination of large and generously sized drawers.



Image: The BOSHIRO Farmhouse 10 Drawers Dresser, showcasing its light gray finish and traditional design, positioned in a room setting.

Setup and Assembly

This dresser requires assembly. Detailed instructions and necessary tools are included in the product packaging to facilitate the process. For a smoother assembly experience, it is recommended to:

1. Review the entire instruction manual before beginning.
2. Identify and arrange all boards and accessories according to their numbered categories as indicated in the instructions.
3. Ensure all parts are present and undamaged before starting assembly.



Image: Technical drawing illustrating the overall dimensions of the dresser (59.05" W x 15.78" D x 31.78" H) and individual drawer sizes.

The dresser's unique bracket feet design contributes to its stability once assembled. Follow the provided steps carefully to ensure proper construction and durability.

Operating the Dresser

The BOSHIRO Farmhouse Dresser is designed for efficient storage and organization. It features 10 drawers in total: 6 large drawers and 4 smaller, generously sized drawers. These drawers are ideal for storing clothing, linens, accessories, and other household essentials.

- **Drawer Operation:** Gently pull and push the drawers using the metal handles. Ensure drawers are not overloaded to maintain smooth operation and prevent damage to the slides.
- **Weight Distribution:** Distribute weight evenly across the drawers to maintain the dresser's balance and stability. Avoid placing excessively heavy items in a single drawer.
- **Top Surface Use:** The top surface can be used for decorative items, lamps, or other light objects. Avoid placing hot

or wet items directly on the surface without protection.



Image: An overhead view of the dresser with several drawers pulled open, demonstrating its ample storage capacity for various items like clothes, snacks, and toys.

Maintenance and Care

To ensure the longevity and appearance of your BOSHIRO Farmhouse Dresser, follow these maintenance guidelines:

- **Cleaning:** Wipe the surface with a damp cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the wood.
- **Sunlight Exposure:** Avoid prolonged direct exposure to sunlight, which can cause fading or discoloration of the wood finish.
- **Humidity:** Maintain a stable room temperature and humidity level to prevent wood from warping or cracking.
- **Moving:** When moving the dresser, always lift it rather than dragging it to prevent damage to the legs and frame.

Remove all items from drawers before moving.



Image: Detailed close-up shots highlighting the vintage metal handles with an antique brass hue and the intricately carved pilasters, showcasing the craftsmanship.

Troubleshooting

If you encounter any issues with your dresser, please refer to the following common troubleshooting tips:

- **Wobbly Dresser:** Ensure all assembly screws and fasteners are tightened securely. Check that the dresser is placed on a level surface. Adjust leg levelers if applicable.
- **Drawer Not Sliding Smoothly:** Check for any obstructions in the drawer slides. Ensure the drawer is correctly aligned on its tracks. Verify that the drawer is not overloaded.
- **Missing or Damaged Parts:** Before installation, verify all parts are included. If any parts are missing or damaged upon arrival, contact customer service immediately for replacements.

For issues not covered here or if problems persist, please contact BOSHIRO customer support.

Specifications

Feature	Detail
Brand	BOSHIRO
Model Name	10 Drawers Dresser
Item Model Number	0090
Product Dimensions	16"D x 59"W x 32"H
Color	Light Gray
Item Weight	128 Pounds
Mounting Type	Floor Mount
Assembly Required	Yes
Special Features	6 large drawers, Framed Drawer Fronts, Unique Bracket Feet, Carved Pilasters
Country of Origin	China

Warranty and Support

BOSHIRO is committed to customer satisfaction. While specific warranty details are not provided in this manual, the manufacturer assures quality craftsmanship and durability.

- **After-sales Service:** If you encounter any problems during the installation process or with the product itself, please contact BOSHIRO customer service. They aim to reply within 24 hours and provide a satisfactory solution.
- **Returns:** This product typically comes with a 30-day return policy. Please refer to your purchase platform's return guidelines for specific details.

For direct support, please refer to the contact information provided with your purchase or visit the official BOSHIRO store page on Amazon.

Important Safety Information

To prevent injury and ensure the safe use of your dresser:

- **Tip-Over Prevention:** Always secure the dresser to a wall using anti-tip hardware, if provided. This is crucial to prevent serious injury from tip-over.
- **Children Safety:** Do not allow children to climb on or play with the dresser drawers. Keep heavy items in lower drawers.
- **Stability:** Ensure the dresser is placed on a flat, stable surface. Avoid placing it on uneven flooring or carpets that could compromise stability.

Media Resources

No official product videos from the seller were available for inclusion in this manual.

© 2025 BOSHIRO. All rights reserved.
For the latest information and support, please visit the BOSHIRO Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DG8ZFTLS

More documents and user manuals: **https://manuals.plus/**