Seizeen IHT-01

Seizeen 4-6 Person Inflatable Hot Tub Model IHT-01 Instruction Manual

Introduction

Thank you for choosing the Seizeen 4-6 Person Inflatable Hot Tub, Model IHT-01. This manual provides essential information for the safe and efficient setup, operation, and maintenance of your new hot tub. Please read all instructions carefully before installation and use to ensure proper function and longevity of the product.

Important Safety Information

- Always ensure the hot tub is placed on a flat, stable, and level surface capable of supporting its full weight when filled with water and occupants.
- Connect the hot tub only to a grounded electrical outlet protected by a Ground Fault Circuit Interrupter (GFCI).
- Do not use extension cords.
- Keep children under supervision at all times when near the hot tub.
- The maximum water temperature is 104°F (40°C). Consult a physician before use if you have health concerns.
- Do not operate the hot tub if it is damaged or malfunctioning.

Package Contents

Verify that all components listed below are present in your package:

- 1 x Inflatable Hot Tub Spa with Electric Pump
- 1 x Spa Cover
- 1 x Inflation Hose
- 1 x Hose Connector
- 1 x Spanner
- 1 x Storage Bag
- 1 x PE Floor Mat
- 1 x Inflatable Lid

- 6 x Filters
- 2 x Filter Cover
- 2 x Repair Patch
- 2 x Child Safety Key

Setup Instructions

1. Site Preparation

Select a suitable location for your hot tub. The area must be:

- **Flat and Level:** To ensure even water distribution and structural integrity.
- **Stable:** Capable of supporting the weight of the hot tub, water (240 gallons / 910 liters), and occupants.
- **Clear of Sharp Objects:** Remove any debris or sharp items that could puncture the tub.
- **Near a Grounded Outlet:** Within reach of the power cord (10.8 ft / 3.3 m) without requiring an extension cord.

2. Hot Tub Inflation

1. Unfold the hot tub and place the PE floor mat underneath it.
2. Locate the inflation valve on the hot tub.
3. Connect the inflation hose to the hot tub's inflation valve and to the electric pump.
4. Turn on the electric pump to inflate the hot tub. Inflate until the walls are firm to the touch but not rigid. Do not over-inflate.
5. Once inflated, disconnect the hose and securely close the valve.
6. Inflate the inflatable lid using the same process.



Image: Seizeen Inflatable Hot Tub in an outdoor setting, illustrating its capacity for 4-6 people.



Image: Diagram showing the reinforced cover, insulated cover, and durable 3-layer laminated PVC walls of the hot tub.

3. Filling the Hot Tub

1. Ensure the drainage plug is securely closed.
2. Begin filling the hot tub with water using a garden hose.
3. Fill the tub to the indicated maximum water volume line on the interior wall. Do not overfill.



Image: Detailed view of the hot tub's convenient features, including the water volume line, built-in handles, spa cover locks, and drainage hole.

Operating Instructions

1. Control Panel Overview

The hot tub features an integrated digital control panel for easy operation:



Image: Close-up view of the integrated digital control panel and pump, highlighting buttons for temperature, filter, inflation/bubbles, and heater.

- **Temperature Display:** Shows current and target water temperature.
- **Temperature Adjustment:** Buttons to increase or decrease the target temperature.
- **Heater Button:** Activates or deactivates the water heating function.
- **Filter Function:** Controls the water filtration system.
- **Inflation/Bubbles:** Activates the bubble massage jets.

2. Heating the Water

To heat the water:

1. Press the 'Heater' button on the control panel. The indicator light will illuminate.
2. Use the temperature adjustment buttons to set your desired water temperature, up to a maximum of 104°F (40°C).
3. The system will automatically heat the water and maintain the set temperature.

3. Bubble Massage Function

To activate the bubble jets:

1. Press the 'Inflation/Bubbles' button. The 130 bubble jets will activate, providing a soothing massage.
2. The bubble massage function typically runs for 20-minute cycles.



Image: Underwater view of the hot tub's 130 bubble jets in action, creating a relaxing massage effect.

4. Filtration System

The hot tub is equipped with an integrated filtration system to keep the water clean. Press the 'Filter' button to activate or deactivate the filtration cycle.



Image: Illustration of the hot tub's integrated water filtration system, showing water circulating through a filter.

Maintenance

1. Water Quality Management

Regularly test the water chemistry using appropriate test strips. Maintain proper pH levels and sanitize the water according to recommended guidelines for inflatable hot tubs to ensure a hygienic environment.

2. Filter Cartridge Replacement

The hot tub uses filter cartridges to remove impurities. It is recommended to clean the filters regularly and replace them every 1-2 weeks, depending on usage, to maintain optimal filtration performance. Six filters are included with your hot tub.

3. Cleaning and Draining

To clean the hot tub:

1. Turn off and unplug the hot tub from the power source.
2. Locate the drainage hole and connect a garden hose if desired to direct the water.
3. Open the drainage plug to empty the water.
4. Once empty, clean the interior surfaces with a soft cloth and mild, non-abrasive cleaner. Rinse thoroughly.
5. Ensure the hot tub is completely dry before deflating and storing.

4. Cover Care

Always use the insulated cover when the hot tub is not in use. This helps to:

- Retain heat and reduce energy consumption.
- Minimize water evaporation.
- Keep debris out of the water.
- Secure the cover with the child safety keys to prevent unauthorized access.

Troubleshooting

If you encounter issues with your hot tub, refer to the following general troubleshooting steps:

- **No Power:** Check the power connection and ensure the GFCI is not tripped.
- **Heating Issues:** Verify the desired temperature is set correctly. Ensure the water level is between the minimum and maximum lines. Clean or replace filters if they are clogged.
- **Bubble Jets Not Working:** Check the 'Inflation/Bubbles' button and ensure the hot tub is powered.
- **Error Codes:** If an error code appears on the display, consult the specific error code section in the full user manual (if provided separately) or contact customer support. Common issues like 'HL' (High Limit) often indicate low water flow, which can be resolved by checking water level and filter cleanliness.
- **Water Leaks:** Inspect the hot tub for visible punctures. Use the provided repair patches for minor leaks.

Specifications

Feature	Specification
Model	IHT-01
Capacity	4-6 people
Volume Capacity	240 gal / 910 L
Number of Air Injection Holes	130
Input Power	110V~120V-60Hz
Rated Power (Jets/Heater/Filter)	Jets-600W / Heater-1350W / Filter-30W
Maximum Temperature	104℉ / 40℃
Filtration Rate	6 gpm / 23 L/min
Power Cord Length	10.8 ft / 3.3 m

Outer Dimensions (Dia x H)	73 x 25.6 inches (185.4 x 65 cm)
Inner Dimensions (Dia x H)	57 x 25.6 inches (144.8 x 65 cm)
Net Weight	53 lbs (24 kg)
Material	3-layer Laminated PVC



Image: Diagram illustrating the external and internal dimensions of the Seizeen Inflatable Hot Tub.

Warranty and Support

Seizeen is committed to providing high-quality products. While specific warranty details are not provided in this document, please note the following:

- **Returns:** The product is eligible for 30-day easy returns. Please refer to your purchase platform's return policy for details.
- **Customer Support:** For any questions, technical assistance, or concerns regarding your Seizeen Inflatable Hot Tub, please contact Seizeen customer support. Contact information can typically be found on the seller's page or your purchase invoice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

What does the FC error code mean on the Seizeen IHT-01 Inflatable Hot Tub?

While the provided manual for the Seizeen IHT-01 does not explicitly define the "FC" code, it is a common error code for inflatable hot tubs that typically refers to Filter Check or Filter Cleaning.Based...

Read full answer