

[Manuals.plus](#) /

› [VINGLI](#) /

› VINGLI Tall Dresser, Rustic Grey, 6-Drawer Chest (Model D02S4LD) Instruction Manual

VINGLI D02S4LD

VINGLI Tall Dresser, Rustic Grey, 6-Drawer Chest (Model D02S4LD) Instruction Manual

Comprehensive Guide for Assembly, Operation, and Maintenance

1. PRODUCT OVERVIEW

The VINGLI Tall Dresser is a 6-drawer chest designed for organized storage in various rooms. This rustic grey dresser features a durable construction and a thoughtful design to enhance your living space.



Image 1.1: The VINGLI Tall Dresser, Rustic Grey, featuring six drawers and a sturdy design.

Key Features:

- **Triple Size Drawers:** Includes two small, two medium, and two large drawers for varied storage needs.
- **Durable Construction:** Made from wooden board with a water and scratch-resistant veneer finish.
- **Smooth Operation:** Equipped with metal full-extension silent slide rails for effortless drawer access.
- **Enhanced Safety:** Features a sturdy curved base and an anti-tip device for stability.
- **Rustic Aesthetic:** Washed grey finish with metal brass knobs for a timeless look.

2. SETUP AND ASSEMBLY

Assembly of the VINGLI Tall Dresser is required. Please follow these instructions carefully. It is recommended to have a second person assist with assembly for easier handling and safety.

2.1 Unpacking and Preparation

1. Carefully open the packaging and remove all components.
2. Verify that all parts and hardware are present by comparing them with the included parts list (not provided in this manual, refer to your product packaging).
3. Lay out all components on a clean, soft surface to prevent scratches during assembly.

2.2 Assembly Steps

While specific step-by-step diagrams are typically provided with the product, general assembly involves:

- Assembling the main frame of the dresser.
- Attaching the drawer slides to the dresser frame and drawer boxes.
- Constructing the individual drawer boxes.
- Installing the metal brass knobs onto each drawer front.
- Inserting the assembled drawers into the frame.



Image 2.1: Illustration of the metal full-extension silent slide for smooth drawer operation.

2.3 Anti-Tip Device Installation

For safety, it is crucial to install the included anti-tip device. This device helps prevent the dresser from tipping over, especially in households with children or pets.

1. Locate the anti-tip kit components.
2. Attach one bracket to the top rear edge of the dresser using the provided screws.
3. Position the dresser against a wall in its final location.
4. Mark the wall where the second bracket or anchor needs to be installed, ensuring the strap is taut.
5. Drill a pilot hole in the wall (if necessary, depending on wall material) and secure the second bracket/anchor.
6. Connect the strap between the dresser bracket and the wall anchor.



Image 2.2: Detail showing the sturdy curved base and the anti-tipping kit for enhanced safety.

3. OPERATING INSTRUCTIONS

The VINGLI Tall Dresser is designed for efficient storage with its varied drawer sizes.

3.1 Drawer Usage and Capacity

The dresser features six drawers of three different sizes:

- **Upper Small Drawers (x2):** Inner size approximately 12.2"W x 12.8"D x 3.94"H. Ideal for socks, intimates, or small accessories. Maximum load capacity: 11 lbs per drawer.
- **Middle Medium Drawers (x2):** Inner size approximately 27.16"W x 12.8"D x 3.94"H. Suitable for T-shirts, smaller garments, or folded items. Maximum load capacity: 11 lbs per drawer.
- **Bottom Large Drawers (x2):** Inner size approximately 27.16"W x 12.8"D x 8.27"H. Designed for larger clothing items, linens, or bulkier articles. Maximum load capacity: 22 lbs per drawer.

The top panel of the dresser has a maximum load capacity of 110 lbs.

Ample Storage




Image 3.1: Overview of the dresser dimensions and individual drawer capacities.

Metal Fully Extended Silent Slide

Smooth & Quiet Drawer Operation



Image 3.2: Visual comparison highlighting the depth of the bottom drawers.

3.2 Opening and Closing Drawers

Each drawer is equipped with metal full-extension silent slide rails and double metal handles for smooth and quiet operation. Pull the handles gently to open and push firmly to close. Avoid forcing drawers if they encounter resistance.

4. MAINTENANCE

Proper care will ensure the longevity and appearance of your VINGLI Tall Dresser.

4.1 Cleaning

- Wipe the dresser surfaces with a dry, soft cloth.
- Avoid using abrasive cleaners, harsh chemicals, or excessive moisture, as these can damage the finish.
- For stubborn marks, a slightly damp cloth followed immediately by a dry cloth may be used.

4.2 General Care

- Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary.
- Avoid placing hot items directly on the dresser surface. Use coasters or protective pads.
- Keep the dresser away from direct sunlight and extreme temperature changes to prevent warping or fading.



Image 4.1: Illustration of the wooden board with water and scratch-resistant veneer finish.

5. TROUBLESHOOTING

If you encounter issues with your dresser, refer to the following common problems and solutions.

5.1 Drawers Do Not Align or Close Properly

- **Check Assembly:** Ensure all drawer slides are installed correctly and are level. Verify that the drawer boxes are assembled squarely.
- **Tighten Screws:** Loose screws on drawer slides or drawer boxes can cause misalignment. Tighten all fasteners.

- **Obstructions:** Check for any objects or debris obstructing the drawer slides or the back of the drawer.
- **Overloading:** Ensure drawers are not overloaded beyond their specified weight capacity, which can cause them to sag or stick.

5.2 Missing Parts or Damaged Components

- If you find any parts missing or damaged upon unpacking, do not proceed with assembly.
- Contact VINGLI customer support immediately for assistance with part replacement. Refer to the 'Support' section for contact information.

5.3 Dresser Feels Unstable

- **Level Surface:** Ensure the dresser is placed on a flat, level surface.
- **Tighten Connections:** Verify that all assembly screws and bolts are securely tightened.
- **Anti-Tip Device:** Confirm that the anti-tip device is correctly installed and securely anchored to the wall.

6. SPECIFICATIONS

Brand	VINGLI
Model Number	D02S4LD
Product Dimensions (Overall)	15.75"D x 31.5"W x 47.64"H
Color	Rustic Grey
Furniture Finish	Gray
Item Weight	94.8 Pounds
Assembly Required	Yes
Product Care Instructions	Wipe with Dry Cloth
Manufacturer	VINGLI

7. WARRANTY AND SUPPORT

7.1 Warranty Information

The VINGLI Tall Dresser comes with a **24-Month Quality Warranty**. This warranty covers manufacturing defects and material flaws under normal use. Please retain your proof of purchase for warranty claims.

7.2 Customer Support

For any questions, concerns, or assistance with your VINGLI product, please contact VINGLI customer support. They offer professional quality service to address your needs.

You can typically find contact information on the VINGLI official website or through the retailer where you purchased the product. For direct inquiries, you may also visit the [VINGLI Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question