

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [INFILAND](#) /

› [INFILAND Keyboard Case User Manual for Samsung Galaxy Tab S10 Lite, S10 FE, S9, and S9 FE](#)

INFILAND 0757158219043

INFILAND Keyboard Case User Manual for Samsung Galaxy Tab S10 Lite, S10 FE, S9, and S9 FE

Brand: INFILAND | Model: 0757158219043

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your INFILAND Keyboard Case. This accessory is designed to enhance the functionality of your compatible Samsung Galaxy tablet, offering a laptop-like experience with a high-precision trackpad, backlit keyboard, and versatile stand.



Image: The INFILAND Keyboard Case with a Samsung Galaxy tablet in an upright position, showcasing the backlit keyboard and trackpad.

COMPATIBILITY

This keyboard case is specifically designed for the following Samsung Galaxy Tab models:

- Samsung Galaxy Tab S10 Lite 5G 10.9" (Model SM-X400/SM-X406B) 2025
- Samsung Galaxy Tab S10 FE 5G 10.9" (Model SM-X520/X526B/X528U) 2025
- Samsung Galaxy Tab S9 FE 5G 10.9" (Model SM-X510/X516B/X518U) 2023
- Samsung Galaxy Tab S9 11" (Model SM-X710/X716B/X718U) 2023

Please verify your tablet's model number before use to ensure proper fit and functionality.

Compatible List:

Only for Samsung Galaxy [Tab S10 Lite 10.9 inch](#), [Samsung Galaxy Tab S10 FE 5G 10.9 inch](#),
[Samsung Galaxy Tab S9 FE 5G 10.9 inch](#), [Samsung Galaxy Tab S9 11 inch](#)



- ✓ Galaxy Tab S10 Lite 5G 10.9" (Model SM-X400/SM-X406B) 2025
- ✓ Galaxy Tab S10 FE 5G 10.9" (Model SM-X520/X526B/X528U) 2025
- ✓ Galaxy Tab S9 FE 5G 10.9" (Model SM-X510/X516B/X518U) 2023
- ✓ Galaxy Tab S9 11" (Model SM-X710/X716B/X718U) 2023



- ✗ Galaxy Tab S10+/S10 Plus 12.4"
- ✗ Galaxy Tab S9+/S9 Plus 12.4"
- ✗ Galaxy Tab S9 FE+/S9 FE Plus 12.4"
- ✗ Galaxy Tab S9 Ultra 14.6"
- ✗ Galaxy Tab S10 FE+ Plus 13.1"

How to find your device model

Android tablet:
go to Settings > About tablet
Product name/Model name




Image: A visual guide showing compatible and incompatible Samsung Galaxy Tab models for the keyboard case.

How to Check Your Tablet Model Number

Your browser does not support the video tag.

Video: This video demonstrates how to locate the model number of your Samsung Galaxy tablet through the device settings.

SETUP INSTRUCTIONS

1. Charging the Keyboard

Before initial use, ensure the keyboard is fully charged. Connect the provided Type-C charging cable to the keyboard's charging port and a power source.

- **Full Charge Time:** Approximately 2-3 hours.
- **Continuous Use Time (without backlight):** 5-7 days.
- **Continuous Use Time (with backlight):** Approximately 4 hours.
- **Standby Time:** Up to 30 days.



Bluetooth connection

Full charge time : **2-3 hours**



Continuous use time

5-7 days of use without using backlight

4 hours of non-stop
use under luminescence



Standby time

30 days



TYPE-C Charging Port



Image: Details of the keyboard's Type-C charging port and indicators for Bluetooth connection and battery status.

2. Bluetooth Pairing

- Turn on the Keyboard:** Locate the power switch on the keyboard and slide it to the 'ON' position.
- Enable Bluetooth on Tablet:** Go to your Samsung Galaxy tablet's **Settings**, then navigate to **Connections**, and turn on **Bluetooth**.
- Activate Pairing Mode:** On the keyboard, press the **Fn + C** keys simultaneously. The Bluetooth indicator light on the keyboard will begin to flash, indicating it is in pairing mode.
- Select Keyboard on Tablet:** On your tablet, in the Bluetooth settings, look for "Bluetooth keyboard" or a similar device name in the list of available devices. Tap on it to connect.
- Confirm Pairing:** A pairing request may appear on your tablet. Confirm the pairing to establish the connection.

Keyboard Pairing Instructions Video

Your browser does not support the video tag.

Video: This video demonstrates how to pair the INFILAND keyboard with a Samsung Galaxy tablet via Bluetooth, and also covers backlight adjustment and trackpad gestures.

OPERATING INSTRUCTIONS

1. Backlight Adjustment

The keyboard features 7-color backlighting with 3 levels of brightness. This allows for comfortable typing in various lighting conditions.

- To adjust brightness: Press the **light bulb icon key** (usually located near the arrow keys) repeatedly to cycle through 3 brightness levels.
- To change backlight color: Press **Fn + light bulb icon key** simultaneously to cycle through the 7 available colors.



Image: A visual representation of the keyboard's 7-color backlight feature and brightness levels.

2. High-Precision Trackpad Gestures

The integrated trackpad supports various multi-finger gestures for efficient navigation and control of your tablet.

- **Single Finger Tap:** Left-click.
- **Two-Finger Tap:** Right-click (context menu).

- **Two-Finger Swipe (Left/Right):** Switch between interfaces/pages.
- **Two-Finger Swipe (Up):** Pull out the search bar.
- **Two-Finger Swipe (Down):** Pull out the notification bar.
- **Three-Finger Swipe (Left/Right):** Switch between background applications.
- **Two-Finger Pinch (In/Out):** Zoom in and out of content.
- **Two-Finger Swipe (Up on background screen):** End background programs.
- **Three-Finger Slide (Up/Down in application):** Switch programs sequentially.
- **Three-Finger Slide (Right in application):** Return to the main page.




Image: A close-up of the keyboard's trackpad, highlighting its high precision and multi-gesture capabilities.

3. 360° Adjustable Rotating Stand

The case features a 360-degree rotating stand, allowing for flexible landscape and portrait viewing angles. The anti-slip grooves ensure stability in various positions.

360° Degree Rotating

Support landscape and portrait viewing



Image: The keyboard case demonstrating its 360-degree rotation and multiple viewing angles for the tablet.

Adjustable Kickstand Demonstration Video

Your browser does not support the video tag.

Video: This video showcases the adjustable kickstand and 360-degree rotation feature of the keyboard case, allowing for versatile viewing orientations.

4. Detachable Keyboard

The keyboard is magnetically attached to the case, allowing it to be easily detached for flexible use. This design provides convenience when you need to use the tablet independently or adjust the keyboard's position.

Easily Detachable



Magnetic Attraction



Specially designed anti-slip grooves

Keep device stable at certain viewing angle for worry-free use

Image: The keyboard being easily detached from the case, demonstrating its magnetic attachment and anti-slip grooves.

5. S Pen Holder

The case includes a dedicated holder for your S Pen, ensuring it is securely stored and easily accessible, preventing loss or damage.



Image: A close-up view of the integrated S Pen holder within the keyboard case, showing the stylus securely stored.

MAINTENANCE

To ensure the longevity and optimal performance of your INFILAND Keyboard Case, follow these maintenance guidelines:

- **Cleaning:** Use a soft, damp cloth to wipe the exterior of the case and keyboard. Avoid harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the keyboard case in a clean, dry environment away from extreme temperatures and direct sunlight.
- **Avoid Liquids:** Keep the keyboard away from liquids to prevent damage to electronic components.
- **Handle with Care:** Avoid dropping the case or applying excessive force to the keyboard or tablet.

TROUBLESHOOTING

If you encounter issues with your INFILAND Keyboard Case, refer to the following common troubleshooting steps:

- **Keyboard Not Connecting:**
 - Ensure the keyboard is powered on and fully charged.
 - Verify Bluetooth is enabled on your tablet.
 - Make sure the keyboard is in pairing mode (Fn + C).
 - Forget the device in your tablet's Bluetooth settings and attempt to re-pair.
 - Restart both the tablet and the keyboard.
- **Keys Not Responding:**
 - Check if the keyboard is connected via Bluetooth.
 - Ensure the keyboard has sufficient battery charge.
 - Clean any debris that might be under the keys.
- **Trackpad Not Working:**
 - Confirm the keyboard is connected.
 - Ensure the trackpad is not accidentally disabled (some keyboards have a function key to toggle the trackpad).
 - Clean the trackpad surface.
- **Backlight Not Working/Changing:**

- Ensure the keyboard is powered on.
- Press the backlight control keys (light bulb icon, Fn + light bulb icon) as described in the "Backlight Adjustment" section.

SPECIFICATIONS

Brand	INFILAND
Model Number	0757158219043
Compatible Devices	Samsung Galaxy Tab S10 Lite/S10 FE/S9/S9 FE 5g
Connectivity Technology	Bluetooth
Special Features	Backlit, High-Precision Trackpad, Detachable Keyboard, 360° Rotating Stand, S Pen Holder
Material	Leather
Item Weight	1.52 pounds
Package Dimensions	10.83 x 7.68 x 1.1 inches
Color	Light Black



WARRANTY AND SUPPORT



For warranty information, technical support, or further assistance, please refer to the contact details provided with your product packaging or visit the official INFILAND website. Keep your purchase receipt for warranty claims.

You can visit the [INFILAND Store on Amazon](#) for more products and information.

© 2025 INFILAND. All rights reserved.

Related Documents - 0757158219043

 INFILAND Backlit Keyboard Case for Samsung Galaxy Tabs - User Guide Detailed information and usage guide for the INFILAND backlit keyboard case, compatible with various Samsung Galaxy Tab S7, S8, and S7 FE models. Includes charging instructions and backlight customization.	 INFILAND Keyboard User Manual A user manual for the INFILAND wireless keyboard, detailing product parameters, charging instructions, pairing with tablets, and troubleshooting common issues.	 INFILAND Keyboard User Manual and Setup Guide Comprehensive user manual for the INFILAND keyboard, covering setup, pairing, charging, product specifications, and troubleshooting for seamless tablet integration.
---	---	--

	<p>INFLAND Crystal Clear Protective Case for Microsoft Surface Pro 9 (13-inch, 2022)</p> <p>Detailed information about the INFLAND Crystal Clear protective case designed specifically for the Microsoft Surface Pro 9 (13-inch, 2022). Learn about compatibility, usage instructions, features, and warranty.</p>
	<p>INFLAND Keyboard User Manual</p> <p>A user manual for the INFLAND keyboard, detailing its features, charging instructions, pairing process, and troubleshooting common problems. Includes product specifications and keyboard layout diagrams.</p>
	<p>Infiland KE00X7SA Keyboard User Manual and Quick Start Guide</p> <p>Comprehensive guide for the Infiland KE00X7SA keyboard, covering quick start, pairing, troubleshooting, gestures, and shortcut keys for seamless operation.</p>