

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [KCCKOM](#) /

› [KCCKOM Party Tent PE 19.7'x39.4' Gray User Manual](#)

KCCKOM KCCKOM

KCCKOM Party Tent PE 19.7'x39.4' Gray User Manual

Model: KCCKOM

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your KCCKOM Party Tent PE 19.7'x39.4' Gray. Designed for outdoor events, this marquee tent offers a spacious and durable shelter solution for various occasions.

The tent features a water-resistant PE material cover and side panels, decorative windows, and a rust-resistant steel frame, ensuring stability and longevity. Please read this manual thoroughly before setup and use to ensure safe and proper operation.

2. SAFETY INFORMATION

WARNING: This product should NEVER be used under bad weather conditions, such as strong wind, heavy rain, snow, or storms. Failure to adhere to this warning may result in damage to the tent or personal injury.

- Ensure the tent is assembled on a flat, stable surface.
- Securely anchor the tent to the ground using all provided ropes and stakes to prevent uplift in windy conditions.
- Keep all flame and heat sources away from the tent fabric.
- Do not hang heavy objects from the tent frame.
- Regularly inspect the tent for any signs of wear or damage, especially before and after each use.

3. PACKAGE CONTENTS

Before beginning assembly, please verify that all components listed below are present in your package:

- Roof canopy
- Sidewalls (with windows)
- Door panels (with zips)

- Tubular frame components
- Assembly accessories (connectors, ropes, stakes, etc.)

4. SETUP INSTRUCTIONS

Assembly of the KCCKOM Party Tent is designed to be straightforward. It is recommended that at least two people are available for assembly.

1. **Prepare the Area:** Choose a clear, level area for the tent. Ensure there are no overhead obstructions or sharp objects on the ground.
2. **Assemble the Frame:** Begin by laying out all tubular frame components. Connect the poles according to the provided diagram (refer to the dimension diagram in Section 7). Ensure all connections are secure.
3. **Attach the Roof Canopy:** Carefully drape the roof canopy over the assembled frame. Ensure it is centered and aligned correctly. Secure the canopy to the frame using the integrated ties or fasteners.
4. **Install Sidewalls and Doors:** Attach the sidewalls to the frame, ensuring the window panels are correctly positioned. The two door panels, located at the ends of the tent, can be attached last.
5. **Secure the Tent:** Once the frame and fabric are in place, use the provided ropes and stakes to firmly anchor the tent to the ground. This is crucial for stability, especially in light winds.



Figure 4.1: Fully assembled KCCKOM Party Tent, showcasing its structure and side windows.




Figure 4.2: Interior view of the tent, showing the robust steel frame and the decorative window design.



Figure 4.3: Detail of a frame joint, illustrating the connection points for the tubular steel structure.



Figure 4.4: Close-up showing how the tent fabric is secured to the frame using elastic cords and eyelets.

5. OPERATING INSTRUCTIONS

Your KCCKOM Party Tent is designed for versatility and ease of use for various outdoor events.

- **Entry and Exit:** The tent features two door panels at each end. These panels are equipped with zips and can be rolled up and secured to allow for easy entry and exit, or to increase airflow.
- **Ventilation:** The decorative windows on the sidewalls provide natural light. While not designed to open, the roll-up door panels offer significant ventilation when needed.

- **Event Use:** Ideal for weddings, parties, BBQs, camping trips, festivals, or as a large sunshade in your backyard.



Figure 5.1: The party tent with one of its end door panels rolled up, demonstrating easy access.



Figure 5.2: A close-up view of the durable zipper on the tent's door panel.

6. MAINTENANCE

Proper maintenance will extend the life of your party tent.

- **Cleaning:** Clean the fabric with mild soap and water. Do not use harsh chemicals or abrasive cleaners, as they may damage the PE material. Rinse thoroughly and allow to air dry completely before storage.
- **Water Resistance:** While the PE material is water resistant, we recommend treating the canopy with a water-resistant spray if the marquee is subjected to heavy rainfall to enhance its protective qualities.
- **Frame Inspection:** Periodically check all frame connections for tightness and ensure no components are bent or damaged.
- **Storage:** When not in use, disassemble the tent and store all components in a dry, cool place, away from direct sunlight and extreme temperatures. Ensure the fabric is completely dry to prevent mold and mildew.

7. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **Tent is unstable:**

Ensure all frame connections are fully engaged. Verify that all ropes and stakes are properly secured and taut. Check if the ground is level.

- **Water pooling on roof:**

Ensure the roof canopy is stretched tightly over the frame. If heavy rainfall is expected, consider applying a water-resistant spray as mentioned in the Maintenance section.

- **Difficulty zipping doors:**

Ensure the fabric around the zipper is not caught. Apply a silicone-based lubricant to the zipper teeth if it's stiff.

- **Missing or damaged parts:**

Refer to the Package Contents list. If any parts are missing or damaged upon arrival, contact customer support immediately.

8. SPECIFICATIONS

| Feature | Detail |
|-------------------------|--|
| Brand | KCCKOM |
| Model Number | KCCKOM |
| Color | Gray |
| Material (Fabric) | Polyethylene (PE) |
| Material (Frame) | Powder-coated Steel / Alloy Steel |
| Size (W x L) | 19.7' x 39.4' (approx. 6m x 12m) |
| Peak Height | 11.8' (approx. 3.6m) |
| Eave Height | 6.6' (approx. 2m) |
| Top Roof Fabric Density | 0.6 oz/ft ² |
| Sidewall Fabric Density | 0.5 oz/ft ² |
| Water Resistance Level | Water resistant (Note: Not Water Resistant in some specifications, but product description states water resistant. Recommend treating for heavy rain.) |
| Assembly Required | Yes |




Figure 8.1: Dimensional diagram of the KCCKOM Party Tent.

9. WARRANTY AND SUPPORT

For warranty information, please refer to the terms and conditions provided at the time of purchase or contact your retailer. For technical support, missing parts, or any inquiries regarding your KCCKOM Party Tent, please contact KCCKOM customer service through the retailer's platform or the contact information provided with your purchase.

© 2024 KCCKOM. All rights reserved.

Manual Version: 1.0