Fockety #611

Fockety Smart Pet Feeder #611 User Manual

Model: #611 (Fockety6k7wug8aev-11)

1. Introduction

Thank you for choosing the Fockety Smart Pet Feeder #611. This automatic pet feeder is designed to provide convenient and reliable feeding for your pets, ensuring they receive their meals on schedule. With its 3-liter capacity, remote control capabilities, and multiple feeding modes, it simplifies pet care. Please read this manual thoroughly before use to ensure proper operation and maintenance.

2. Safety Instructions

- Always place the feeder on a stable, level surface to prevent tipping.
- Do not immerse the main unit in water or any other liquid.
- Keep the feeder away from direct sunlight and heat sources.
- Ensure the power cord is not chewed by pets. Use battery power if this is a concern.
- This device is intended for dry pet food only. Do not use wet food, canned food, or treats.
- Keep out of reach of children.
- Regularly inspect the feeder for any damage or wear. Discontinue use if damaged.

3. Product Overview

3.1 Included Components

- Main Unit
- Cover
- Feeding Bowl
- 4 x Accessories (e.g., feet, desiccant packs)
- USB Cable

- Power Adapter
- Battery Cover

3.2 Key Features

- **3L Capacity Grain Bin:** Provides ample food storage, reducing the frequency of refills.
- **Remote Control:** Adjust feeding times and portions remotely.
- **Multiple Feeding Modes:** Customizable timed feeding schedules to suit your pet's dietary needs.
- **Anti-Overflow Design:** Helps prevent food spillage and maintains cleanliness.
- **Dual Power Supply:** Operates via USB cable with power adapter or 4 x AA batteries (not included).



Image 3.2.1: The Fockety Smart Pet Feeder #611, showing the main unit and attached feeding bowl.

4. Setup

4.1 Unpacking and Assembly

1. Carefully remove all components from the packaging.
2. Attach the feeding bowl to the main unit by aligning the slots and pushing gently until it clicks into

place.

3. If included, attach the four accessories (e.g., feet) to the bottom of the main unit for stability.



Image 4.1.1: All components of the Fockety Smart Pet Feeder #611 laid out, including the main unit, cover, bowl, USB cable, power adapter, battery cover, and four small accessories.

4.2 Power Supply

The feeder can be powered by either a USB cable with a power adapter or 4 x AA batteries.

- **USB Power:** Connect the USB cable to the feeder's power port and plug the power adapter into a standard wall outlet.
- **Battery Power:** Open the battery compartment on the bottom of the main unit, insert 4 x AA batteries (not included) according to the polarity markings, and close the battery cover. Battery power acts as a backup in case of power outage.

4.3 Filling the Grain Bin

1. Remove the cover from the top of the feeder.
2. Pour dry pet food into the grain bin. Ensure the food is suitable for automatic feeders (typically kibble size 5-15mm). Do not overfill.
3. Replace the cover securely.



Image 4.3.1: A cat sitting next to the feeder, highlighting the transparent grain storage tank which allows for easy monitoring of food levels.

5. Operating Instructions

5.1 Control Panel Overview

The control panel on the front of the feeder typically includes buttons for power, timer settings, manual feeding, and portion adjustments.



Image 5.1.1: A close-up view of the feeder's control panel, showing buttons for power, timer, settings, and portion adjustment.

5.2 Setting Up Feeding Schedules

The Fockety Smart Pet Feeder allows for multiple timed feeding modes. Refer to the specific instructions provided with your remote control or app for detailed setup.

- **Using the Remote Control:** If your model includes a remote control, use it to set the desired feeding times and portion sizes. The remote typically allows you to program up to several meals per day.
- **Using a Mobile App (if applicable):** Some models may connect to a mobile application for advanced scheduling and monitoring. Follow the app's instructions for pairing and setup.



Image 5.2.1: A hand holding a smartphone, illustrating a potential mobile application interface for controlling the pet feeder's settings and schedules.

5.3 Manual Feeding

To dispense food immediately, press the manual feed button on the control panel. This will dispense one portion of food.

6. Maintenance and Cleaning

Regular cleaning ensures the hygiene and proper functioning of your pet feeder.

- **Grain Bin and Feeding Bowl:** These components are removable and can be hand washed with mild soap and water. Rinse thoroughly and dry completely before reassembling.
- **Main Unit:** Wipe the exterior of the main unit with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Food Residue:** Periodically check for and remove any food residue or dust accumulation in the dispenser mechanism to prevent blockages.



Image 6.1.1: A close-up of the feeding bowl, highlighting its anti-overflow design which helps keep the feeding area clean.

7. Troubleshooting

If you encounter issues with your Fockety Smart Pet Feeder, refer to the following common solutions:

Problem	Possible Cause	Solution
Feeder not dispensing food	Grain bin empty; Food jammed; Low battery; Power disconnected	Refill grain bin; Clear food jam; Replace batteries; Check power connection
Feeder not turning on	No power; Batteries incorrectly installed or dead	Ensure USB cable is connected and power adapter is plugged in; Check battery installation and replace if necessary
Remote control not working	Remote batteries dead; Out of range; Interference	Replace remote batteries; Move closer to feeder; Reduce interference sources

Problem	Possible Cause	Solution
Food spilling from bowl	Overfilling; Feeder not level	Do not overfill the grain bin; Ensure feeder is on a stable, level surface

8. Specifications

Feature	Detail
Brand	Fockety
Model Name	#611 (Fockety6k7wug8aev-11)
Capacity	3 Liters
Material	Plastic
Power Supply	USB (with Power Adapter) or 4 x AA Batteries (not included)
Product Dimensions (L x W x H)	11.81 x 9.84 x 3.94 inches (approx. 28 x 17 cm)
Item Weight	2.33 pounds
Care Instructions	Hand Wash Only (for removable parts)
Target Species	Pet (suitable for cats and dogs)

9. Warranty and Support

Specific warranty information for the Fockety Smart Pet Feeder #611 is not provided in this manual. For warranty claims, technical support, or further assistance, please refer to the product packaging, your purchase documentation, or contact the retailer/manufacturer directly.

© 2024 Fockety. All rights reserved.