

Kemei KM-2606

Kemei KM-2606 Hair Clipper User Manual

Model: KM-2606

INTRODUCTION

This manual provides essential instructions for the safe and effective use of your Kemei KM-2606 hair clipper. Please read all instructions carefully before initial use and retain this manual for future reference. This device is designed for hair styling and beard trimming.

SAFETY INSTRUCTIONS

To reduce the risk of electric shock, injury, or fire, always follow these basic safety precautions:

- Do not immerse the appliance in water or other liquids.
- Keep the appliance dry. Do not use it in wet conditions or near water.
- Unplug the appliance before cleaning or performing any maintenance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Use only the charger and accessories supplied or specified by the manufacturer.
- Do not operate the appliance with a damaged cord or plug, or if it malfunctions or has been dropped or damaged.
- Avoid placing the appliance in direct sunlight or near heat sources.

PACKAGE CONTENTS

Please check the package to ensure all items are present and in good condition:



Image: The Kemei KM-2606 hair clipper kit, showing the main clipper unit, various guide combs, a power adapter, a USB charging cable, a small bottle of lubricating oil, and a cleaning brush.

- Kemei KM-2606 Hair Clipper Unit
- Multiple Guide Combs
- USB Charging Cable
- Power Adapter
- Cleaning Brush
- Lubricating Oil

PRODUCT OVERVIEW

Familiarize yourself with the main components of your Kemei KM-2606 hair clipper:



Image: Side view of the Kemei KM-2606 hair clipper, highlighting its ergonomic design and the location of the power switch.

- **Stainless Steel Blade:** Sharp and durable cutting head.
- **Power Button:** To turn the clipper on or off.
- **LCD Display:** Shows battery status and other operational information.
- **Charging Port:** USB compatible for convenient charging.
- **Adjustable Lever:** For fine-tuning cutting length (if applicable, check specific model for blade adjustment mechanism).

CHARGING THE DEVICE

Before first use, fully charge the hair clipper. Ensure the device is turned off during charging.

1. Insert the USB charging cable into the charging port at the bottom of the clipper.
2. Connect the other end of the USB cable to a power source, such as a power adapter, computer USB port, or power bank.
3. The LCD display will indicate the charging status. A full charge takes approximately 3 hours.
4. Once fully charged, the clipper provides approximately 180 minutes of continuous use.

SETUP AND PREPARATION

Attaching Guide Combs

Guide combs allow you to achieve various hair lengths. Select the desired comb before trimming.

1. Ensure the clipper is turned off.
2. Align the guide comb with the clipper blade and slide it on until it clicks securely into place.
3. To remove, gently push the comb upwards and off the blade.

Blade Adjustment

The Kemei KM-2606 features an advanced smooth steel cutting head. It can achieve a close shave of up to 2mm without any guide combs attached. For specific models with an adjustable lever, use it to fine-tune the cutting length.

OPERATING INSTRUCTIONS

Turning On/Off

Press the power button located on the clipper body to turn the device on or off.

Basic Hair/Beard Trimming

For optimal results, ensure hair is clean and dry before trimming.

1. Attach the desired guide comb for your preferred hair length.
2. Turn on the clipper.
3. Hold the clipper with the blade flat against the hair.
4. Move the clipper slowly against the direction of hair growth.
5. For beard trimming, start with a longer comb and gradually reduce the length until desired style is achieved.
6. Regularly tap or brush off accumulated hair from the blade during use to maintain cutting efficiency.

MAINTENANCE AND CLEANING

Proper maintenance ensures the longevity and performance of your clipper.

Cleaning the Blades



Image: A detailed view of the Kemei KM-2606 clipper's stainless steel blade, showing the fine teeth.

1. Turn off the clipper and unplug it from any power source.
2. The cutter head is detachable and washable. Carefully detach the blade assembly from the clipper body.
3. Use the provided cleaning brush to remove any loose hair from the blades and the clipper body.
4. Rinse the detached blade assembly under running water. Ensure the main clipper body does not get wet.
5. Allow the blade assembly to air dry completely before reattaching it to the clipper.
6. Apply a few drops of the lubricating oil (provided) to the blades after each cleaning or every few uses to maintain smooth operation and prevent rust.

Storage

Store the clipper in a cool, dry place, away from direct sunlight and out of reach of children.

TROUBLESHOOTING

If you encounter any issues with your Kemei KM-2606 hair clipper, refer to the table below:

Problem	Possible Cause	Solution
Clipper does not turn on.	Battery is discharged.	Charge the clipper for approximately 3 hours.
Clipper runs slowly or pulls hair.	Blades are dirty or not lubricated.	Clean the blades and apply lubricating oil.
Clipper is making unusual noise.	Blades are not properly aligned or need lubrication.	Ensure blades are correctly attached and lubricate them.
Clipper does not charge.	Charging cable or adapter is faulty.	Try a different USB cable or power source. Ensure connections are secure.

SPECIFICATIONS

Technical details for the Kemei KM-2606 hair clipper:

Feature	Detail
Brand	Kemei
Model Number	KM-2606
Cutter Head Material	Stainless Steel
Battery Type	2000 mAh Lithium Battery
Charging Time	Approximately 3 hours
Discharge Time (Run Time)	Approximately 180 minutes
Motor Speed	6500 RPM
Charging Interface	USB (Compatible with power banks, computers, mobile chargers)
Cleaning Method	Detachable and Washable Cutter Head
Product Dimensions	15 x 4 x 3 cm
Item Weight	1.2 kg
Special Features	Rechargeable, LCD Display, Noise Reduction

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided at the time of purchase or contact your retailer. Keep your purchase receipt as proof of purchase.