Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Aroepurt Atmpc It-801b

User Manual

Aroepurt Atmpc It-801b 10-Inch Tablet Case

Introduction

This manual provides instructions for the proper use and care of your Aroepurt Atmpc It-801b 10-Inch Tablet Case. Please read this manual thoroughly to ensure optimal performance and longevity of your product.

Product Features

The Aroepurt Atmpc It-801b 10-Inch Tablet Case is designed to provide protection and versatility for your tablet. Key features include:

- Compatibility with Atmpc It-801b 10-Inch tablets, offering a 360-degree rotation for multi-viewing angles.
- Constructed from premium durable synthetic leather with a soft anti-slip interior to prevent fingerprints, dirt, and scratches.
- Provides total full body protection against scratches, shocks, fingerprints, and dust.
- Features an anti-slip strip design, allowing the tablet to stand firmly for viewing.
- Includes a reserved back camera opening to support camera usage.
- Equipped with a convenient storage pocket for carrying cards, documents, and cash.



Image: The Aroepurt tablet case, showcasing its design and versatility in stand mode.



Image: Detail of the anti-slip stripe, which helps secure the tablet in various viewing angles.



Image: Demonstration of the 360-degree rotation capability, allowing for multiple viewing orientations.



Image: The integrated storage pocket, useful for carrying small items like cards or cash.

Setup

Follow these steps to set up your tablet case:

1. **Inserting the Tablet:** Gently align your Atmpc It-801b 10-Inch tablet with the case's frame. Press firmly but carefully to secure the tablet within the protective shell. Ensure all edges are properly seated.
2. **Utilizing the Stand:** Fold the front cover back to form a triangular stand. The anti-slip strip on the interior will help stabilize the tablet in your desired viewing angle.
3. **Camera Access:** The case features a reserved opening for the tablet's rear camera. Ensure your tablet's camera aligns with this cutout for unobstructed use.



Image: Guide for inserting the tablet into the case, highlighting compatibility.



Image: Details of the camera cutouts, designed to accommodate different tablet camera placements.

Operation

The tablet case is designed for ease of use and protection:

- **Viewing Angles:** The 360-degree rotation feature allows you to orient your tablet in portrait or landscape mode. Simply rotate the tablet within its frame to achieve the desired viewing angle.
- **Stand Functionality:** Fold the cover to create a stable stand for hands-free viewing. Adjust the angle by repositioning the tablet along the anti-slip strip.
- **Port and Button Access:** The case is designed with precise cutouts to ensure full access to all tablet ports, speakers, and buttons without needing to remove the case.
- **Storage Pocket:** Use the integrated pocket to store small documents, cards, or cash for convenience.

Note: This case does not support any tablet's auto-sleep/wake function.




Image: Overview of the case's protective features, slim profile, and accessible ports.

Maintenance

To keep your tablet case in optimal condition:

- **Cleaning:** Wipe the exterior PU leather surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as they may damage the material.
- **Storage:** When not in use, store the case in a cool, dry place away from direct sunlight to prevent material degradation.
- **Handling:** Avoid excessive bending or forcing the case, especially around the rotating mechanism, to maintain its structural integrity.

Troubleshooting

If you encounter any issues with your tablet case, consider the following:

- **Tablet Not Fitting:** Ensure your tablet is the correct model (Atmpc It-801b 10-Inch). Gently re-align the tablet and

apply even pressure to seat it properly. Do not force the tablet into the case.

- **Stand Instability:** Verify that the anti-slip strip is clean and free of debris. Ensure the stand is fully formed into a stable triangular shape.
- **Camera Obstruction:** Confirm that your tablet's camera is aligned with the case's cutout. If not, slightly adjust the tablet's position within the case.

Specifications

Attribute	Detail
Product Dimensions	0.39 x 0.39 x 0.39 inches
Item Weight	2.46 ounces
Color	Red
Form Factor	Flip Case
Compatible Devices	Atmpc It-801b 10"
Shell Type	Hybrid
Special Features	Card insertion, Stash the change, Thickened anti-drop corner protector + folding stand

What's in the Box

The product package includes:

- 1 x Tablet Case

Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your purchase or contact the seller directly. Specific warranty terms and support channels are typically provided by the manufacturer or retailer at the time of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DGDW7ZJK

More documents and user manuals: **https://manuals.plus/**