

[Manuals.plus](#) /

› [Aroepurt](#) /

› Aroepurt Tablet Case for Andersson Tbx11 10.3-Inch: User Manual

## Aroepurt ARO-SSPB-190

# Aroepurt Tablet Case for Andersson Tbx11 10.3-Inch: User Manual

## 1. PRODUCT OVERVIEW

---

This manual provides instructions for the Aroepurt Tablet Case, designed for the Andersson Tbx11 10.3-inch tablet. This folio case offers 360-degree rotation, multiple viewing angles, and comprehensive protection for your device. It features a durable PU leather exterior, a soft anti-slip interior, and precise cutouts for camera and ports.



Figure 1: Aroepurt Tablet Case for Andersson Tbx11 10.3-Inch.

The case is constructed from premium synthetic leather, offering protection against fingerprints, dirt, scratches, and minor impacts. Its design ensures full body protection while maintaining access to all essential tablet functions.

## 2. INSTALLATION GUIDE

---

### 2.1 Inserting Your Tablet

1. Ensure your Andersson Tbx11 10.3-inch tablet is clean and free of debris.
2. Gently align the tablet with the case's internal frame. The case is designed to securely hold the tablet.
3. Press the tablet firmly into the frame, ensuring all corners and edges are properly seated within the protective shell.
4. Verify that all ports, buttons, and the camera are accessible through the case's precise cutouts.

# COMPATIBLE WITH A LOT OF TABLET


Please kindly check your tablet size before purchase as shown



Figure 2: Illustration of tablet insertion into the case, highlighting compatibility and fit.

# ALL-OVER- PROTECTION


Goes into every side & corner,



Device ports, speakers,  
buttons all work  
fine



Slim & Lightweight



It can protect the  
plate very well

Figure 3: The tablet fully secured within the case, demonstrating access to ports, speakers, and buttons, along with the slim profile.

## 3. OPERATING YOUR TABLET CASE

### 3.1 Adjusting the Viewing Stand

The case features an anti-slip strip design and 360-degree rotation capability, allowing for multiple viewing angles. To use the stand function:

1. Open the folio cover.
2. Position the tablet section of the case onto the anti-slip strips located on the inside of the cover.
3. Adjust the tablet's angle by moving it along the anti-slip strips to achieve your desired viewing position.
4. To utilize the 360-degree rotation, gently rotate the tablet within its frame to switch between portrait and landscape orientations while maintaining the stand function.

# MULTIPLE VIEWING

It turns into a convenient stand.  
Frees your hands and gives you a  
best viewiing angle.




Figure 4: The tablet case configured as a stand, illustrating various viewing angles supported by the anti-slip strip.

# ADJUSTABLE MULTIPLE ANGLES

Supports multiple viewing angles with 360° free rotate



Figure 5: Demonstrating the 360-degree rotation feature and the flexibility to adjust to multiple viewing angles.

## 3.2 Accessing Features

The case includes specific cutouts to ensure full functionality of your tablet:

- **Camera Access:** The case has a reserved back camera opening, supporting 99% camera usage. Note that it does not support any tablet's auto-sleep/wake function.
- **Port and Button Access:** All device ports, speakers, and buttons are precisely aligned and fully accessible when the tablet is correctly installed.

# SUITABLE FOR DIFFERENT PLATES

The 3 pre-cutouts can be used by tablets with different camera positions




Figure 6: The case features three pre-cutouts to accommodate tablets with different camera positions.

## 3.3 Using the Storage Pocket

The case includes a convenient storage pocket for carrying small items.

- Locate the large welt pocket on the inside of the folio cover.
- This pocket can be used to store cards, documents, or cash.

# STORAGE POCKET

The pocket is convenient for carrying cards, documents, and cash



Figure 7: The internal storage pocket, suitable for carrying cards, documents, and cash.

## 4. CARE AND MAINTENANCE

---

To maintain the appearance and longevity of your Aroepurt tablet case, follow these care instructions:

- **Cleaning:** Wipe the exterior PU leather surface with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the material.
- **Drying:** Allow the case to air dry completely after cleaning. Do not expose it to direct sunlight or high heat.
- **Storage:** Store the case in a cool, dry place when not in use.
- **Avoid Sharp Objects:** Keep the case away from sharp objects to prevent scratches or punctures.

## 5. TROUBLESHOOTING

---

- **Tablet does not fit:** Ensure your tablet is an Andersson Tbx11 10.3-inch model. This case is specifically designed for this model. Do not force the tablet into the case, as this may cause damage to both the tablet and the case.
- **Stand is unstable:** Ensure the tablet is placed firmly on the anti-slip strips. Adjust the angle to find a

stable position. The anti-slip design is intended to provide stability on flat surfaces.

- **Ports or buttons are blocked:** Re-check the tablet's seating within the case. Ensure it is fully inserted and aligned correctly with all cutouts.

## 6. PRODUCT SPECIFICATIONS

---

Feature	Detail
Brand	Aroepurt
Model Number	ARO-SSPB-190
Compatible Devices	Andersson Tbx11 10.3-inch
Color	Black
Material	Polyurethane (PU) Leather
Form Factor	Flip Case
Shell Type	Hybrid
Special Features	360 Degree Rotation, Multi-Viewing Stand, Anti-slip Strip, Storage Pocket, Thickened Anti-drop Corner Protector
Item Dimensions	0.39 x 0.39 x 0.39 inches (approximate)
What's in the Box	1*Tablet Case

## 7. SUPPORT AND RETURN POLICY

---

For any questions, concerns, or support regarding your Aroepurt tablet case, please contact the seller directly through the platform where you made your purchase.

**Return Policy:** This product is eligible for a refund or replacement within 30 days of purchase, in accordance with the seller's return policy.