

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Aroepurt](#) /

› [Aroepurt Case for Logicom Tab XL 14 Tablet Instruction Manual](#)

## Aroepurt Logicom Tab XL 14

# Aroepurt Case for Logicom Tab XL 14 Tablet Instruction Manual

Model: Logicom Tab XL 14 | Brand: Aroepurt

## INTRODUCTION

---

This manual provides instructions for the Aroepurt PU Leather Stand Folio Cover, designed specifically for the Logicom Tab XL 14 Tablet. This case offers comprehensive protection, multiple viewing angles, and convenient features for an enhanced tablet experience.

## PACKAGE CONTENTS

---

- 1 x Aroepurt Tablet Case for Logicom Tab XL 14

## SETUP: INSTALLING YOUR TABLET

---

1. **Open the Case:** Lay the case flat on a clean surface with the interior facing upwards.
2. **Position the Tablet:** Carefully align your Logicom Tab XL 14 tablet with the case's frame. Ensure the tablet's corners fit securely into the case's corner holders.
3. **Secure the Tablet:** Gently press the tablet into the case, ensuring all edges are properly seated and the tablet is held firmly. Verify that all ports, buttons, and the camera are accessible through the case's cutouts.

# COMPATIBLE WITH A LOT OF TABLET

Please kindly check your tablet size before purchase as shown



*Image: The tablet case open, demonstrating how the Logicom Tab XL 14 tablet fits securely within the case.*

## OPERATING INSTRUCTIONS

---


### Using the Multi-Viewing Stand

The case features an anti-slip strip design and a 360-degree rotation mechanism, allowing for multiple stable viewing angles.

1. **Activate Stand:** Fold the front cover backward to form a triangular stand.
2. **Adjust Angle:** Position the tablet's edge against one of the anti-slip strips on the inner cover to achieve your desired viewing angle.
3. **Rotate View:** The tablet can be rotated 360 degrees within the case to switch between portrait and landscape orientations while maintaining stand functionality.

# MULTIPLE VIEWING

It turns into a convenient stand.  
Frees your hands and gives you a  
best viewing angle.



*Image: The case configured as a stand, highlighting the anti-slip stripe for secure positioning.*

# ADJUSTABLE MULTIPLE ANGLES

Supports multiple viewing angles with 360° free rotate



*Image: Illustrations showing the 360-degree rotation feature for flexible viewing orientations.*

## Using the Storage Pocket

The case includes a convenient storage pocket for cards, documents, or cash.

- Locate the welt pocket on the interior of the case's front cover.
- Insert small items such as ID cards, credit cards, or folded cash into the pocket for secure carrying.

# STORAGE POCKET

The pocket is convenient for carrying cards, documents, and cash



*Image: The case's interior pocket, demonstrating its use for storing cards and cash.*

## Camera Access

The case features a reserved back camera opening to support camera usage. Please note that the case does not support any tablet's auto-sleep/wake function.

# SUITABLE FOR DIFFERENT PLATES

The 3 pre-cutouts can be used by tablets with different camera positions




*Image: Detail of the case's camera cutouts, designed to accommodate various tablet camera positions.*

## Protection Features

The case is constructed from premium durable synthetic leather with a soft anti-slip interior, providing full body protection against scratches, shocks, fingerprints, and dust. It features thickened anti-drop corner protectors to safeguard your device.

# ALL-OVER- PROTECTION

Goes into every side & corner



Device ports, speakers, buttons all work fine



Slim & Lightweight



It can protect the plate very well

*Image: Details illustrating the case's slim profile, precise cutouts for device ports and buttons, and robust corner protection.*

## MAINTENANCE

### Cleaning Instructions

- To clean the PU leather exterior, gently wipe with a soft, damp cloth.
- Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the material.
- Allow the case to air dry completely before reinserting your tablet.

## TROUBLESHOOTING

- **Tablet Does Not Fit:** Ensure your tablet is a Logicom Tab XL 14 model. This case is specifically designed for this model.
- **Stand Instability:** Ensure the tablet's edge is firmly seated against one of the anti-slip strips. Adjust the angle as needed.
- **Camera Obstruction:** While the case has a reserved opening, some tablet camera placements may vary slightly. Ensure the tablet is correctly aligned within the case.

- **Auto-Sleep/Wake Function:** This case does not support the auto-sleep/wake function. You will need to manually turn your tablet's screen on and off.

## SPECIFICATIONS

---

<b>Brand</b>	Aroepurt
<b>Compatible Device</b>	Logicom Tab XL 14
<b>Material</b>	Premium Durable Synthetic PU Leather
<b>Form Factor</b>	Flip Case
<b>Special Features</b>	360 Degree Rotation, Multi-Viewing Stand, Anti-slip Strip, Card Insertion, Storage Pocket, Thickened Anti-drop Corner Protector
<b>Color</b>	Brown
<b>Product Dimensions</b>	0.39 x 0.39 x 0.39 inches (Approximate, for case only)
<b>Item Weight</b>	2.46 ounces

## SUPPORT

---

For further assistance or inquiries, please contact Aroepurt customer support through your purchase platform.