

- Manuals.plus /
- › Aroepurt /
- › Aroepurt Xgody R15 11-Inch Tablet Case User Manual

Aroepurt B0DGDXXQH1L

Aroepurt 360 Degree Rotation Tablet Case User Manual

Model: B0DGDXXQH1L | Brand: Aroepurt

1. PRODUCT OVERVIEW

This manual provides instructions for the Aroepurt 360 Degree Rotation PU Leather Stand Folio Cover, designed specifically for the Xgody R15 11-Inch Tablet. This case offers comprehensive protection and versatile viewing options for your device.



Figure 1.1: Aroepurt Tablet Case - Front and Usage View

Key Features:

- **360 Degree Rotation:** Allows for multi-angle viewing in both portrait and landscape orientations.
- **Multi-Viewing Angles:** Integrated stand with anti-slip stripe for stable positioning.
- **Premium PU Leather:** Durable synthetic leather exterior with a soft anti-slip interior for protection against fingerprints, dirt, and scratches.
- **Full Body Protection:** Guards against scratches, shocks, and dust.
- **Reserved Camera Opening:** Supports camera usage without removing the tablet from the case.
- **Storage Pocket:** Convenient for carrying cards, documents, and cash.
- **Slim & Lightweight Design:** Adds minimal bulk to your tablet.

2. SETUP AND INSTALLATION

Follow these steps to properly install your Xgody R15 11-Inch Tablet into the Aroepurt case.

1. **Prepare Your Tablet:** Ensure your Xgody R15 11-Inch Tablet is clean and free of dust or debris.
2. **Open the Case:** Gently open the folio cover of the Aroepurt case.
3. **Align the Tablet:** Carefully align your tablet with the internal frame of the case. Ensure the camera, ports, and buttons align with the corresponding cutouts in the case.
4. **Secure the Tablet:** Press the tablet gently into the frame until it is securely seated. The case is designed to hold the tablet firmly while allowing access to all essential functions.



Figure 2.1: Tablet Compatibility and Fit

Note: This case features specific cutouts for the camera. Verify that your tablet's camera aligns with one of the provided cutouts for proper functionality.

SUITABLE FOR DIFFERENT PLATES

The 3 pre-cutouts can be used by tablets with different camera positions



Figure 2.2: Camera Cutout Options

3. OPERATING INSTRUCTIONS

Using the Stand Function:

The case is designed with an anti-slip stripe and a 360-degree rotating mechanism to provide multiple stable viewing angles.

1. **Activate Stand:** Fold the front cover back to form a triangular stand. The anti-slip stripe on the interior of the cover helps secure the tablet at your desired angle.
2. **Adjust Viewing Angle:** Position the tablet along the anti-slip stripe to achieve various viewing angles suitable for typing, watching videos, or browsing.

MULTIPLE VIEWING

It turns into a convenient stand.
Frees your hands and gives you a
best viewiing angle.




Figure 3.1: Multiple Viewing Angles with Anti-slip Stripe

Utilizing 360 Degree Rotation:

The central pivot point allows for seamless rotation between portrait and landscape modes while maintaining stand functionality.

1. **Rotate Tablet:** While the tablet is in the stand position, gently rotate the tablet within its frame to switch between horizontal (landscape) and vertical (portrait) orientations.
2. **Secure Position:** Ensure the tablet clicks into place or feels stable in the desired orientation before use.

ADJUSTABLE MULTIPLE ANGLES

Supports multiple viewing angles with 360° free rotate



Figure 3.2: 360 Degree Rotation Feature


Using the Storage Pocket:

The case includes a convenient pocket for small items.

- Insert cards, small documents, or cash into the designated pocket on the front cover.

ALL-OVER- PROTECTION

Goes into every side & corner



Device ports, speakers, buttons all work fine



Slim & Lightweight



It can protect the plate very well

Figure 3.3: Integrated Storage Pocket

4. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your tablet case.

- **Cleaning:** Wipe the exterior PU leather surface with a soft, damp cloth. For stubborn stains, use a mild soap solution and then wipe with a clean, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Drying:** Allow the case to air dry completely after cleaning. Do not expose to direct sunlight or high heat.
- **Storage:** When not in use, store the case in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Sharp Objects:** Keep the case away from sharp objects to prevent scratches or punctures.

COMPATIBLE WITH A LOT OF TABLET

Please kindly check your tablet size before purchase as shown



Figure 4.1: Case Protection and Design Details

5. TROUBLESHOOTING

If you encounter any issues with your tablet case, refer to the following common problems and solutions.

- **Tablet Does Not Fit Properly:**

- Ensure you have the correct model: This case is specifically designed for the Xgody R15 11-Inch Tablet. Verify your tablet's model and screen size.
- Check alignment: Make sure the tablet is correctly aligned with all cutouts before attempting to fully insert it.

- **Stand is Not Stable:**

- Ensure the tablet is placed firmly on the anti-slip stripe.
- Adjust the angle: Experiment with different positions along the anti-slip stripe to find a stable viewing angle.
- Ensure the case is on a flat, stable surface.

- **Camera Opening Does Not Align:**
 - This case has multiple camera cutouts to accommodate various tablet camera positions. Ensure your tablet's camera aligns with one of the available cutouts. If it does not, this case may not be fully compatible with your specific tablet variant.

6. SPECIFICATIONS

Feature	Detail
Product Dimensions	0.39 x 0.39 x 0.39 inches
Item Weight	2.46 ounces
ASIN	B0DGDXXQH1L
Special Features	Card insertion, Stash the change, Thickened anti-drop corner protector + folding stand
Form Factor	Flip Case
Color	Brown
Compatible Devices	Xgody R15 11"
Shell Type	Hybrid
Material	Premium durable synthetic leather (PU Leather)

7. WARRANTY AND SUPPORT

Aroepurt stands behind the quality of its products. While specific warranty details may vary by region and retailer, generally, products are covered against manufacturing defects for a reasonable period from the date of purchase.

For Support:

- If you have questions, require assistance, or experience issues not covered in this manual, please contact the retailer where you purchased the product.
- You may also visit the official Aroepurt website for potential support resources or contact information. Please have your product model (B0DGDXXQH1L) and purchase details ready when seeking support.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DGDXXH1L>

More documents and user manuals: **<https://manuals.plus/>**