

## Acouto Acoutondk73gbye9

# Acouto 1080P HD Action Camera Instruction Manual

Model: Acoutondk73gbye9

## 1. INTRODUCTION

---

This manual provides essential information for the safe and effective use of your Acouto 1080P HD Action Camera. Please read it thoroughly before operating the device and retain it for future reference. This compact action camera is designed for capturing high-definition video and photos during various outdoor activities, featuring a wide-angle lens, electronic image stabilization, and connectivity for real-time viewing and sharing.

## 2. SAFETY INFORMATION

---

- Do not expose the camera to extreme temperatures, direct sunlight for prolonged periods, or corrosive materials.
- While the camera features an ABS body wrap resistant to rain and splash water, it is not designed for submersion unless explicitly stated with a waterproof housing. Avoid direct water exposure beyond splashes.
- Keep the device away from strong magnetic fields.
- Use only approved charging cables and power adapters.
- Do not attempt to disassemble or modify the camera. This will void the warranty and may cause damage.
- Ensure all mounts are securely fastened before engaging in activities to prevent the camera from falling.

## 3. PACKAGE CONTENTS

---

Verify that all items are present in your package:

- 1 x Acouto Small Action Camera

- 1 x Helmet Mount
- 4 x Mounting Accessories
- 1 x Bike Mount
- 2 x Data Cables (USB-A to USB-C, USB-C to USB-C)
- 1 x Silicone Case



Image: The Acouto Action Camera displayed with all its included accessories, such as helmet mount, bike mount, various adapters, data cables, and a silicone case.

## 4. SETUP

---

### 4.1. Charging the Camera

Before first use, fully charge the camera. Connect one of the provided data cables to the camera's charging port and the other end to a USB power source (e.g., computer, wall adapter). The charging indicator light will show the charging status.

### 4.2. Inserting a Memory Card

The camera supports up to 128GB small memory cards (not included). Locate the memory card slot on the camera. Gently insert the memory card with the contacts facing the correct direction until it clicks into place. Ensure the camera is powered off before inserting or removing the memory card.

### 4.3. Mounting the Camera

Use the included helmet mount or bike mount to secure the camera for your activities. Ensure the mount is firmly attached to your helmet or bicycle handlebars. The camera can be attached to the mount using the provided accessories.



Image: The Acouto Action Camera securely mounted on the handlebar of a motorcycle, demonstrating its use during travel.

### 4.4. App Connection

To connect the camera to your smartphone, scan the QR code provided on the packaging to download the dedicated application. Once installed, enable fidelity (Wi-Fi) on your phone and connect to the camera's network. This allows for real-time footage viewing and control without consuming mobile data.



Image: A hand holding a smartphone displaying various captured videos and images, with the Acouto Action Camera and a Wi-Fi signal icon indicating connectivity for immediate sharing.

## 5. OPERATING INSTRUCTIONS

---

### 5.1. Power On/Off

Press and hold the power button (usually located on the side) for a few seconds to turn the camera on or off.

### 5.2. Recording Video

Once powered on, press the record button to start video recording. Press it again to stop. The camera captures 1080P HD footage.

### 5.3. Taking Photos

Switch to photo mode (if applicable, refer to app interface) and press the shutter button to capture still images.

### 5.4. Electronic Image Stabilization

The camera features built-in electronic image stabilization to reduce blur and shake, resulting in smoother footage during dynamic activities.



Image: A visual comparison showing the effect of electronic image stabilization, with blurred images on the left and clear, stable images on the right, demonstrating enhanced anti-shake capabilities.

## 5.5. Loop Recording

The camera supports loop recording, which automatically overwrites the oldest files when the memory card is full. This ensures continuous recording without manual intervention.

## 5.6. Recording While Charging

The camera can record continuously even while connected to a power source and charging.

## 5.7. Using the App

The dedicated app allows you to:

- View live footage from the camera.
- Start and stop recording.
- Adjust camera settings.
- Download and share recorded content to your smartphone.

## 6. MAINTENANCE

---

- **Cleaning:** Use a soft, dry cloth to clean the camera body. For the lens, use a specialized lens cleaning cloth and solution.
- **Storage:** Store the camera in a cool, dry place away from direct sunlight when not in use.
- **Battery Care:** For optimal battery life, avoid fully discharging the battery frequently. If storing for extended periods, charge the battery to about 50%.
- **Firmware Updates:** Check the manufacturer's website or app for any available firmware updates to ensure optimal performance.

## 7. TROUBLESHOOTING

---

- **Camera not turning on:** Ensure the battery is charged. Connect to a power source and try again.
- **Recording issues:** Check if a memory card is inserted correctly and has sufficient free space. Format the memory card if necessary (this will erase all data).
- **App connectivity problems:** Ensure Wi-Fi is enabled on your phone and you are connected to the camera's network. Restart both the camera and your phone.
- **Unstable footage:** Ensure the camera is securely mounted. Electronic image stabilization is active,

but extreme vibrations may still affect footage quality.

## 8. SPECIFICATIONS

---

Feature	Specification
Model Number	Acoutondk73gbye9
Material	ABS
Battery Type	Lithium battery (built-in)
Battery Capacity	1200mAh
Video Resolution	1980x1080 (1080P HD)
Memory Card Support	Up to 128GB (small memory card, not included)
Connectivity	Fidelity (Wi-Fi) for app control
Features	Wide-angle lens, Electronic Image Stabilization, HiFi microphone, Loop Recording, Recording while charging
Package Dimensions	5.51 x 3.15 x 2.76 inches
Item Weight	6.5 ounces

## 9. WARRANTY AND SUPPORT

---

For warranty information or technical support, please refer to the documentation included with your purchase or contact Acouto customer service through the retailer where the product was purchased. Please have your model number (Acoutondk73gbye9) and purchase date available when contacting support.