



[Manuals.plus](#) /

› [Furinno](#) /

› Furinno Moretti TV Stand (Model FM19203WHSWH) Instruction Manual

Furinno FM19203WHSWH

Furinno Moretti TV Stand (Model FM19203WHSWH) Instruction Manual

3-Tier Metal Frame Modern Entertainment Center

PRODUCT OVERVIEW

The Furinno Moretti TV Stand, Model FM19203WHSWH, is a 3-tier entertainment center designed for modern living spaces. It features a durable metal frame and open shelves, providing storage for electronic devices and media accessories. This stand is suitable for televisions up to 70 inches. Its design aims for both functionality and a clean aesthetic.



Image: The Furinno Moretti TV Stand in solid white, showcasing its 3-tier design with a television and various media devices placed on its shelves.

SAFETY INFORMATION

To ensure safe use of your Furinno Moretti TV Stand, please observe the following:

- Keep the TV stand away from naked flames or direct heat sources to prevent damage or fire hazards.
- Do not exceed the maximum weight capacity of 120 lbs (54.4 kg) for the entire unit. The top shelf has a maximum weight capacity of 80 lbs (36.3 kg).
- Ensure the TV stand is placed on a flat, stable surface to prevent tipping.
- Distribute weight evenly across shelves to maintain stability.

PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. The package should contain:

- Assembly Instructions
- Hardware Pack (screws, connectors, etc.)
- Shelf Panels (Engineered Wood)

- Metal Frame Components



Image: An overhead view of the TV stand, illustrating the layout of its shelves and frame, useful for identifying components.

ASSEMBLY INSTRUCTIONS

Assembly of the Furinno Moretti TV Stand is designed to be straightforward. Follow the step-by-step instructions provided in the included assembly manual. All necessary hardware is supplied.

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify each part according to the assembly diagram in the manual.
3. Connect the metal frame components as instructed, ensuring all connections are secure.
4. Attach the shelf panels to the frame, tightening all fasteners as directed.
5. Once assembled, gently lift and place the stand in its desired location.




Image: A visual representation of the TV stand's structure, aiding in understanding the assembly process.

OPERATING INSTRUCTIONS

This section provides guidance for the proper use and placement of your TV stand.

- **TV Placement:** The top surface is designed to accommodate televisions up to 70 inches in size. Ensure the television's base fits securely within the dimensions of the top shelf.
- **Weight Capacity:** The top shelf supports up to 80 lbs (36.3 kg). The lower shelves support up to 30 lbs (13.6 kg).

kg) and 20 lbs (9 kg) respectively. Do not exceed these limits.

- **Media Storage:** Utilize the two open shelves for organizing electronic devices such as media players, gaming consoles, and soundbars, as well as media accessories.
- **Ventilation:** Ensure adequate airflow around electronic devices placed on the shelves to prevent overheating.



Image: The TV stand shown with a large television, indicating its capacity for TVs up to 78 inches (note: product description states up to 70 inches for this specific model, please refer to specifications for exact model compatibility).

CARE AND MAINTENANCE

Proper care will help maintain the appearance and longevity of your TV stand.

- **Cleaning:** Wipe the surfaces clean with a soft, damp cloth.
- **Chemicals:** Avoid using harsh chemicals, abrasive cleaners, or polishes, as these can damage the finish.
- **Spills:** Promptly clean up any spills to prevent staining or damage to the engineered wood.
- **Inspection:** Periodically check all fasteners and connections to ensure they remain tight. Retighten if necessary.

TROUBLESHOOTING

This section addresses common issues you might encounter.

- **Instability:** If the stand feels wobbly, ensure it is placed on a level surface. Check that all assembly screws

and connections are fully tightened.

- **Missing Parts:** If any parts are missing from the package, refer to the contact information in the Warranty and Support section for assistance.
- **Damaged Parts:** If any components arrived damaged, do not proceed with assembly. Contact customer support for replacement parts.

PRODUCT SPECIFICATIONS

Model Number	FM19203WHSWH
Brand	Furinno
Color	Solid White/White
Material	Engineered Wood, Metal
Dimensions (L x W x H)	70 x 15.98 x 21.89 inches (177.8 x 40.6 x 55.6 cm)
Item Weight	43.6 Pounds (19.8 kg)
TV Size Compatibility	Up to 70 inches
Total Weight Capacity	120 lbs (54.4 kg)
Top Shelf Weight Capacity	80 lbs (36.3 kg)
Number of Shelves	2 (plus top surface)
Assembly Required	Yes
UPC	840308812444




Image: An annotated diagram displaying the precise dimensions and weight limits for each section of the TV stand.

WARRANTY AND SUPPORT

Manufacturer's Warranty: This product is covered by a 1-year limited manufacturer's warranty. This warranty covers defects in materials and workmanship under normal use.

Customer Support: For assistance with assembly, missing parts, damaged components, or warranty claims, please contact Furinno customer service. Refer to the contact information provided in your product packaging or visit the official Furinno website for support details.

Please retain your proof of purchase for warranty purposes.