Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

K&F CONCEPT MS09

K&F Concept Selfie Stick Tripod MS09 User Manual

Model: MS09

1. Introduction

The K&F Concept Selfie Stick Tripod MS09 is a versatile accessory designed for photographers and videographers using cameras and smartphones. It functions as both a compact selfie stick and a stable tripod, offering adjustable height, panoramic shooting capabilities, and a convenient Bluetooth remote control. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance.



Figure 1: K&F Concept Selfie Stick Tripod MS09 with smartphone and remote.

2. Package Contents

Please verify that all items listed below are included in your package:

- Selfie Stick Tripod (MS09) x 1
- Phone Clip x 1
- Bluetooth Remote Control x 1

Figure 2: Contents of the product package.

3. Product Overview and Features

3.1 Key Components

- **Adjustable Extension Rod:** Five-section design for variable height.
- **Ball Head:** Provides 360° horizontal rotation and 90° vertical tilt.
- **Tripod Legs:** Foldable legs with anti-slip silicone pads for stability.
- **Phone Holder:** Compatible with smartphones 2.2-3.74 inches wide.
- **1/4" Screw:** Universal compatibility for cameras and other accessories.
- **Bluetooth Remote:** Detachable remote for wireless control within 10 meters.




Figure 3: Detailed product features including stainless steel connections and non-slip elements.

3.2 Feature Highlights

- **Adjustable Height:** Extends up to 34cm (13.38 inches) with 5-section legs for various shooting needs.
- **Strong Load Capacity:** Supports devices up to 2kg (4.4 lbs).
- **360° Panoramic Shooting:** Ball head allows for flexible angle adjustments.
- **Stable & Portable Design:** Lightweight (116g) with a wide base and anti-slip pads.
- **Bluetooth Remote Included:** For effortless shooting within 10 meters.



Figure 4: Adjustable height range of the tripod.

4. Setup

4.1 Attaching a Camera or Smartphone

1. **For Cameras:** Use the 1/4" screw on the ball head to securely attach your camera.
2. **For Smartphones:** Attach the provided phone clip to the 1/4" screw. Extend the phone clip to fit your smartphone (2.2-3.74 inches).

4.2 Extending the Selfie Stick

Gently pull the top section of the rod upwards to extend it. The 5-section design allows for smooth and controlled extension up to 34cm. Ensure each section is fully extended for stability.

4.3 Setting up as a Tripod

To convert to a tripod, hold the handle and push the bottom part outwards to deploy the three legs. Ensure the legs are fully spread for maximum stability. The anti-slip silicone pads on the feet will help secure it on various surfaces.



Figure 5: Two-in-one design: selfie stick and tripod mode.

4.4 Pairing the Bluetooth Remote

1. Turn on the Bluetooth remote control.
2. On your smartphone, go to Bluetooth settings and search for available devices.
3. Select the remote control from the list to pair. No password is required.
4. Once paired, you can use the remote to trigger your camera's shutter.

5. Operating Instructions

5.1 Using as a Selfie Stick

With your device securely attached, extend the rod to your desired length. Hold the comfortable grip and use the Bluetooth remote to capture photos or start/stop video recording.



Figure 6: Selfie shooting with the extended stick.

5.2 Using as a Tripod

Deploy the tripod legs and place the tripod on a flat, stable surface. Adjust the height and angle of your device using the extension rod and ball head. This mode is ideal for stable shots, time-lapses, or hands-free video calls.



Figure 7: Indoor shooting setup using the tripod.

5.3 Adjusting Angles

The integrated ball head allows for 360° horizontal rotation and 90° vertical tilt. Loosen the knob on the ball head to adjust the angle, then tighten it to secure your device in position.

5.4 Using the Bluetooth Remote

After successful pairing, press the button on the remote to remotely control your smartphone's camera shutter. The remote operates within a 10-meter range and supports up to 10 hours of continuous use.

Your browser does not support the video tag.

Video 1: K&F Concept Selfie Stick Tripod in use, demonstrating its features and versatility.

6. Maintenance

- Clean the tripod with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.

- Ensure the 1/4" screw and ball head mechanism are free from dust and debris for smooth operation.
- Store the tripod in a dry place away from extreme temperatures and direct sunlight.
- Regularly check all connections and screws to ensure they are tight and secure.

7. Troubleshooting

- **Device not stable on tripod:** Ensure legs are fully spread and placed on a flat surface. Check that the ball head knob is tightened.
- **Bluetooth remote not pairing:** Ensure the remote is charged and within 10 meters of your smartphone. Check your smartphone's Bluetooth settings and try re-pairing.
- **Extension rod sticking:** Clean the rod sections to remove any dirt or grit. Avoid forcing the extension.
- **Phone clip not holding device:** Ensure your smartphone's width is within the 2.2-3.74 inch range.

8. Specifications

Feature	Detail
Model Name	MS09
Maximum Height	34 Centimeters (13.38 inches)
Minimum Height	13 Centimeters (5.11 inches)
Item Weight	116 Grams (4.1 ounces)
Material	Aluminum
Load Capacity	Up to 2kg (4.4 lbs)
Compatible Devices	Camera, Smartphone
Phone Holder Width	2.2 - 3.74 inches
Special Feature	Foldable, Bluetooth Remote

9. Warranty and Support

For warranty information, technical support, or any inquiries regarding your K&F Concept Selfie Stick Tripod MS09, please refer to the official K&F Concept website or contact their customer service directly. Keep your purchase receipt as proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DGG61SBC

More documents and user manuals: **https://manuals.plus/**