

[Manuals.plus](#) /

› [SUPCASE](#) /

› SUPCASE MagSafe Wallet with Stand Instruction Manual

SUPCASE SUP-PhoneMagFlip

SUPCASE MagSafe Wallet with Stand Instruction Manual

Model: SUP-PhoneMagFlip

Brand: SUPCASE

PRODUCT OVERVIEW

The SUPCASE MagSafe Wallet with Stand is a versatile accessory designed to enhance your smartphone experience. It combines a secure card holder with an adjustable stand, offering convenience and functionality for daily use. This product is engineered with strong magnetic attachment and RFID blocking technology to protect your personal information.



Figure 1: Overview of the SUPCASE MagSafe Wallet with Stand, highlighting its wallet and stand capabilities.

KEY FEATURES

- **Strong Magnetic Lock:** Built-in magnets provide a magnetic force of up to 3000g, ensuring a tight and secure attachment to your iPhone.
- **Smart Card Storage:** Ingeniously designed to hold up to 5 cards, allowing easy access to credit cards, ID cards, and transportation cards.
- **Adjustable Stand:** Transforms into a stable phone stand with a simple fold, perfect for watching videos or FaceTime calls with multiple viewing angles.
- **Security & Privacy:** Includes 1 RFID Card with RFID blocking technology to prevent card demagnetization and identity theft.
- **Broad Compatibility:** Compatible with iPhone 16/15/14/13/12 series, Google, and Moto devices. Includes a magnetic ring for use with non-MagSafe devices and cases. (Note: Not compatible with iPhone 13 mini / iPhone 12 mini / Galaxy S25 series. Does not support Find My function).

SETUP

The SUPCASE MagSafe Wallet with Stand is designed for easy attachment and use.

Attaching to MagSafe Compatible Devices:

1. Ensure your iPhone (16/15/14/13/12 series) or MagSafe compatible case is clean and free of debris.
2. Align the MagSafe Wallet with Stand to the back of your device. The strong magnets will automatically snap it into place, ensuring a secure connection.

STRONG MAGNETIC LOCK

Locks on with 2x more strength than other magnetic wallets.



Magnetic Strength:

SUPCASE

3000g

Others

800g

Figure 2: Demonstrating the strong magnetic attachment of the wallet to a MagSafe-compatible iPhone.

Attaching to Non-MagSafe Devices:

For non-MagSafe devices or cases, use the included circular magnetic adhesive ring.

1. Clean the back surface of your phone or case thoroughly. Ensure it is a flat, smooth, and hard surface (not suitable for leather, textured, silicone, or uneven cases).
2. Carefully peel off the adhesive backing from the magnetic ring.
3. Center and firmly press the adhesive ring onto the desired location on your phone or case. Allow sufficient time for the adhesive to bond before attaching the wallet.
4. Once the ring is securely attached, you can magnetically attach the SUPCASE MagSafe Wallet with Stand to it.

COMPATIBILITY

Please check your model



iPhone 16/15/14/13/12 Series
Note: Not fit for iPhone 13 mini, 12 mini



MagSafe Cases



Work with MagSafe Ring 

iPhone 11 and below, Samsung, Google, Moto, etc.
and flat, smooth and hard surfaces cases
Note: Not for leather, textured, silicone & uneven cases

Figure 3: Compatibility details and usage of the included magnetic ring for non-MagSafe devices.

OPERATING INSTRUCTIONS

Using the Card Holder:

1. To access your cards, gently lift the metal lock cover on the wallet.
2. Insert or remove up to 5 cards into the designated slots. The shrapnel design ensures easy access and secure storage.
3. Close the metal lock cover to secure your cards.
4. Place the included RFID blocking card at the front of your stack of cards to protect against demagnetization and identity theft.

HOLDS UP TO 5 CARDS

Easy access to cards
and secure storage.



METAL LOCK COVER

Built-in metal lock cover
protects cards from losing
and scratches. It also
works as a kickstand.



Figure 4: Illustrates the card storage capacity and the metal lock cover for security.

RFID BLOCKING TECHNOLOGY

Against card demagnetization and identity theft.



EXTRA INCLUDED:
**1 RFID
SHIELDING CARDS**



Figure 5: The RFID blocking technology in action, protecting your card information.

Using the Adjustable Stand:

The wallet features a multi-angle adjustable stand for various viewing modes.

1. To deploy the stand, simply fold the wallet into the desired position. The robust hinge allows for stable

horizontal or vertical phone orientation.

2. Adjust the angle by gently pushing or pulling the stand until you achieve the optimal viewing position for activities like vlogging, browsing, or watching media.

Vlogging Mode



Browsing Mode



MULTI-SCENARIO


All-in-One,
convenient for your life



Smart Card Storage



Theatre Mode



Tripod Mode




Figure 6: Various usage scenarios demonstrating the adjustable stand's versatility.

MAINTENANCE

To ensure the longevity and optimal performance of your SUPCASE MagSafe Wallet with Stand, follow these general maintenance guidelines:

- **Cleaning:** Wipe the surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as they may damage the material.
- **Storage:** Store the wallet in a cool, dry place when not in use.
- **Magnetic Care:** Keep the magnetic surfaces clean and free of metallic particles to maintain strong attachment.
- **Hinge Care:** The stand's hinge is designed for durability. Avoid excessive force when adjusting to prevent damage.

TROUBLESHOOTING

If you encounter any issues with your SUPCASE MagSafe Wallet with Stand, consider the following common solutions:

- **Weak Magnetic Attachment:**
 - Ensure both the wallet's magnetic surface and your phone/case are clean and free of obstructions.
 - Verify that your phone or case is MagSafe compatible. If not, ensure the included magnetic adhesive ring is properly installed and fully bonded.
 - Avoid placing other magnetic objects between the wallet and your phone/case.
- **Cards Not Fitting or Sliding Out:**
 - Ensure you are not exceeding the 5-card capacity.
 - Check that cards are inserted correctly and fully into the slots.
 - Confirm the metal lock cover is fully closed to secure the cards.
- **Stand Instability:**
 - Ensure the stand is fully extended and locked into position for stability.
 - Verify that the surface on which the phone is placed is flat and stable.

If problems persist, please contact SUPCASE customer support for further assistance.

SPECIFICATIONS

Attribute	Detail
Product Dimensions	0.63 x 2.76 x 3.94 inches
Item Weight	5.6 ounces
Item Model Number	SUP-PhoneMagFlip
Brand	SUPCASE
Color	Black

Form Factor	Tripod
Material	Polycarbonate
Special Features	RFID Blocking, Card Holder, Adjustable Stand, Strong Magnets

SUPER HEIGHT SUPER STEADY

Horizontal and vertical switching is fast and flexible.



Dimensions:

3.94 x 2.79 x 0.63 inches

Weight:

130g / 4.6oz / 0.28lbs



Figure 7: Product dimensions and weight details.

WARRANTY AND SUPPORT

SUPCASE products are known for their durability and quality, exceeding military shock specification standards. For specific warranty information or technical support, please visit the official SUPCASE website or contact their customer service directly.

You can find more information and contact details on the [SUPCASE Brand Store](#).

© 2025 SUPCASE. All rights reserved.