

[Manuals.plus](#) /

› [PELLOR](#) /

› PELLOR Mini Digital Scoreboard Model VCTR06-A User Manual

PELLOR VCTR06-A

PELLOR Mini Digital Scoreboard Model VCTR06-A User Manual

Portable Magnetic Electronic Scoreboard

1. INTRODUCTION

Thank you for choosing the PELLOR Mini Digital Scoreboard. This portable electronic scoreboard is designed for various indoor and outdoor games, offering clear score tracking with an easy-to-read LED display and simple controls. Please read this manual carefully to ensure proper use and maintenance of your device.



Image 1.1: The PELLOR Mini Digital Scoreboard displaying scores.

Your browser does not support the video tag.

Video 1.1: An overview of the PELLOR Mini Digital Scoreboard, demonstrating its features and design.

2. PRODUCT FEATURES

- **Portable Design:** Compact and lightweight for easy transport.
- **Magnetic Back:** Built-in magnets allow attachment to metal surfaces.
- **High-Brightness LED Display:** Visible in various lighting conditions, including sunlight and dark environments.
- **Rechargeable Battery:** Integrated 900 mAh lithium battery for cordless operation.
- **Simple Controls:** Intuitive buttons for score and period adjustments.

- **Versatile Use:** Suitable for table tennis, cornhole, pickleball, badminton, basketball, volleyball, baseball, chess, and card games.



Image 2.1: The scoreboard being placed into a bag, highlighting its portable design.




Image 2.2: A diagram illustrating the magnetic function on the back of the scoreboard.

3. PACKAGE CONTENTS

Upon opening your PELLOR Mini Digital Scoreboard package, you should find the following items:

- 1 x PELLOR Mini Digital Scoreboard
- 1 x USB-C Charging Cable
- 1 x Storage Pouch
- 1 x User Manual (this document)



Image 3.1: The scoreboard, storage pouch, and USB-C charging cable included in the package.

4. SETUP

Before using your scoreboard for the first time, ensure it is fully charged. Refer to the Charging section for detailed instructions.

1. **Power On:** Hold the **GUEST +1 / PWR** button for 2 seconds to turn the scoreboard on.
2. **Placement:** Place the scoreboard on a flat, stable surface. If a metal surface is available, the built-in magnets can secure the scoreboard in place.

5. OPERATING INSTRUCTIONS

The PELLOR Mini Digital Scoreboard features intuitive buttons for easy score and period management.



Image 5.1: Layout of the control buttons on the PELLOR Mini Digital Scoreboard.

- **HOME Score Adjustment:**
 - Press **HOME +1** to increase the Home team's score by one.
 - Press **HOME -1** to decrease the Home team's score by one.
- **GUEST Score Adjustment:**
 - Press **GUEST +1** to increase the Guest team's score by one.
 - Press **GUEST -1** to decrease the Guest team's score by one.
- **Period Adjustment:**
 - Press **PERIOD +1** to advance the period count by one.
 - Press **PERIOD -1** to decrease the period count by one. If the value is less than 1, the period display will turn off.
- **Power On/Off:** Hold the **GUEST +1 / PWR** button for 2 seconds to turn the scoreboard on or off.
- **Reset Scores:** Hold the **GUEST -1 / RST** button for 2 seconds to reset all scores (Home, Guest, and Period) to zero.
- **Toggle Button Sound:** Press the **GUEST +1 / PWR** and **GUEST -1 / RST** buttons simultaneously to enable or disable the button beep sound.

Your browser does not support the video tag.

Video 5.1: A demonstration of key pressing operations, including score adjustment, reset, and sound toggle.

6. CHARGING INSTRUCTIONS

The scoreboard is equipped with a built-in 900 mAh lithium battery, providing approximately 4 hours of continuous use on a full charge.

- **Charging Method:** Use the provided USB-C cable to connect the scoreboard to a standard 5V USB power source (e.g., wall adapter, power bank, computer USB port).
- **Charging Time:** A full charge takes approximately 1.5 hours when the device is turned off.
- **Important Note:** This device supports standard 5V USB-C charging only. **Fast charging adapters/cables are NOT supported and may damage the device.**

① Plug in



NOTE: Fast charging is not supported.

② Power Bank



NOTE: Fast charging is not supported.

Charging Method:

Plug-in or power bank Charging for 1.5 hours can be used continuously for 4 hours. This device comes with standard charging only. Please also note that fast charging is not supported.

Image 6.1: Illustrations of charging the scoreboard using a wall adapter and a power bank.



Long Battery Life
Built-in 900 mAh Rechargeable
Lithium Battery

Image 6.2: The scoreboard being charged via its USB-C port.

Your browser does not support the video tag.

Video 6.1: A demonstration of connecting the scoreboard to a standard 5V USB-C charger.

7. CARE AND MAINTENANCE

- **Cleaning:** Wipe the scoreboard with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the scoreboard in a cool, dry place away from direct sunlight and extreme temperatures. Use the provided storage pouch to protect it from scratches when not in use.
- **Water Exposure:** The scoreboard is not waterproof. Avoid exposure to water or high humidity.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Scoreboard does not turn on.	Battery is depleted.	Charge the scoreboard for at least 1.5 hours using a standard 5V USB-C charger.
Short battery life.	Battery not fully charged or aging battery.	Ensure the scoreboard is fully charged before use. If the issue persists, contact customer support.
Buttons are unresponsive or stuck.	Debris under buttons or mechanical issue.	Gently clean around the buttons. Avoid pressing buttons with excessive force. If buttons remain stuck, contact customer support.
Display is dim or flickering.	Low battery or environmental factors.	Charge the scoreboard. Ensure it is not exposed to extreme temperatures.

9. SPECIFICATIONS

- **Model Name:** VCTR06-A
- **Dimensions (LxWxH):** 7.09 x 0.87 x 1.85 inches (18 x 2.2 x 4.7 cm)
- **Weight:** 8 ounces (0.23 kg)
- **Material:** Plastic
- **Battery:** Built-in 900 mAh Lithium Battery
- **Charging:** Standard 5V USB-C (Fast charging not supported)
- **Display:** High-brightness LED
- **Color:** Red Black




Image 9.1: The scoreboard with its physical dimensions indicated.

10. WARRANTY INFORMATION

The PELLOR Mini Digital Scoreboard comes with a **1-Year Limited Warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or improper charging. Please retain your proof of purchase for warranty claims.

11. CUSTOMER SUPPORT

If you encounter any issues or have questions regarding your PELLOR Mini Digital Scoreboard that are not addressed in this manual, please contact our customer support team. For the most up-to-date contact information, please refer to the

product packaging or the official PELLOR website.

© 2026 PELLOR. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question