

[Manuals.plus](#) /

› [EVISTR](#) /

› EVISTR 128GB Digital Voice Recorder User Manual

EVISTR L357128G

EVISTR 128GB Digital Voice Recorder User Manual

Model: L357128G

INTRODUCTION

This manual provides detailed instructions for the EVISTR 128GB Digital Voice Recorder, Model L357128G. Please read this manual thoroughly before using the device to ensure proper operation and to maximize its features. This device is designed for high-quality audio recording in various settings, including conferences, meetings, interviews, and personal notes.

PRODUCT OVERVIEW

The EVISTR L357128G is a digital voice recorder featuring a 128GB storage capacity, dual microphones with noise cancellation, and voice-activated recording. It supports MP3 and WAV audio formats and offers a clear 1-inch TFT color display for easy navigation.

Package Contents

- 1 x EVISTR Digital Voice Recorder (L357128G)
- 1 x USB-C Charging Cable
- 1 x Earphones

Device Layout

Familiarize yourself with the buttons and ports on your device.

Fonctionnement simple



Image: Front view of the EVISTR Digital Voice Recorder, highlighting the REC, STOP, MENU, and PLAY buttons. This image illustrates the simple control layout for basic operations.

- **REC Button:** Initiates recording.
- **STOP Button:** Stops recording and saves the file.
- **MENU Button:** Accesses device settings and confirms selections.
- **PLAY/PAUSE Button:** Starts or pauses playback.
- **Volume Buttons:** Adjusts playback volume.
- **USB-C Port:** For charging and data transfer.
- **Headphone Jack:** For connecting earphones.
- **Power Switch:** Turns the device on/off.

SETUP

Charging the Device

Before first use, fully charge the voice recorder. Connect the provided USB-C cable to the device's USB-C port and the other end to a computer's USB port or a compatible USB wall adapter. A full charge takes approximately 2 hours and provides up to 20 hours of continuous recording or 35 hours of continuous playback.



Image: The EVISTR Digital Voice Recorder connected to a laptop via its USB-C cable, displaying a "Charged" status on its screen. This illustrates the charging and data transfer connection.

Powering On/Off

Locate the power switch on the side of the device. Slide it to the 'ON' position to power on the recorder. Slide it to the 'OFF' position to power off the recorder.

OPERATING INSTRUCTIONS

Basic Recording

1. Ensure the device is powered on.
2. Press the **REC** button to start recording. The screen will display recording time and a waveform.

3. To stop recording and save the file, press the **STOP** button.

1536Kpbs Microphone à haute sensibilité

Enregistrement avec annulation du bruit

Puce Pro Audio

7 niveaux de gain d'enregistrement

Niveau de réduction du bruit réglable

1536 Kbps

Audio stéréo clair

MP3 32Kbps 64Kbps 128 Kbps

WAV 512Kbps 768Kbps 1024Kbps 1536Kbps

Image: The EVISTR Digital Voice Recorder's screen showing active recording with audio levels and a waveform. Text highlights the 1536Kbps high sensitivity microphone and noise cancellation feature.

Voice-Activated Recording (VOR/AVR)

The voice-activated recording feature allows the device to record only when sound is detected, conserving memory and reducing silent periods. You can adjust the sensitivity level.

1. Navigate to the settings menu using the **MENU** button.
2. Select 'AVR Mode' or 'Voice Activated Recording'.
3. Choose a sensitivity level (e.g., Level 1 for high sensitivity, Level 7 for low sensitivity).
4. Exit the menu. The device will now record only when sound is present above the set threshold.

Enregistrement activé par la voix

Capturer en parlant seulement Sauter le silence

adjustable 7 levels of voice-activated sensitivity



Image: The EVISTR Digital Voice Recorder's display illustrating the voice-activated recording feature with adjustable sensitivity levels (Level 1 to Level 7, from 50dB to 70dB). This shows how the device can be configured to capture sound only when detected.

Playback

1. From the main screen, use the navigation buttons to select a recorded file.
2. Press the **PLAY** button to start playback.
3. During playback, use the volume buttons to adjust the sound level.
4. Press **PLAY** again to pause, and again to resume.
5. To fast forward or rewind, press and hold the navigation buttons during playback.
6. The A-B repeat function allows you to loop a specific segment of an audio file. Access this feature through the menu during playback.

File Management and Transfer

Recorded files are automatically saved with a timestamp (YYYY-MM-DD-HH-MM-SS.WAV or .MP3) for easy organization.



Image: The EVISTR Digital Voice Recorder's screen showing a recorded file named with a timestamp (e.g., 20230510104003.WAV). This demonstrates the automatic file naming convention for easy organization.

To transfer files to a computer (Windows or Mac):

1. Connect the recorder to your computer using the supplied USB-C cable.
2. The device will appear as a removable disk drive.
3. Open the drive and locate your recorded files (typically in a folder named 'RECORD' or similar).
4. Drag and drop files to your computer or copy/paste them as needed.



Image: The EVISTR Digital Voice Recorder displaying a password entry screen. This illustrates the device's password protection feature, allowing users to secure their recordings.

For enhanced security, the device supports password protection. Access this feature in the settings menu to set or change your password.

MAINTENANCE

- Keep the device dry and away from extreme temperatures.
- Clean the device with a soft, dry cloth. Do not use liquid cleaners.
- Avoid dropping the device or subjecting it to strong impacts.
- Regularly back up important recordings to your computer to prevent data loss.
- Periodically check for firmware updates on the EVISTR official website.

TROUBLESHOOTING

Problem	Possible Cause / Solution
Device does not power on.	Battery is depleted. Charge the device fully. Ensure the power switch is in the 'ON' position.
Cannot record.	Memory is full. Transfer files to a computer and delete them from the device. Device may be in playback mode; stop playback before recording.
Poor recording quality.	Microphone may be obstructed. Ensure the device is placed in an open area. Adjust recording sensitivity or disable voice activation in noisy environments. Check recording format settings (WAV offers higher quality than MP3).
Device not recognized by computer.	Ensure the USB-C cable is securely connected. Try a different USB port or cable. Restart both the recorder and the computer.
Voice activation not working as expected.	Adjust the VOR/AVR sensitivity level in the settings. Higher sensitivity (lower level number) detects quieter sounds. Ensure VOR/AVR is enabled.

SPECIFICATIONS

- Model Number:** L357128G
- Brand:** EVISTR
- Memory Storage Capacity:** 128 GB
- Digital Recording Time:** Up to 10240 hours (depending on quality settings)
- Audio Formats:** MP3, WAV
- Recording Quality:** Up to 1536Kbps (WAV)
- Microphone:** Built-in, Dual MIC with Noise Cancellation, Speech Recognition
- Display:** 1-inch TFT Color Screen
- Hardware Interface:** USB-C
- Headphone Jack:** 3.5 mm
- Battery:** 1 Lithium-ion (included)
- Charging Time:** Approximately 2 hours
- Continuous Recording Time:** Up to 20 hours
- Continuous Playback Time:** Up to 35 hours
- Item Weight:** 160 Grams
- Compatible Devices:** Personal Computer (Windows, Mac)
- Country of Origin:** China

WARRANTY AND SUPPORT

The EVISTR L357128G Digital Voice Recorder comes with an **18-month warranty** from the date of purchase. For technical support, warranty claims, or further assistance, please contact EVISTR customer service through their official website or the retailer where the product was purchased. Please have your model number (L357128G) and proof of purchase ready when contacting support.



