1Mii SafeFly Pro

1Mii SafeFly Pro Bluetooth 5.3 Transmitter Receiver User Manual

Model: SafeFly Pro

Your ultimate wireless audio companion for travel and home entertainment.

Product Overview

The 1Mii SafeFly Pro is a compact and powerful Bluetooth 5.3 audio adapter that functions as both a transmitter (TX) and a receiver (RX). Equipped with a clear OLED screen, it provides real-time information on battery level, volume, paired devices, and audio codecs. Its wide compatibility and dual connection capability make it perfect for sharing audio experiences on the go or at home.

Image: The 1Mii SafeFly Pro Bluetooth 5.3 Transmitter Receiver, showcasing its compact design and integrated audio jack.

What's Included

Your 1Mii SafeFly Pro package contains the following items:

- SafeFly Pro Bluetooth Audio Adapter
- USB-C Charging Cable
- 3.5mm Female to Female Audio Adapter
- Keychain Attachment
- User Manual

Image: All components included in the 1Mii SafeFly Pro retail package, laid out clearly.

Video: An unboxing video demonstrating the contents of the 1Mii SafeFly Pro package and initial handling of the device.

Device Layout

Familiarize yourself with the buttons and ports on your SafeFly Pro:



Image: Detailed diagram of the SafeFly Pro, highlighting its audio plug protector, flexible audio cable, OLED display screen, M key, OK key, TX/RX sliding switch, one-click reset button, and USB-C charging port.

- **OLED Display Screen:** Shows device name, Bluetooth codec, volume level, and battery level.
- **M Key:** Selects connected device or switches Bluetooth decoding format.
- **OK Key:** Power ON/OFF (long press for 2s), confirms connected device, enters pairing mode (long press for 2s), or Play/Pause.
- **TX/RX Sliding Switch:** Toggles between Transmitter (TX) and Receiver (RX) modes.
- **USB-C Charging Port:** For charging the device.
- **3.5mm Audio Connection:** For connecting to audio sources or output devices.

Setup and Pairing

Charging the Device

Before first use, fully charge the SafeFly Pro using the provided USB-C charging cable. Connect the USB-C end to the

device and the USB-A end to a compatible USB power adapter (not included). A full charge takes approximately 1.5 hours and provides up to 30 hours of playtime.

Transmitter (TX) Mode Setup

Use TX mode to transmit audio from non-Bluetooth devices (e.g., airplane entertainment systems, TVs, gym equipment) to your Bluetooth headphones or speakers.

1. Slide the TX/RX switch to **TX**.
2. Plug the SafeFly Pro's 3.5mm audio jack into the audio output port of your non-Bluetooth device.
3. Long press the **OK** button for 2 seconds to enter pairing mode. The screen will display 'Searching'.
4. Put your Bluetooth headphones or speakers into pairing mode.
5. The SafeFly Pro will automatically search for and connect to nearby Bluetooth devices. Once connected, the device name will appear on the OLED screen.
6. To connect a second pair of headphones, press the **M** button to select an empty slot (A or B), then long press **OK** for 2 seconds to enter pairing mode for the second device.

Image: The SafeFly Pro connected to an airplane seat's audio jack, enabling wireless audio streaming to Bluetooth headphones.

Video: A demonstration of the 1Mii SafeFly Pro's functionality as a transmitter, showing connection to an airplane entertainment system and pairing with Bluetooth headphones.

Receiver (RX) Mode Setup

Use RX mode to receive audio from your Bluetooth-enabled devices (e.g., smartphone, tablet) and play it through non-Bluetooth audio systems (e.g., wired speakers, car stereo, boat systems).

1. Slide the TX/RX switch to **RX**.
2. Plug the SafeFly Pro's 3.5mm audio jack into the audio input port of your wired speaker or car stereo.
3. Long press the **OK** button for 2 seconds to enter pairing mode. The screen will display 'Searching'.
4. On your smartphone or tablet, enable Bluetooth and search for 'SafeFly Pro' in the list of available devices. Select it to connect.
5. Once connected, the device name will appear on the OLED screen.
6. To connect a second smartphone, press the **M** button to select an empty slot (A or B), then long press **OK** for 2 seconds to enter pairing mode for the second device.

Operating Instructions

Power On/Off

Long press the **OK** button for 2 seconds to power the device ON or OFF.

Switching Modes (TX/RX)

Use the physical TX/RX sliding switch on the side of the device to change between Transmitter and Receiver modes. Ensure the device is powered off before switching modes for optimal performance.

Using the M and OK Buttons

- **M Button:** In pairing mode, press once to select the connected device. In transmission mode, press to switch the Bluetooth decoding format (e.g., AptX LL, AptX HD, SBC).
- **OK Button:** Short press to Play/Pause audio. Long press for 2 seconds to enter pairing mode or power ON/OFF.

Understanding the OLED Screen

The OLED screen provides crucial information at a glance:

- **Volume Level:** Indicated by a numerical value (e.g., '15').
- **Audio Format:** Displays the active Bluetooth codec (e.g., SBC, AptX, AptX LL, AptX HD, AptX Adaptive).
- **Battery Level:** An icon indicates the remaining battery charge.
- **Paired Devices:** Shows the names of up to two connected devices (A and B).

Image: A visual representation of the SafeFly Pro operating in both Transmitter (TX) and Receiver (RX) modes, illustrating typical use cases.

Image: The SafeFly Pro enabling dual headphone connection to a television, allowing two users to enjoy audio simultaneously.

Maintenance

To ensure the longevity and optimal performance of your 1Mii SafeFly Pro, follow these maintenance guidelines:

- Keep the device clean by wiping it with a soft, dry cloth. Avoid using harsh chemicals or abrasive cleaners.
- Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- When not in use, utilize the keychain attachment to protect the 3.5mm audio plug from damage.
- Avoid dropping the device or subjecting it to strong impacts.

Troubleshooting

If you encounter issues with your SafeFly Pro, try the following solutions:

- **Device not powering on:** Ensure the device is fully charged. Connect it to a power source and try again.
- **Cannot pair with headphones/phone:**
  - Ensure the SafeFly Pro is in the correct TX or RX mode.
  - Make sure both the SafeFly Pro and your target device are in pairing mode.
  - Move the devices closer to each other.
  - Clear previous pairing records on both devices and try pairing again.
- **No sound or low volume:**
  - Check the volume levels on both the SafeFly Pro (via OLED screen) and the connected audio device/headphones.
  - Ensure the 3.5mm audio connection is fully inserted into both the SafeFly Pro and the audio source/output.
  - Verify that the correct audio input/output is selected on your external device (e.g., TV, speaker).
- **Sound quality issues (e.g., static, distortion):**
  - Ensure there are no strong electromagnetic interferences nearby.
  - Try switching the Bluetooth decoding format using the M button.
  - Reduce the distance between the SafeFly Pro and the connected Bluetooth device.

Specifications

Feature	Detail
Product Dimensions	2.2 x 1.1 x 0.47 inches
Item Weight	0.64 ounces
Bluetooth Version	5.3
Audio Codecs	AptX Low Latency, AptX HD, AptX Adaptive, AptX, AAC, SBC
Connectivity Technology	Bluetooth, AUX
Power Source	Battery Powered (1 Lithium Polymer battery included)
Battery Life	Up to 30 hours of playtime
Manufacturer	1Mii

Safety Information

Please read and follow these safety guidelines to prevent injury or damage to the device:

- Do not expose the device to extreme temperatures (hot or cold), direct sunlight, or high humidity.
- Avoid dropping, disassembling, or attempting to repair the device yourself. This will void the warranty.
- Dispose of the battery and device according to local regulations. Do not dispose of in household waste.
- Keep out of reach of children.

Warranty and Support

1Mii products are designed for reliability and performance. For any product inquiries, technical support, or warranty claims, please contact 1Mii customer service directly. Refer to the official 1Mii website or the contact information provided in your product packaging for details.

© 2024 1Mii. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question