

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [JVC](#) /

› [JVC HAA4TB True Wireless Earbuds User Manual](#)

## JVC HAA4TB

# JVC HAA4TB True Wireless Earbuds User Manual

Model: HAA4TB | Brand: JVC

## INTRODUCTION

This manual provides detailed instructions for the safe and efficient use of your JVC HAA4TB True Wireless Earbuds. Please read this manual thoroughly before using the product and retain it for future reference. The JVC HAA4TB earbuds feature a lightweight design, 12mm driver units for clear audio, Bluetooth 5.1 connectivity, and a compact charging case. They offer up to 30 hours of total playback time, are IPX4 rated for splash resistance, and include multiple sound modes for a customized listening experience.

## WHAT'S IN THE BOX

Verify that all items are present before initial use:

- JVC HAA4TB True Wireless Earbuds (Left and Right)
- Wireless Charging Case
- USB Charging Cable
- User Manual

## PRODUCT OVERVIEW

Familiarize yourself with the components and features of your JVC HAA4TB True Wireless Earbuds.



Image: The JVC HAA4TB True Wireless Earbuds, shown in black, highlighting their sleek design.



Image: A person wearing JVC HAA4TB earbuds, with the charging case visible, illustrating their glossy and stylish appearance.

## Key Features:

- **12mm Driver Units:** Designed for enhanced audio clarity and powerful sound.
- **Bluetooth 5.1:** Provides a stable and efficient wireless connection.
- **Long Battery Life:** Up to 7.5 hours of playback from the earbuds, with an additional 22.5 hours from the charging case, totaling up to 30 hours.
- **IPX4 Splash Proof:** Resistant to sweat and light splashes, suitable for various activities.
- **Three Sound Modes:** Customize your audio experience with Normal, Bass, and Clear modes.
- **Single-Ear Use:** Either earbud can be used independently.
- **Effortless Touch Control:** Manage playback, calls, and sound modes with intuitive touch gestures.
- **Automatic Connection:** Earbuds automatically power on and connect to your device when removed from the case.
- **Lightweight Design:** Ensures comfortable wear for extended periods.

## SETUP

### 1. Initial Charging

1. Place both earbuds into the charging case.
2. Connect the USB charging cable to the charging case and a power source.
3. Allow approximately 2 hours for a full charge of both the earbuds and the charging case.
4. The charging case typically has indicator lights to show charging status. Refer to the case for specific light

patterns.



Image: The JVC HAA4TB earbuds inside their charging case, illustrating the compact and portable design.



Image: The JVC HAA4TB charging case, emphasizing its slim design and up to 30 hours of total playtime.

## 2. Bluetooth Pairing

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically power on and enter pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth.
4. Search for "JVC HAA4TB" in the list of available Bluetooth devices.
5. Select "JVC HAA4TB" to connect. Once connected, you will hear an audio confirmation.
6. The earbuds will automatically reconnect to the last paired device when removed from the case, if Bluetooth is enabled on the device.

## OPERATING INSTRUCTIONS

### Touch Controls

The JVC HAA4TB earbuds feature intuitive touch controls on each earbud. Specific functions may vary slightly, but common controls include:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold on either earbud.

- **Activate Voice Assistant:** Triple tap on either earbud.



Image: The JVC HAA4TB earbuds shown with water splashes, highlighting their IPX4 splash-proof design and the convenience of touch controls.

## Sound Modes

The earbuds offer three distinct sound modes to optimize your listening experience:

- **Normal Mode:** Balanced audio for general listening.
- **Bass Mode:** Enhanced bass for a richer, deeper sound.
- **Clear Mode:** Emphasizes vocal clarity, ideal for podcasts or calls.

To switch between sound modes, press and hold the touch sensor on the right earbud for approximately 2 seconds until you hear an audio prompt indicating the mode change.




Image: A visual representation of the three customizable sound modes: Bass, Normal, and Clear, available on the JVC HAA4TB earbuds.

## Single-Ear Use

You can use either the left or right earbud independently. Simply remove one earbud from the charging case, and it will automatically connect to your device. This feature allows you to stay aware of your surroundings while enjoying audio.



Image: A person using a single JVC HAA4TB earbud, demonstrating the convenience of single-ear use for situational awareness.

## MAINTENANCE

### Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Ensure charging contacts on both earbuds and case are clean and free of debris for optimal charging.

### Water Resistance (IPX4)

The earbuds are rated IPX4, meaning they are resistant to splashing water from any direction. This makes them suitable for workouts and light rain. However, they are not designed for submersion in water. Do not expose them to running water or wear them while swimming or showering.

### Storage

When not in use, store the earbuds in their charging case to protect them and ensure they remain charged. Store the product in a cool, dry place away from extreme temperatures and direct sunlight.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Earbuds do not power on.	Low battery.	Place earbuds in the charging case and charge fully.
Cannot pair with device.	Bluetooth is off on device; earbuds not in pairing mode; too far from device.	Ensure Bluetooth is enabled. Open case to activate pairing mode. Keep earbuds within 10 meters of device. Try forgetting the device and re-pairing.
No sound or low volume.	Volume too low; earbud placement; connection issue.	Adjust volume on your device. Ensure earbuds are properly seated in your ears. Reconnect Bluetooth.
Charging case not charging.	Cable issue; power source issue; dirty contacts.	Try a different USB cable or power adapter. Ensure charging contacts are clean.
One earbud has no sound.	Individual earbud connection issue; low battery on one earbud.	Place both earbuds back in the case, close it, then reopen to reset connection. Ensure both earbuds are charged.

## SPECIFICATIONS

Feature	Detail
Model Name	HAA4T True Wireless
Bluetooth Version	5.1
Bluetooth Range	10 Meters
Audio Driver Size	12 Millimeters
Frequency Range	20 Hz - 20,000 Hz
Impedance	16 Ohm
Battery Life (Earbuds)	Up to 7.5 Hours
Total Battery Life (with Case)	Up to 30 Hours
Charging Time	2 Hours (Earbuds & Case)
Water Resistance Level	IPX4 (Splash Proof)
Control Type	Touch Control
Weight (Item)	2.89 ounces
Included Components	Headphones, Wireless Charging Case, Cable, User Manual

## WARRANTY AND SUPPORT

## Warranty Information

JVC products are manufactured to high quality standards. For specific warranty details, including coverage period and terms, please refer to the warranty card included with your product or visit the official JVC website. Retain your proof of purchase for warranty claims.

## Customer Support

If you encounter any issues not covered in this manual or require further assistance, please contact JVC customer support. Contact information can typically be found on the official JVC website or on the product packaging.

For more information, visit the official [JVC Store](#).

