



[Manuals.plus](#) /

> [HOMCOM](#) /

> HOMCOM Electric Recliner Massage Chair User Manual - Model 700-156V90LG

## HOMCOM 700-156V90LG

# HOMCOM Electric Recliner Massage Chair User Manual

Model: 700-156V90LG

## 1. INTRODUCTION

Thank you for choosing the HOMCOM Electric Recliner Massage Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new chair. Please read it thoroughly before use and retain it for future reference.

## 2. SAFETY INFORMATION

To ensure safe operation and prevent injury or damage, please observe the following safety guidelines:

- **Assembly:** Follow all assembly instructions carefully. Ensure all components are correctly installed and tightened before use.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 150 kg (330 lbs). Overloading can cause instability and damage.
- **Stability:** Always ensure the chair is placed on a stable, level surface. Avoid using on uneven floors.
- **Adjustable Functions:** When adjusting the recline or footrest, ensure there are no obstructions or persons in the path of moving parts to prevent pinching or injury.
- **Children and Pets:** Keep children and pets away from the chair's moving parts during operation.
- **Electrical Safety:** Ensure the power cord is not pinched or damaged. Do not operate the chair with a damaged cord or plug. Disconnect from power before cleaning or maintenance.
- **Intended Use:** This chair is designed for indoor use only for relaxation, reading, and sleeping. Do not use it for purposes other than its intended design.

## 3. PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning assembly. If any parts are missing or damaged, contact customer service.

- Chair Backrest
- Chair Seat with Armrests

- Footrest Assembly
- Swivel Table
- Remote Control
- Power Adapter
- Assembly Hardware (screws, washers, etc.)
- User Manual



Figure 3.1: HOMCOM Electric Recliner Massage Chair in beige, shown in an upright position with its swivel table and cup holder. This image provides an overview of the assembled product.

## 4. ASSEMBLY AND SETUP

Assembly is required. Please follow the step-by-step instructions provided in the included assembly guide. Ensure all connections are secure before use.

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.

2. Attach the backrest to the seat base, ensuring the connection points align and lock securely.
3. Connect the footrest assembly to the main chair frame.
4. Install the swivel table into its designated slot on the armrest.
5. Connect the power adapter to the chair's power input and then to a suitable electrical outlet.
6. Place the remote control in the side pocket for easy access.



Figure 4.1: Dimensions of the chair. Refer to this diagram for space planning and to ensure proper clearance for reclining.

## 5. OPERATING INSTRUCTIONS

### 5.1 Reclining Mechanism

The chair features an electric reclining mechanism, allowing for an inclination of up to 145 degrees. The footrest operates independently of the backrest.

- To recline: Use the control buttons located on the side of the chair or on the remote control to adjust the backrest and footrest to your desired position.

- To return to upright: Press the corresponding buttons to bring the backrest and footrest back to their original positions.



Figure 5.1: Demonstrates the chair's recline function, allowing for a maximum inclination of 145 degrees for optimal relaxation.

## 5.2 Massage Functions

The chair is equipped with an 8-point vibrating massage system, targeting areas from the back to the legs. Control the massage functions using the provided remote control.

- **Intensity Levels:** Select from 3 different intensity levels (Low, Medium, High) to suit your preference.
- **Massage Programs:** Choose from 4 distinct massage programs, each offering a unique pattern of vibration.
- **Timer:** Set the massage duration for 10, 20, or 30 minutes using the timer function on the remote control. The massage will automatically stop once the timer expires.

# MASSAGGIO VIBRANTE

✓ 3 intensità

✓ 4 modalità

✓ 8 punti



Figure 5.2: Visual representation of the 8 massage points and available settings (3 intensities, 4 modes).

## 5.3 Special Features

- **Swivel Table:** The integrated swivel table can be rotated for convenient access to drinks, books, or electronic devices.
- **Cup Holder:** An integrated cup holder in one of the armrests provides a secure place for your beverage.
- **Side Pockets:** Two side pockets offer storage for the remote control, magazines, or other small items.



Imbottitura  
spessa



Portabicchieri



Tasca  
laterale



Piedini  
retrattili



Vassoio  
da tavolo

Figure 5.3: Close-up of the chair's integrated features, including the cup holder, side pocket, and swivel table.



Figure 5.4: Detailed view of the cup holder, designed to securely hold beverages.

## 6. MAINTENANCE

---

Regular maintenance will prolong the life and appearance of your chair.

- **Cleaning:** Wipe the chair with a damp cloth. For stubborn stains, use a mild soap solution and then wipe with a clean, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Fabric Care:** The chair is upholstered in 100% polyester fabric. Avoid direct sunlight exposure to prevent fading.
- **Moving Parts:** Periodically check all screws and connections to ensure they are tight. Lubricate moving parts if necessary, following manufacturer recommendations.
- **Electrical Components:** Inspect the power cord and plug for any signs of damage. If damage is found, discontinue use and contact customer service.



Figure 6.1: Illustrates the internal construction of the chair, highlighting the durable materials used for comfort and longevity.

## 7. TROUBLESHOOTING

If you encounter any issues with your chair, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Chair does not recline or massage.	Power cord is disconnected or not fully plugged in. Power outlet is not functioning. Remote control batteries are dead.	Ensure the power cord is securely plugged into both the chair and the wall outlet. Test the outlet with another device. Replace remote control batteries if applicable (check manual for battery type).
Reclining mechanism is stiff or noisy.	Moving parts require lubrication. Obstruction in the mechanism.	Apply a silicone-based lubricant to the moving joints of the reclining mechanism. Check for any objects or debris obstructing the mechanism.

Problem	Possible Cause	Solution
Massage function is weak or inconsistent.	Incorrect intensity setting. Loose electrical connection.	Adjust the intensity level using the remote control. Check all electrical connections to the massage unit. If the problem persists, contact customer support.
Chair feels unstable.	Loose assembly bolts. Uneven floor surface.	Tighten all assembly bolts. Move the chair to a level surface or use shims to stabilize.

## 8. SPECIFICATIONS

Feature	Detail
Brand	HOMCOM
Model Number	700-156V90LG
Color	Beige
Material	100% Polyester Fabric, Foam Padding, Alloy Steel Frame
Overall Dimensions (Upright)	77L x 93W x 105H cm (30.3L x 36.6W x 41.3H inches)
Overall Dimensions (Reclined)	77L x 165W x 82H cm (30.3L x 65W x 32.3H inches)
Seat Dimensions	50L x 53W cm (19.7L x 20.9W inches)
Seat Height	49 cm (19.3 inches)
Backrest Height (Internal)	68 cm (26.8 inches)
Backrest Thickness	22 cm (8.7 inches)
Armrest Height	14 cm (5.5 inches)
Weight Capacity	150 kg (330 lbs)
Net Weight	32 kg (70.5 lbs)
Recline Angle	Up to 145 degrees
Massage Points	8 (back to legs)
Massage Intensity Levels	3
Massage Programs	4
Massage Timer Settings	10, 20, 30 minutes
Special Features	Electric Recline, Massage Function, Retractable Footrest, Swivel Table, Integrated Cup Holder, Side Pockets, Remote Control
Assembly Required	Yes
Care Instructions	Wipe clean with a damp cloth

## 9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact HOMCOM customer service directly. Keep your purchase receipt as proof of purchase.

Manufacturer: Aosom Italy

For assistance, please visit the HOMCOM store or contact your retailer.