RESPAWN RSP-110V2F-GRY

RESPAWN 110 Pro Gaming Chair User Manual

Brand: RESPAWN | Model: RSP-110V2F-GRY

1. Introduction

This manual provides comprehensive instructions for the assembly, operation, maintenance, and troubleshooting of your RESPAWN 110 Pro Gaming Chair. Designed for extended use, this chair combines ergonomic features with durable construction to enhance your gaming or work experience.

The RESPAWN 110 Pro Gaming Chair features thicker, segmented padding with dual-layer, high-density foam for lasting comfort. It includes a built-in extendable footrest and advanced lumbar support. Adjustability is key, with a 155-degree reclining backrest, pneumatic seat height adjustment, and pivoting padded armrests. This chair is built to support users up to 275 lbs.



Figure 1.1: RESPAWN 110 Pro Gaming Chair in a typical gaming environment.



Figure 1.2: Key dimensions of the RESPAWN 110 Pro Gaming Chair, including overall height (48"-51.2"), overall width (26.4"), overall depth (28"), interior arm width (21.7"), seat depth (21.3"), and seat height (18.5"-21.7").

2. Safety Information

Please read all safety warnings and instructions carefully before assembling and using the RESPAWN 110 Pro Gaming Chair. Failure to follow these instructions may result in injury or damage to the product.

- The maximum weight capacity for this chair is **275 pounds**. Do not exceed this limit to prevent instability and potential injury.
- Ensure all components are properly assembled and tightened before use. Periodically check all bolts and screws to ensure they remain secure.
- Keep hands and fingers clear of moving parts, especially during recline and height adjustments.
- Use the chair on a flat, stable surface to prevent tipping.
- Do not stand on the chair or use it as a step stool.
- Keep children and pets away from the chair during assembly and adjustment.

3. Setup and Assembly

Your RESPAWN 110 Pro Gaming Chair comes with detailed, color-illustrated assembly instructions. Please refer to the included guide for step-by-step assembly. All necessary tools and hardware are provided.

General Assembly Steps:

1. Unpack all components and verify against the parts list in your included manual.
2. Attach the casters to the chair base.
3. Insert the pneumatic cylinder into the base.
4. Assemble the seat and backrest components.
5. Attach the assembled seat and backrest to the pneumatic cylinder.
6. Install the headrest pillow and lumbar support cushion.



Figure 3.1: Key features and components of the RSP-110 Pro Gaming Chair, including 155-degree back recline, adjustable headrest pillow, endurance foam in seat and back, pivoting padded arm design, and extendable footrest.

4. Operating Instructions

Familiarize yourself with the various adjustment mechanisms of your RESPAWN 110 Pro Gaming Chair to optimize your comfort and support.

4.1. Recline Function

The chair features a 155-degree recline mechanism with an infinite angle lock. Locate the recline lever on the side of the chair (typically the right side when seated). Pull the lever up to unlock the backrest, lean back to your desired angle, and then push the lever down to lock it in place.

4.2. Seat Height Adjustment

To adjust the seat height, locate the pneumatic lift lever (typically below the seat on the right side). To raise the seat, lift the lever while taking your weight off the seat. To lower the seat, lift the lever while remaining seated.

4.3. Extendable Footrest

The chair is equipped with a built-in extendable footrest for added relaxation. To deploy the footrest, pull the handle located beneath the front of the seat. The footrest will slide out. To retract, push the footrest back into its stored position until it locks securely.



Figure 4.1: Steps to activate the extendable footrest: 1. Pull out the footrest from under the seat. 2. Rotate the footrest into position. 3. Extend fully for use.

4.4. Lumbar Support and Headrest Pillow

The chair includes an adjustable headrest pillow and a thick lumbar support cushion. These can be positioned to provide optimal support for your neck and lower back. Adjust their height by sliding them along the straps on the backrest.

4.5. Pivoting Padded Armrests

The armrests are designed to pivot with the recline of the backrest, maintaining support regardless of your seating angle. They are padded for comfort.




Figure 4.2: Close-up views of key features: pivoting padded armrests, extendable footrest, endurance foam in seat and back, and adjustable headrest pillow.

5. Maintenance

Proper maintenance will extend the life and appearance of your RESPAWN 110 Pro Gaming Chair.

5.1. Cleaning

For general cleaning, wipe the chair surfaces with a clean, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the fabric and other materials.

5.2. Hardware Inspection

Periodically inspect all bolts, screws, and connections to ensure they are tight. Re-tighten any loose hardware to maintain stability and safety.

5.3. Moving Parts

If any moving parts, such as the footrest mechanism or casters, become stiff, a small amount of silicone-based lubricant can be applied to improve their function. Avoid oil-based lubricants on plastic components.

6. Troubleshooting

This section addresses common issues you might encounter with your gaming chair.

6.1. Chair Wobbles or Feels Unstable

- **Solution:** Check all assembly bolts and screws. Ensure they are fully tightened. Make sure the chair is on a flat, even surface.

6.2. Seat Height Adjustment Not Working

- **Solution:** Ensure the pneumatic lift lever is fully engaged. If the issue persists, the pneumatic cylinder may need replacement. Contact customer support.

6.3. Footrest is Difficult to Extend or Retract

- **Solution:** Inspect the footrest rails for any obstructions. Apply a small amount of silicone lubricant to the sliding

mechanisms if needed.

6.4. Armrests Feel Loose

- **Solution:** Check the screws attaching the armrests to the seat base and backrest. Tighten them if they are loose.

7. Specifications

Feature	Detail
Brand	RESPAWN
Model Name	RSP-110
Item Model Number	RSP-110V2F-GRY
Color	2021 Grey Fabric
Product Dimensions	28"D x 26.4"W x 51.2"H
Overall Size (D x W x H)	28.50" x 26.75" x 48.50"-51.50"
Item Weight	46.3 pounds
Maximum Weight Recommendation	275 Pounds
Back Style	Solid Back
Special Features	Arm Rest, Cushion Availability, Ergonomic, Rolling, Swivel
Reclining Position Count	2 (up to 155 degrees)
UPC	192767015523

8. Warranty and Support

RESPAWN stands behind the durability and comfort of its gaming furniture.

8.1. Warranty Information

The RESPAWN 110 Pro Gaming Chair is backed by a **RESPAWN 5-Year Limited Warranty**. This warranty covers defects in materials and workmanship under normal use. Please refer to the warranty card included with your product for full terms and conditions.

8.2. Customer Support

For any questions, assistance with assembly, troubleshooting, or warranty claims, please contact RESPAWN customer support. Contact information can typically be found on the product packaging or the official RESPAWN website.

© 2025 RESPAWN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question