

Furmax MY0240480AAAA

Furmax Executive Office Chair User Manual

Model: MY0240480AAAA

Brand: Furmax

1. INTRODUCTION

Thank you for choosing the Furmax Executive Office Chair. This chair is designed to provide superior comfort and support for extended periods of sitting, featuring ergonomic design, a robust build, and versatile adjustments including a reclining backrest and a retractable footrest. This manual provides essential information for assembly, operation, maintenance, and troubleshooting to ensure you get the most out of your new office chair.

2. IMPORTANT SAFETY GUIDELINES

- **Maximum Weight Capacity:** This chair is designed to support a maximum weight of 400 pounds (181 kg). Do not exceed this limit to prevent damage or injury.
- **Stable Surface:** Always ensure the chair is placed on a stable, hard floor surface. Avoid uneven surfaces or thick carpets that may impede caster movement or stability.
- **Proper Adjustment:** Adjust the chair to fit your size and posture correctly. Improper adjustment can lead to discomfort or strain.
- **Caution with Features:** Use caution when operating the reclining function and extending/retracting the footrest to avoid pinching or injury. Ensure no obstructions are present.
- **Regular Inspection:** Periodically check all bolts, screws, and connections to ensure they are tight. Retighten as necessary.
- **Children and Pets:** Keep children and pets away from the chair during assembly and adjustment to prevent accidents.

3. PACKAGE CONTENTS

Before beginning assembly, please verify that all components are present and undamaged. If any parts are missing or damaged, please contact Furmax customer support.

- Chair Backrest
- Chair Seat with Armrests
- Retractable Footrest
- Star Base
- Casters (Wheels)
- Gas Lift Cylinder
- Mechanism Plate
- Hardware Kit (Screws, Washers, Allen Wrench)
- Assembly Instructions Manual

4. ASSEMBLY INSTRUCTIONS

The Furmax Executive Office Chair is designed for easy assembly, typically taking 20-25 minutes. Please follow the detailed step-by-step instructions provided in the separate assembly manual included in your package. Below is a general overview of the assembly process:

1. Attach the casters to the star base.
2. Insert the gas lift cylinder into the center hole of the star base.
3. Secure the mechanism plate to the underside of the chair seat using the provided screws.
4. Attach the chair backrest to the seat assembly.
5. Carefully place the assembled seat and backrest onto the gas lift cylinder.
6. Ensure all screws are tightened securely before use.

For visual guidance, refer to the product images and the official assembly video.

Image: The Furmax Executive Office Chair, fully assembled and positioned in a modern office environment, showcasing its sleek black design and ergonomic form.

Image: A detailed front view of the Furmax Executive Office Chair, highlighting the lumbar massage points with glowing orange circles, emphasizing its ergonomic features.

5. OPERATING INSTRUCTIONS

5.1. Height Adjustment

To adjust the seat height, locate the lever on the right side under the seat. While seated, pull the lever up to

lower the chair. To raise the chair, stand up slightly and pull the lever up. Release the lever at your desired height.

5.2. Reclining Function

The chair's backrest can recline between 90° (upright work mode) and 155° (rest/sleep mode). To recline, pull the lever on the left side under the seat upwards and lean back. Release the lever to lock the backrest in your desired position. To return to an upright position, lean forward slightly while pulling the lever up.

5.3. Retractable Footrest

For added comfort, especially when reclining, pull the footrest out from underneath the seat. Extend it fully until it locks into place. To retract, push it back underneath the seat until it is fully stored.

5.4. Lumbar Vibration Massage

The chair features two vibration points in the lumbar area to help relieve fatigue. Connect the USB cable to a compatible power source (e.g., computer USB port, USB wall adapter). Use the attached remote control to activate and adjust the vibration intensity. Please note: This function provides vibration only; it does not include kneading or heating.



Image: A visual representation of the Furmax Executive Office Chair's adjustable features, including the 90-155 degree recline range and the 4-inch height adjustment.



Image: A person comfortably reclining in the Furmax Executive Office Chair with the footrest fully extended, demonstrating the chair's relaxation capabilities.




Image: A detailed diagram highlighting the two vibration points in the lumbar area of the Furmax Executive Office Chair, indicating its massage function.

Video: An official product video demonstrating the key features of the Furmax Executive Office Chair, including its high resilience cushion, wide cushioned headrest, massage lumbar support, high-quality PU leather, comfortable armrests, 360-degree rotation, ergonomic design, adjustable backrest tilt, adjustable height, and soft footrest support.

6. MAINTENANCE

6.1. Cleaning

The chair is upholstered in high-quality PU leather, which is soft, skin-friendly, and easy to clean. To maintain its appearance and longevity:

- Wipe clean with a soft, damp cloth.
- Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the PU leather.
- For spills, blot immediately with a clean, dry cloth.

6.2. General Care

- Regularly check all screws and bolts to ensure they are tight. Retighten as needed to maintain stability and prevent squeaking.
- Keep the casters clean from hair and debris to ensure smooth rolling.
- Avoid exposing the chair to direct sunlight or extreme temperatures, which can cause the material to fade

or crack over time.

7. TROUBLESHOOTING

If you encounter any issues with your Furmax Executive Office Chair, refer to the common problems and solutions below:

Problem	Possible Cause	Solution
Chair wobbles or is unstable	Loose screws or connections.	Check and tighten all assembly screws, especially those connecting the seat to the backrest and the mechanism plate to the seat.
Chair does not adjust height	Gas lift cylinder malfunction or lever not engaged.	Ensure the height adjustment lever is fully engaged. If the issue persists, the gas lift cylinder may need replacement. Contact customer support.
Casters do not roll smoothly	Debris (hair, dust) caught in casters.	Turn the chair over and carefully remove any debris from the caster wheels.
Reclining function is stiff or not working	Mechanism obstruction or lever issue.	Ensure the reclining lever is fully engaged. Check for any obstructions under the seat mechanism.
Lumbar massage not working	USB power issue or remote control malfunction.	Ensure the USB cable is securely connected to a working power source. Check the remote control for any damage.

If the problem persists after attempting these solutions, please contact Furmax customer support for further assistance.

8. SPECIFICATIONS

Feature	Detail
Brand	Furmax
Model Name	Furmax Office Chair
Item Model Number	MY0240480AAAA
Color	Black
Product Dimensions	18.6"D x 25.6"W x 48.9"H (47.2cm D x 65cm W x 124.2cm H)

Feature	Detail
Item Weight	40.1 pounds (18.2 kg)
Maximum Weight Recommendation	400 Pounds (181 kg)
Material	PU Leather (Furniture Finish), Foam (Fill Material), Nylon (Finish Type)
Special Features	Reclining (90°-155°), Adjustable Height, Adjustable Backrest, Lumbar Vibration Massage, Retractable Footrest
Back Style	Solid Back
Furniture Base Movement	Swivel (360 degrees)
Assembly Required	Yes
Product Care Instructions	Wipe Clean

Image: A detailed diagram illustrating the key dimensions of the Furmax Executive Office Chair and its maximum weight capacity of 400 lbs.

9. WARRANTY AND SUPPORT

Furmax provides a warranty for its products, covering manufacturing defects. Specific warranty terms and conditions, including duration and coverage details, are typically included with your product packaging or can be found on the official Furmax website. Please retain your proof of purchase for warranty claims.

For technical support, replacement parts, or any other inquiries, please contact Furmax customer service through the contact information provided in your product documentation or on the official Furmax brand store page.

Visit the Furmax Store: <https://www.amazon.com/stores/Furmax/page/A9387283-3F74-4244-90A6-48D61AD7B83D>