

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [WOODBIDGE](#) /

› [WOODBIDGE Widespread Deck Mount Roman Tub Faucet with Hand Shower \(Model F0041CH\) - Instruction Manual](#)

WOODBIDGE F0041CH

WOODBIDGE Widespread Deck Mount Roman Tub Faucet with Hand Shower

Model: F0041CH

INTRODUCTION

Thank you for choosing the WOODBRIDGE Widespread Deck Mount Roman Tub Faucet with Hand Shower. This manual provides detailed instructions for the safe installation, operation, and maintenance of your new faucet. Please read this manual thoroughly before installation and retain it for future reference.

SAFETY INFORMATION

- Always turn off the main water supply before installing or performing any maintenance on the faucet.
- Wear safety glasses and gloves during installation to prevent injury.
- Ensure all local plumbing and building codes are met.
- If you are unsure about any part of the installation, consult a professional plumber.

INCLUDED COMPONENTS

Verify that all components are present before beginning installation:




Image: Exploded view of the WOODBRIDGE F0041CH faucet components, showing each part labeled with a number.

1. Brass Faucet Body
2. Faucet Switch (Handles)
3. Handheld Shower
4. Shower Hose (60" stainless steel)
5. Shower Holder
6. Deck Plate
7. Water Supply Hoses (Hot/Cold waterlines)

DIMENSIONS AND SPECIFICATIONS

Refer to the diagram below for detailed dimensions and ensure compatibility with your bathtub setup.

WOODBIDGE®



ATTENTION! Dimensions may vary by up to 3/8". It is highly recommended to pull all dimensions of actual model for installation and measuring purposes.

ATTENTION! Measurements in inches are rounded to the nearest 1/8".

www.woodbridgebath.com

Image: Technical drawing illustrating the dimensions of the WOODBRIDGE F0041CH faucet, including spout height, spout reach, and mounting spread.

Product Specifications

Feature	Specification
Brand	WOODBRIDGE
Model Number	F0041CH
Color	Chrome
Material	Stainless Steel, Brass
Finish Type	Chrome
Number of Handles	2 (Two-Handle)
Mounting Type	Deck Mount (4-Holes)
Spout Height	10-1/2 inches
Spout Reach	7-3/4 inches
Max Spout Flow Rate	4.5 GPM at 80 PSI
Max Hand Shower Flow Rate	1.8 GPM at 80 PSI
Hand Shower Hose Length	60 inches (Stainless Steel)
Item Weight	9 Pounds
Product Dimensions	12.88 x 7.75 x 10.5 inches

INSTALLATION INSTRUCTIONS

This faucet is designed for a 4-hole deck mount installation. Professional installation is recommended.

- 1. Prepare the Mounting Surface:** Ensure the bathtub deck has four pre-drilled holes with the correct spacing for the faucet body, handles, and hand shower holder. The recommended spread for the deck mount tub filler is 10-1/4 inches.
- 2. Install Faucet Body and Handles:** Insert the brass faucet body and the two faucet switches (handles) into their respective holes on the deck plate. Secure them from underneath the deck using the provided mounting hardware. Ensure they are tightened securely but do not overtighten.
- 3. Connect Water Supply Lines:** Attach the hot and cold water supply hoses to the corresponding inlets on the faucet body. Connect the other ends of the hoses to your hot and cold water supply valves. Use thread sealant tape on all threaded connections to prevent leaks.
- 4. Install Hand Shower Holder:** Insert the shower holder into its designated hole on the deck. Secure it from underneath with the provided hardware.
- 5. Connect Hand Shower Hose:** Attach one end of the 60-inch stainless steel shower hose to the outlet on the faucet body (diverter connection) and the other end to the handheld shower head.
- 6. Test for Leaks:** Once all connections are made, slowly turn on the main water supply. Check all connections for leaks. If leaks are detected, tighten the connections as necessary.
- 7. Verify Operation:** Test the faucet spout and handheld shower to ensure proper water flow and temperature control.

OPERATION

Your WOODBRIDGE Roman Tub Faucet features two handles for precise control of water temperature and flow, along with

a pull-out hand shower for added convenience.



Image: The main spout of the WOODBRIDGE F0041CH faucet actively filling a bathtub with water.

- **Controlling Water Flow and Temperature:** Use the two handles to adjust the hot and cold water supply. Turn the handles to achieve your desired water temperature and flow rate for the main spout.
- **Using the Hand Shower:** To activate the hand shower, pull it from its holder. The faucet includes a diverter mechanism that switches water flow from the main spout to the hand shower. The 60-inch flexible hose allows for maximum reach and movement, ideal for rinsing or cleaning the tub.



Image: A hand holding the handheld shower of the WOODBRIDGE F0041CH faucet, demonstrating its use to spray water into a bathtub.

CARE AND MAINTENANCE

Proper care and maintenance will ensure the longevity and appearance of your faucet.

- **Cleaning:** Clean the faucet regularly with a soft cloth and mild soap. Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the chrome finish.
- **Water Spots:** To prevent water spots, wipe the faucet dry after each use.
- **Aerator Maintenance:** Periodically unscrew the aerator from the spout and clean any mineral deposits or debris that may restrict water flow.

TROUBLESHOOTING

If you encounter any issues, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Low Water Flow	Clogged aerator; partially closed shut-off valves; debris in water lines.	Clean the aerator. Ensure shut-off valves are fully open. Flush water lines.
Leaks from Faucet Base	Loose mounting nuts; worn O-rings or gaskets.	Tighten mounting nuts. Inspect and replace O-rings or gaskets if necessary.
Dripping Faucet	Worn cartridge.	Replace the faucet cartridge.
Water Temperature Issues	Incorrect hot/cold water line connection; issues with water heater.	Verify hot and cold lines are connected correctly. Check water heater settings.

If these steps do not resolve the issue, please contact customer support.

WARRANTY INFORMATION

WOODBIDGE brand offers a **1-year limited warranty** on this product. This warranty covers manufacturing defects in materials and workmanship under normal use and service.

The warranty does not cover damage resulting from improper installation, misuse, abuse, accident, or normal wear and tear. Proof of purchase is required for all warranty claims.

CUSTOMER SUPPORT

For customer support, inquiries, or concerns regarding your WOODBRIDGE faucet, please reach out to our dedicated support team:

Email: help@woodbridgebath.com

Please have your model number (F0041CH) and proof of purchase ready when contacting support.