

## Fastrack 3315KM01

# Fastrack Opulence Quartz Chronograph Watch NT3315KM01 User Manual

## 1. INTRODUCTION

This manual provides comprehensive instructions for the Fastrack Opulence Quartz Chronograph Watch, model NT3315KM01. Please read this manual carefully to understand the functions and proper operation of your watch. Retain this manual for future reference.

## 2. PRODUCT OVERVIEW AND FEATURES

The Fastrack Opulence Quartz Chronograph Watch NT3315KM01 combines precise quartz timekeeping with advanced chronograph capabilities and a unique moon phase display. Key features include:

- **Quartz Movement:** Ensures accurate and reliable timekeeping.
- **Chronograph Function:** Measures elapsed time with precision.
- **Integrated Moon Phase Sub-Dial:** Displays the current lunar phase.
- **Analog Display:** Clear and easy-to-read dial with distinct hands.
- **Durable Construction:** Features a black metal strap and robust casing.
- **Water Resistance:** Rated for 50 meters (5 ATM).



Image 1: Front view of the Fastrack Opulence Quartz Chronograph Watch NT3315KM01, showcasing the black dial, chronograph subdials, and moon phase indicator.

### 3. WATCH COMPONENTS

Familiarize yourself with the main components of your watch:

- **Crown (A):** Used for setting the time.
- **Pusher (B, Red):** Activates and stops the chronograph function.
- **Pusher (C, Black):** Resets the chronograph hands to zero.
- **Hour, Minute, and Second Hands:** Indicate the current time.
- **Chronograph Subdials:** Measure elapsed seconds, minutes, and 1/10th seconds.
- **Moon Phase Sub-dial:** Displays the current phase of the moon.



Image 2: Angled view of the watch, highlighting the crown and pushers on the side of the case.



Image 3: Side profile of the watch, providing a clear view of the crown and the red and black pushers.

## 4. SETUP AND INITIAL ADJUSTMENT

---

### 4.1. Setting the Time

1. Pull the crown (A) out to its outermost position (Position 2).
2. Rotate the crown to move the hour and minute hands clockwise until the correct time is displayed.
3. Push the crown back into its normal operating position (Position 0).

### 4.2. Setting the Moon Phase

The moon phase sub-dial typically advances with the watch's timekeeping. If the moon phase display requires adjustment, it is usually linked to the time setting mechanism or a specific crown position. For precise adjustment, it is recommended to consult a qualified watch technician or refer to the detailed manufacturer's guide if available, as incorrect adjustment can affect other functions.

## 5. OPERATING INSTRUCTIONS

---

### 5.1. Using the Chronograph Function

The chronograph allows you to measure elapsed time independently of the main time display.

1. **Start:** Press the red Pusher (B) once to start the chronograph. The chronograph second hand and minute sub-dial will begin to move.
2. **Stop:** Press the red Pusher (B) again to stop the chronograph. The elapsed time will be indicated by the chronograph hands.
3. **Reset:** After stopping the chronograph, press the black Pusher (C) to reset all chronograph hands to their zero positions.

## 5.2. Moon Phase Display

The moon phase sub-dial visually represents the current phase of the moon (e.g., new moon, crescent, quarter, gibbous, full moon). This display advances automatically as the watch keeps time.

## 6. CARE AND MAINTENANCE

---

- **Cleaning:** Regularly wipe the watch case and strap with a soft, dry cloth to remove dust and dirt. For the metal strap, a slightly damp cloth can be used, ensuring it is dried thoroughly afterward.
- **Water Resistance:** This watch is water resistant up to 50 meters (5 ATM). It is suitable for short periods of recreational swimming. However, it is not designed for diving, snorkeling, or prolonged water immersion. Do not operate the crown or pushers while the watch is wet or submerged.
- **Battery Replacement:** The watch is powered by a Lithium Polymer battery. When the battery life ends, it should be replaced by a qualified watch technician to ensure proper sealing and function.
- **Avoid Extreme Conditions:** Protect your watch from extreme temperatures (hot or cold), strong magnetic fields, and severe impacts, as these can affect its accuracy and longevity.



Image 4: Rear view of the watch, displaying the stainless steel case back and water resistance marking.

## 7. TROUBLESHOOTING

- **Watch Not Running:** Ensure the crown is fully pushed into Position 0. If the watch still does not operate, the battery may require replacement.
- **Chronograph Hands Not Resetting to Zero:** Press Pusher (C) firmly. If the hands remain misaligned, a specific reset procedure may be necessary, which typically involves pulling the crown to a certain position and pressing the pushers in sequence. It is advisable to consult a watch specialist for this.
- **Moon Phase Display Incorrect:** If the moon phase is significantly out of sync, it may need manual adjustment. This is best handled by a watch technician to prevent damage.

## 8. SPECIFICATIONS

Feature	Detail
Brand	Fastrack
Model Number	3315KM01

Feature	Detail
Display Type	Analog
Movement	Quartz
Power Source	Battery Powered
Battery Type	Lithium Polymer (1 required, included)
Water Resistance	50 meters (5 ATM)
Item Weight	130 g
Product Dimensions	13 x 9 x 6 cm

## 9. WARRANTY AND SUPPORT

This Fastrack watch is covered by a manufacturer's warranty. For specific warranty terms, service requests, or technical support, please refer to the warranty card included with your purchase. You may also contact Fastrack customer service directly using the information below:


**Manufacturer:** Titan Company Limited




**Address:** 3, Sipcot Industrial Complex, Hosur - 635126

**Email:** [corpcomm@titan.co.in](mailto:corpcomm@titan.co.in)

**Phone:** +91-(0)4344-664199

### Related Documents - 3315KM01

	<p><a href="#">Fastrack S06 Smartwatch User Manual</a></p> <p>Comprehensive user manual for the Fastrack S06 Smartwatch, covering setup, features, maintenance, and safety information.</p>
<p><small>User Manual of Product 1: Fastrack Urban New Reflex Beat+ Smartwatch (1.31) (Black) Display (300 Nits Brightness) Sports Modes (10) WaterResistant - 7 ATM (50Meters) Tracker (Music &amp; Camera) Control 5 Days Battery (48h) (Black)</small></p> <p><small>User Manual of Product 2: Fastrack New Reflex Beat+ Smartwatch (1.31) (Black) Display (300 Nits Brightness) Sports Modes (10) WaterResistant - 7 ATM (50Meters) Tracker (Music &amp; Camera) Control 5 Days Battery (48h) (Black)</small></p>	<p><a href="#">Fastrack Reflex Play Smartwatch User Manual: Setup, Features, and Troubleshooting</a></p> <p>Comprehensive user manual for the Fastrack Reflex Play smartwatch, covering setup, app connection, features like fitness tracking, heart rate monitoring, notifications, and troubleshooting guides.</p>
<p><small>User Manual of Product 1: Fastrack Urban New Reflex Beat+ Smartwatch (1.31) (Black) Display (300 Nits Brightness) Sports Modes (10) WaterResistant - 7 ATM (50Meters) Tracker (Music &amp; Camera) Control 5 Days Battery (48h) (Black)</small></p> <p><small>User Manual of Product 2: Fastrack New Reflex Beat+ Smartwatch (1.31) (Black) Display (300 Nits Brightness) Sports Modes (10) WaterResistant - 7 ATM (50Meters) Tracker (Music &amp; Camera) Control 5 Days Battery (48h) (Black)</small></p>	<p><a href="#">Fastrack Reflex Beat+ Smartwatch User Manual: Features, Pairing &amp; Setup</a></p> <p>Comprehensive user manual for the Fastrack Reflex Beat+ Smartwatch. Learn about its features, app installation, watch pairing, health tracking, and technical specifications.</p>

	<p><a href="#">Fastrack FPods FT7 Truly Wireless Earpods Quick Start Guide</a></p> <p>Get started with your Fastrack FPods FT7 Truly Wireless Earpods. This guide covers setup, controls, features like 3C NitroFast Charge, Quad Mic ENC, and low latency gaming mode.</p>
	<p><a href="#">Lionel Plug-Expand-Play Classic Automatic Gateman Owner's Manual</a></p> <p>Owner's manual for the Lionel Plug-Expand-Play Classic Automatic Gateman accessory (model 78-1063-250). Provides instructions on assembly, wiring options for various track systems (Plug-Expand-Play, FasTrack, Tubular Track) and control systems (TMCC, LEGACY), and warranty information.</p>
	<p><a href="#">Fastrack FPods FZ100 Truly Wireless Earbuds Quick Start Guide</a></p> <p>Learn how to set up, use, and care for your Fastrack FPods FZ100 Truly Wireless Earbuds. This guide covers pairing, controls, features like gaming mode and voice assistant, charging, and specifications.</p>