

[Manuals.plus](#) /

> [Huuger](#) /

> Huuger 9-Drawer Dresser and TV Stand Instruction Manual (Model B0DGL7FV53)

## Huuger B0DGL7FV53

# Huuger 9-Drawer Dresser and TV Stand Instruction Manual

Model: B0DGL7FV53

## 1. INTRODUCTION

Thank you for choosing the Huuger 9-Drawer Dresser. This versatile furniture piece is designed to provide ample storage and can also serve as a TV stand for screens up to 60 inches. Constructed with a durable metal frame, a robust wooden top, and fabric drawers, it offers a blend of functionality and style. This manual provides essential information for assembly, usage, maintenance, and safety to ensure optimal performance and longevity of your product.



Image 1.1: The Huuger 9-Drawer Dresser in Rustic Brown. This image displays the dresser's overall appearance with its

## 2. SAFETY INFORMATION

- **Anti-Tip Kit:** Always attach the dresser to the wall using the included anti-tip kits to prevent accidental tipping, especially in households with children or pets. Failure to do so may result in serious injury.
- **Weight Capacity:** Do not exceed the maximum weight capacity for each drawer (12 pounds) or the top surface. Overloading can compromise stability and structural integrity.
- **Placement:** Place the dresser on a flat, stable, and level surface. Use the adjustable feet to ensure stability on uneven floors.
- **Children Safety:** Do not allow children to climb on or play with the dresser or its drawers. Keep small parts away from children during assembly.



Image 2.1: A diagram illustrating the correct installation of the anti-tip device to secure the dresser to a wall, emphasizing safety.

## 3. PACKAGE CONTENTS

Verify that all components listed below are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Metal Frame Components
- Wooden Top Panel
- Fabric Drawers (9 units)
- Drawer Handles
- Adjustable Feet (5 units)
- Anti-Tip Kit
- Assembly Hardware (screws, Allen key)
- Instruction Manual

## 4. SETUP AND ASSEMBLY

Assembly is designed to be straightforward and typically takes approximately 30 minutes. All necessary parts and detailed instructions are included.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Frame:** Follow the step-by-step diagrams in the included instruction booklet to connect the metal frame components using the provided hardware and Allen key. Ensure all connections are secure.
3. **Attach Top Panel:** Secure the wooden top panel to the assembled metal frame.
4. **Install Adjustable Feet:** Screw the 5 adjustable feet into the bottom of the frame. Adjust them as needed to level the dresser on your floor.
5. **Prepare Drawers:** Unfold each fabric drawer and insert the bottom panel to create a sturdy box.
6. **Attach Handles:** Secure the handles to the front of each fabric drawer.
7. **Insert Drawers:** Slide the assembled drawers into their respective compartments within the frame.
8. **Install Anti-Tip Kit:** Following the instructions in the safety section, securely attach the anti-tip kit to the dresser and the wall.




Image 4.1: A detailed view highlighting the supporting bars for drawer stability and the adjustable feet for leveling the dresser.

## 5. USAGE AND OPERATING

The Huuger 9-Drawer Dresser offers versatile storage and display options:

- **Storage:** The nine deep fabric drawers (17.1 x 13.8 inches each) provide ample space for clothing, bedding, media collections, gaming gear, and other household items. Each drawer can hold up to 12 pounds.
- **TV Stand:** The wide desktop (54 x 13.8 inches) is suitable for holding televisions up to 60 inches, making it an ideal entertainment center.
- **Versatile Placement:** This dresser is suitable for various rooms including bedrooms, living rooms, closets, hallways, and nurseries.



Each Drawer  
Capacity



## LARGE STORAGE CAPACITY



 20~26 Shirts •  12~14 Jeans

Image 5.1: The dresser with several drawers pulled out, demonstrating its large storage capacity for various items like folded clothes.



*Image 5.2: The dresser functioning as a TV stand in a living room setting, with a 55-inch television placed on top.*

## 6. MAINTENANCE

- **Cleaning:** Wipe the wooden top and metal frame with a damp cloth. For fabric drawers, spot clean with a mild detergent and allow to air dry. Avoid harsh chemicals or abrasive cleaners.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Drawer Care:** Avoid overfilling drawers to maintain their shape and ensure smooth operation.

## 7. TROUBLESHOOTING

- **Dresser Wobbles:** Adjust the individual feet at the bottom of the dresser until it is stable on your floor.
- **Drawers Not Closing Smoothly:** Ensure drawers are not overloaded. Check for any obstructions within the drawer compartments.
- **Missing Parts:** Refer to the 'Package Contents' section. If any parts are missing upon arrival, contact customer support for assistance.

## 8. SPECIFICATIONS

Feature	Detail
Brand	Huuger
Model Number	B0DGL7FV53
Product Dimensions	13.8"D x 54"W x 26.8"H
Color	Rustic Brown
Room Type	Bedroom, Living Room
Product Care Instructions	Wipe with Damp Cloth
Assembly Required	Yes
Item Weight	31.9 pounds
Drawer Capacity	Up to 12 pounds per drawer
TV Size Support	Up to 60 inches



*Image 8.1: A visual representation of the dresser's dimensions, including height, width, and depth, alongside a human figure for scale.*

## **9. CUSTOMER SUPPORT**

For any questions, concerns, or assistance with your Huuger 9-Drawer Dresser, please contact Huuger customer support. Refer to your purchase documentation for specific contact details or visit the official Huuger website.

---

© 2024 Huuger. All rights reserved.